

Plastic drop machine Setting

1. Machine set file / pin okay

1.1 We use parallel injection guns for mold injection .

| S/N | Pin 1 (color 1) | Pin 2(color 2) | Pin 3(color 3) |
|---------|-----------------|-----------------|-----------------|
| Machine | Injection gun 1 | Injection gun 2 | Injection gun 3 |
| | Injection gun 4 | Injection gun 5 | Injection gun 6 |



pin 1, pin 2, pin 3,
pin 4 groups.MP4

Video :

2.2 install pins for machine

There are 9 different pins , according to mold inside figure size to choose pin size .



① use pin tip to measure mold inside figure .



② loose the injection gun cap to put pin on injection gun and cover the cap and tighten. 2

parallel injection guns install same size pin .



2.2 About the mold size and cross '+' distance


① : the mold short side with 4 crosses '+' w gun side .




② all molds size , cross position , and cross distances are all the same , just use any one mold to set file / pin okay .








2.3 set file /pin okay at machine .






① open 'Cylinder ' button on machine , put a mold on machine 2 table, press' LT Clamp' or 'RT Clamp' to fix mold on table .
















②set pin 1, 2, 3 okay , file 1 okay operation .





| | | |
|--------|--|---|
| Step 1 | Press 'P/F' to let 'pin 1' display on LCD screen |  |
| | Press 'C' to let injection gun 1 down . |  |
| | Press 'Sel' to let pin 4' display on LCD screen , |  |
| | press 'C' to let injection gun 4 down. |  |
| Step 2 | Press 'Sel' to let pin 1 display on LCD , |  |
| | Press 'X+,X-,Y+,Y-,Z+,Z-' to let the first injection gun 1 to aim at the center of first cross . |   |

| | |
|--|--|
| <p>Loose injection gun 4 bracket screw and manual move injection gun tip aim at the center of ' + '. the injection gun bracket can move to left ,right , and front , back .</p> <p>The bracket front screw adjust injection gun 4 up and down .</p> <p>Tighten the screw after aim at the center of cross .</p> <p>After adjust 'injection gun 1 and injection 4 ' .</p> |  |
| <p>Press 'Pro-0' to set 'pin 1' okay</p> |  |
| <p>Step 3: Press 'P/F' to shift 'pin 1' to 'file 1' displayed on LCD screen,</p> |  |
| <p>Press 'File-set 0', LCD screen display 'File 1 ok' .</p> |  |
| <p>Press 'P/F' to shift 'file 1' to 'pin 1'. press 'C', injection gun 1 goes up</p> |  |


| | | |
|---------------|---|--|
| | <p>Press 'Sel' to let pin 4' display on LCD screen . press 'C' , injection gun 4 goes up.</p> |   <p>injection gun 4 goes up</p> |
| <p>Step 5</p> | <p>Press 'Sel' to let pin 5' display on LCD screen . press 'C' , injection gun 5 goes down.</p> |   <p>injection gun 5 down</p> |
| | <p>Press 'Sel' to let pin 2' display on LCD screen ,press 'C' to let injection gun 2 down.</p> |   <p>injection gun 2</p> |
| | <p>Press 'X+,X-,Y+,Y-,Z+,Z-' to first move injection gun 2 aim at the center of '+'. +</p> |   <p>injection gun 2</p> |

| | | |
|----------------------|--|--|
| | <p>loose injection gun 5 bracket screw to make injection gun 5 tip aim at the center of '+' and tighten the screw.</p> |  |
| <p>Step 6</p> | <p>Press 'pro-0' to set pin 2 okay .</p> |  |
| | <p>Press 'C' rise up 'injection gun 2' .</p> |  |
| | <p>Press 'Sel' shift to 'pin 5' , press 'C' to rise up injection gun 5.</p> |  |
| | <p>Press ' Sel' to shift 'pin 5 'to' pin 6' display on LCD screen . Press ' C' to let injection gun 6 down .</p> |  |


Press 'Sel' to let 'pin 3' display on LCD screen . press 'C' to let injection gun 3 down .




Press 'X+,X-, Y+,Y-, Z+,Z-' to let injection gun 3 aim at the center of the 1st mold cross





please loose injection gun 6 bracket screw to make injection gun tip aim at the center of ' + ' and tighten the screw.



Press 'pro-0' to set pin 3 okay .



Press 'C' , injection gun 3 goes up , press 'Sel' shift to pin 6 , press 'C' , injection gun 6 goes up.



2. Production .

3.1 Adding material .




| | | |
|-----------------------------------|---|--|
| Syringe 1 stock white PVC | Supply PVC to injection gun 1 | Used to inject big letters |
| syringe 2 stock white PVC | Supply PVC to injection gun 2 | Used to inject small letters |
| syringe 3 stock white PVC | Supply PVC to injection gun 3 | Used to inject big letters |
| syringe 4 stock white PVC | Supply PVC to injection gun 4 | Used to inject small letters |
| syringe 5 stock Green / black PVC | Supply PVC to injection gun 5 and injection gun 6 | Restonic label base has two base . when make black base , please add black pvc in syringe 5. If make green base , please add green pvc in syringe . |


3.2 Release MACHINE Injection guns air



- ① Press machine 1 and 3 valve buttons to open material .
- ② before working , please release each machine air out from injection gun .


| | | |
|--|---|--|
| Release MACHINE Injection guns air | First , please press X,Y to move the injection guns on top of waste narrow sink . |  |
| | Press 'P/F' shift to Pin 1 . Press ' V ' 15-20 times to let PVC out from injection gun 1 to release air out . | |
| | Press 'Sel' shift to Pin 2 . Press ' V ' 15-20 times to let PVC out from injection gun 2 to release air out . | |
| | Press 'Sel' shift to Pin 3 . Press V 15-20 times to let PVC out from injection gun to release air out . | |
| | Press 'P/F' shift to Pin 4 . Press V 15-20 times to let PVC out from injection gun to release air out . | |
| | Press 'P/F' shift to Pin 5 . Press V 15-20 times to let PVC out from injection gun to release air out . | |
| | Press 'P/F' shift to Pin 6 . Press V 15-20 times to let PVC out from injection gun to release air out . | |

3.3 air pressure meter adjustment for machine 1,2,3



| | |
|-------------------|---|
| MACHINE Air meter | RV 1 to control injection gun 1 material flow volume. Meter working number within 0.4. if the pvc is too much , please reduce the air pressure , if too small , please increase the air pressure |
| | RV 2 to control injection gun 2 material flow volume. Meter working number within 0.4. if the pvc is too much , please reduce the air pressure , if too small , please increase the air pressure |
| | RV 3 to control injection gun 3 material flow volume. Meter working number within 0.4. if the pvc is too much , please reduce the air pressure , if too small , please increase the air pressure |
| | RV 4 to control injection gun 4 material flow volume. Meter working number within 0.4. if the pvc is too much , please reduce the air pressure , if too small , please increase the air pressure |
| | RV 5 to control injection gun 5, gun 6 material flow volume. Meter working number within 0.4. if the pvc is too much , please reduce the air pressure , if too small , please increase the air pressure |


3.4 software pin setting .



① Open Weldo software, click **Controller**, choose pin setting:


② please tick the valve and cylinder for pin 1 , pin 2, pin 3 .as below image.


DONG GUAN WELDO





③ measure the distance from the 1st cross to the 2nd cross .


Measure X direction distance. Measure the distance between two near cross.

①click  => put the curse suppose on the first cross + => move curse to the second cross + => move curse to the second, there will be a line as below shows:






② Click  to change the curse to arrow.



③ click the line by left mouse

④ Read the distance from the statue column




⑤ double click blank , the File Property Setting will pup out , fill in 2 in Copies of X-axis direction that mean the pin

will move 2 times to the right . fill the distance 18.881 to X-axis

X-axis offset(mm): .that mean the distance between two near

copies in X direction is 18.881mm. Press'



⑥Select the line , press “Delete” to delete the line.

DONG GUAN WELDO