

download file 1
plate 2 to machine

download file to
machine 2.MP4

Video:

2. Machine set file / pin okay

2.1 We use parallel injection guns for mold injection .

S/N	Pin 1 (color 1)	Pin 2(color 2)	Pin 3(color 3)	Pin 4(color 4)
Machine 1	Injection gun 1	Injection gun 2	Injection gun 3	Injection gun 7
	Injection gun 4	Injection gun 5	Injection gun 6	Injection gun 9
S/N	Pin 1 (color 1)	Pin 2(color 2)	Pin 3(color 3)	
	For big figure	For small figure	For stitching line	
Machine 2	Injection gun 1	Injection gun 2	Injection gun 3	
	Injection gun 4	Injection gun 5	Injection gun 6	

pin 1, pin 2, pin 3,
pin 4 groups.MP4

Video :

2.2 install pins for machine 2

There are 9 different pins , according to mold inside figure size to choose pin size .



① use pin tip to measure mold inside figure .



② loose the injection gun cap to put pin on injection gun and cover the cap and tighten. 2

parallel injection guns install same size pin .




 choose pin and install on injection

Video :

2.2 About the mold size and cross '+' distance

① : the mold short side with 4 crosses '+' w gun side .




② all molds size , cross position , and cross distances are all the same , just use any one mold to set file / pin okay .




Video :

2.3 set file /pin okay at machine 2 .









① open 'Cylinder ' button on machine , put a mold on machine 2 table, press' LT Clamp' or 'RT Clamp' to fix mold on table .














② set pin 1, 2 , 3 okay , file 1 , file 2, file 3 okay operation .






Step1	Press 'P/F' to let 'pin 1' display on LCD screen	 
	Press 'C' to let injection gun 1 down.	 
	Press 'Sel' to let pin 4' display on LCD screen,	 
	press 'C' to let injection gun 4 down.	 

Step2	Press 'Sel' to let pin 1 display on LCD ,	
	Press 'Pro-0' , machine automatically moves injection gun 1 down to mold 1st '+', injection gun 4 down to mold 3rd '+'. the injection gun 1 and injection gun 4 tip not aim at the center of '+'	
	<p>Loose injection gun bracket screw and manual move injection gun tip aim at the center of '+'. the injection gun bracket can move to left ,right , and front , back .</p> <p>The bracket front screw adjust injection gun up and down .</p> <p>Tighten the screw after aim at the center of cross .</p> <p>After adjust 'injection gun 1 and injection 4 '. pin 1 is okay .</p> <p>Video :  set pin 1 okay at machine 2.MP4</p>	
Step3:	Press 'P/F' to shift 'pin 1' to 'file 1' displayed on LCD screen,	
	Press 'File-set 0', LCD screen display 'File 1 ok' .	
	Press 'Sel' shift 'File 1' to 'File 2' display on LCD screen .	


	<p>Press 'File-set 0', LCD screen display 'File 2 ok'.</p>	
	<p>Press 'Sel' shift 'File 2' to 'File 3' display on LCD screen</p>	
	<p>Press 'File-set 0', LCD screen display 'File 3 ok'. 3 files zero set okay .</p>	
	<p>Press 'P/F' to shift 'file 3' to 'pin 1'. press 'C', injection gun 1 goes up</p>	
	<p>Press 'Sel' to let pin 4 display on LCD screen . press 'C', injection gun 4 goes up.</p>	
<p>Step 5</p>	<p>Press 'Sel' to let pin 5 display on LCD screen . press 'C', injection gun 5 goes down.</p>	
	<p>Press 'Sel' to let pin 2 display on LCD screen ,press 'C' to let injection gun 2 down.</p>	

Press 'Pro-0' machine automatically moves injection gun 2 down to mold 1st '+', injection gun 5 down to mold 3rd '+'. →

Pro-0




Injection gun 2 and 5 tip not aim at the center of '+'. loose injection gun bracket screw to make injection gun 2, 5 tip aim at the center of '+' and tighten the screw.




Video :




set pin 2 okay and adjust injection




Step6 Press 'C' rise up 'injection gun 2'.




Press 'Sel' shift to pin 5'



Press ' Sel' to shift 'pin 5 'to' pin 6' display on LCD screen . Press' C' to let injection gun 3down .




Press'Sel' to let 'pin 3'display on LCD screen .



Press' Pro-0' , machine automatically moves injection gun 3 down to mold 1st '+', injection gun 6 down to mold 3rd '+'.
↓





Please check injection gun tip aim at the center of '+' or not , if not ,please loose injection gun bracket screw to make injection gun tip aim at the center of '+' and tighten the screw.



Video :

set pin 3 okay at machine 2.MP4




Press 'C' , injection gun 3 goes up , press 'Sel' shift to pin 6 , press 'C' , injection gun 6 goes up.

Video :



set pin 3 okay at machine 2.MP4



2.4 set file / pin okay at machine 1

①install pins for injection guns




②Operation steps

Step1	Press 'P/F' to let 'pin 1' display on LCD screen	
	Press 'C' to let injection gun 1 down.	
	Press 'Sel' to let pin 4' display on LCD screen ,	
	press 'C' to let injection gun 4 down.	
Step2	Press 'Sel' to let pin 1 display on LCD ,	
	Press 'Pro-0' , machine automatically moves injection gun 1 down to mold 1st '+', injection gun 4 down to mold 3rd '+'. the injection gun 1 and injection gun 4 tip aim at the center of '+'. no need to adjust injection gun 1 and injection 4 .	
Step3:	Press 'P/F' to shift pin 1' to 'file 1 ' displayed on LCD screen,	

	<p>Press 'File-set 0', LCD screen display 'File 1 ok'.</p> 
	<p>Press 'Sel' shift 'File 1' to 'File 2' display on LCD screen.</p> 
	<p>Press 'File-set 0', LCD screen display 'File 2 ok'.</p> 
	<p>Press 'Sel' shift 'File 2' to 'File 3' display on LCD screen</p> 
	<p>Press 'File-set 0', LCD screen display 'File 3 ok'. 3 files zero set okay.</p> 
	<p>Press 'P/F' to shift 'file 3' to 'pin 1'. press 'C', injection gun 1 goes up</p> 
	<p>Press 'Sel' to let pin 4' display on LCD screen. press 'C', injection gun 4 goes up.</p> 
<p>Step 5</p>	<p>Press 'Sel' to let pin 5' display on LCD screen. press 'C', injection gun 5 goes down.</p> 


Press 'Sel' to let pin 2' display on LCD screen ,press 'C' to let injection gun 2 down.



Press 'Pro-0' , machine automatically moves injection gun 2 down to mold 1st '+', injection gun 5 down to mold 3rd '+'. →



Step6 Press 'C' rise up 'injection gun 2' .




Press 'Sel' shift to pin 5'




Press 'Sel' to shift 'pin 5' to 'pin 6' display on LCD screen . Press 'C' to let injection gun 3 down .




Press 'Sel' to let 'pin 3' display on LCD screen .



Press 'Pro-0' , machine automatically moves injection gun 3 down to mold 1st '+' center, injection gun 6 down to mold 3rd '+' center .




Press 'C' ,
 injection gun 3
 goes up , press
 'Sel' shift to pin
 6 , press 'C' ,
 injection gun 6
 goes up.
 Video :




Step7 Press 'Sel' shift
 'pin 6 ' to 'pin
 7',press 'C' to
 press injection 7
 down .



Press 'Sel' shift
 'pin 7 ' to 'pin
 9',press 'C' to
 press injection 9
 down .




Press ' Sel' shift
 pin 9 to pin 4.
 press Pro-0' ,
 machine
 automatically
 moves injection
 gun 7 down
 to mold 1st
 '+' center,
 injection gun 9
 down to mold 3rd
 '+' center .



Press 'Sel' shift pin 4 to pin 7, press 'C', injection gun 7 goes up.

Press 'Sel' shift pin 7 to pin 9, press 'C' pin 9 goes up.

Video:



3. Production .

3.1 Adding material .



Syringe 1 stock white PVC	Supply PVC to injection gun 1	Used to inject small letters
syringe 2 stock white PVC	Supply PVC to injection gun 2	Used to inject big letters
syringe 3 stock green/black PVC	Supply PVC to injection gun 3 and gun 6	Used to inject stitching lines Restonic label base has two base color . when make black base , please add black pvc in syringe 3. If make green base , please add green pvc in syringe .
Syringe 4 stock white PVC	Supply PVC to injection gun 4	Used to inject small letters
syringe 5 stock white PVC	Supply PVC to injection gun 5	Used to inject big letters