

Wireless Wall Switch WTX4

1. Operational Voltage: 12V DC
2. Programming;
 - a) Use one button only for each receiver
 - b) Follow instructions on receiver for programming
3. Mounting
 - a) Use the template to mark the screw positions on the wall. Choose either the wall fixing holes or the hanging holes.
 - b) Drill holes in the positions marked on the wall and mount the wall switch with the screw and plugs provided.

