# VD2(WT)

# WiFi & RF

# WiFi & RF 3-Button CCT LED Dimmer

- WiFi & RF 2 channel constant voltage CCT LED controller.
- Tuya APP cloud control, support on/off, color temperature and brightness adjust, delay turn on/off light, timer run, scene edit function.
- Voice control, support for Amazon Alexa, Google Assistant, Tmall Genie and Xiaodu smart speakers.
- 3 button operation with on/off and CCT adjustment.
- $\bullet$  Match with RF 2.4G single zone or multiple zone CCT remote control optional.
- 4096 levels 0-100% dimming smoothly without any flash.




## C€ RoHS emc RED


## **Technical Parameters**

Input and Output		Dimming data		Safety and EMC	
Input voltage	5-24VDC	Input signal	Tuya APP + RF 2.4GHz + 3 button	EMC standard (EMC)	ETSI EN 301 489-1 V2.2.3
Output voltage	5-24VDC	Control distance	30m(Barrier-free space)		ETSI EN 301 489-17 V3.2.4
Output current	2CH,2A/CH	Dimming level	4096 (2^12) levels	Safety standard	EN 62368-1:2020+A11:2020
Output power	20W@5V 48W@12V 96W@24V	Dimming range	0-100%	Radio Equipment(RED)	ETSI EN 300 328 V2.2.2
		Dimming curve	Logarithmic	Certification	CE,EMC,RED
Environment		PWM Frequency	2KHz (default)	Package	
Operation temperature	Ta: -30°C ~ +55°C	Warranty	5 years	Size	L120 x W43 x H27mm
Case temperature (Max.)	Tc: +85°C	Protection	Over-heat, Short circuit	Gross weight	0.013kg

#### Dimension




# Wiring Diagram



Note: 1. Press and hold the 🔘 and 🛞 button for 2s, output LED flashes 3 times, the light on/off fade time will change between 3s and 0.5s.

2. Press and hold the (a), (c) and (b) button for 2s, output LED flashes multiple times, switch between "+, CW, WW" (flashes 1 times) and "+, WW CW" (flashes 2 times) output sequences, default is "+, CW, WW" order.



#### Note:

- 1. The above distance is measured in spacious (no obstacle) environment, please refer to the actual test distance before installation.
- 2. Please check if the WiFi router net in 2.4G band, the 5G band is not available, and do not hide your router network.
- 3. Please keep the distance between VD2(WT) devices and router close, and check the WiFi signals.
- 4. WiFi signal strength detection: open the main interface of social security, click 🗷 enter the device interface, click "check device network" for testing.

## **Button function**



: Turn on or off light.



: Short press to switch between 3 color temperatures (WW, NW and CW), long press 1-6s for continuous 256 levels color temperature adjustment.



: Brightness +/-, short press 10 levels, long press 1-6s for continuous 256 levels adjustment.

## Tuya APP network connection

Please download the corresponding tuya/smart life app according to your region.

Press and hold 0 and c button for 2s:

clear previous network connection, enter Smart config mode, the output LED will flash 10 times.

Press and hold  $(\circ)$  and  $(\circ)$  button for 5s:

Clear previous network connection, enter AP config mode, the output LED will flash 5 times. If smart config failed, please try AP config.



Smart life APP

Tuya Smart

Repeat power on and off for 5 consecutive times, also clear previous network connection, enter Smart config mode, the output LED will flash 10 times

If Tuya APP network connection succeed, the output LED will stop flash, and in Tuya APP, you can find CCTc device

# Tuya APP interface



#### CCT interface

Touch color circle to adjust the color temperature. Touch brightness slide to adjust brightness.



#### Scene interface

The 1-4 scene is static color. the inner color of these scene can be editable.





#### Music, Schedule, Timer

The music play can use smart phone music player or micro-phone as music signal input.

The Schedule key can add multiple timers to turn on or turn off light according to different time periods.

The Timer key can turn on or turn off light in the next 24 hours.

## Match Remote Control (optional)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use © and ® button

Match:

Long press © and ® button 2s, immediately press on/off key (single zone remote) or zone key (multiple zone remote) of the remote.

Delete

Press and hold © and ® button for 5s to delete all match,
The output LED blinks 5 times means all matched remotes were deleted.

## Use Power Restart

#### Match:


Switch off the power, then switch on power again, immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote. The output LED blinks 3 times means match is successful.

#### Delete:


Switch off the power, then switch on power again, immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote. The output LED blinks 5 times means all matched remotes were deleted.

# Dimming Curve

# Linear dual color tuning



# Dimming curve



## Packing List

