





| CYLINDER ASSEMBLY Page 1 of 12 |                     |                     |                     |                                      |      |
|--------------------------------|---------------------|---------------------|---------------------|--------------------------------------|------|
| RefNo.                         | Elsődleges cikkszám | Másodlagos cikkszám | Chinese Description | English Description                  | Q'ty |
| 1                              | B06170000800009     | 906161-006          | GB6170□□M8          | NUT M8                               |      |
| 2                              | 91138-I008-0000     | 102222-011          | □□□□□□□□ M8×35      | STUD M8×35                           |      |
| 3                              | 1572B-I008-0000     | 104310-011          | □□□□□               | VALVE STEM SEAL ASSY                 |      |
| 4                              | 81300-I006-0000     | 102250-014          | □□□ (D8TC)          | SPARK PLUG (D8TC)                    |      |
| 5                              | 90103-LA51-0001     | 102275-006          | □□□□□□□□            | SEAL RING, CYLINDER HEAD UPPER COVER |      |
|                                | 90103-LA51-0000     |                     |                     |                                      |      |
| 6                              | 11226-LA73-0000     | 102271-032          | □□□□□               | CYLINDER HEAD UPPER COVER            |      |
|                                | 11226-LA73-0000A    |                     |                     |                                      |      |
| 7                              | B05789000600287     | 116101-019          | □□ M6×28            | BOLT M6×28                           |      |
| 8                              | B05789000600127     | 116101-020          | □□ M6×12            | BOLT M6×12                           |      |
| 9                              | 93301-70651512000   | 906150-043          | □□□6.5×1.5×12       | WASHER 6.5×1.5×12                    |      |
| 10                             | 1122B-LA73-0001-S11 | 102240-297          | □□□□□               | CYLINDER HEAD ASSY                   |      |
| 11                             | 90101-20335000300   | 118113-011          | O□□□□ 33.5×3        | O-RING 33.5×3                        |      |
| 12                             | 15800-L044-0041     | 100004-015          | □□□□□ (JQ-41)       | PIPE COMP,INTAKE (JQ-41)             |      |
| 13                             | B06170000600009     | 115100-008          | GB6170□□M6          | NUT M6                               |      |
| 14                             | B0578300060020700   | 102217-007          | □□ M6×20            | BOLT M6×20                           |      |
| 15                             | 161000-006          | 161000-008          | □□□□□               | CARBURETOR ASSY                      |      |
| 16                             | 91104-LA51-0000     | 102230-039          | □□□□□□□□ M8×82      | BOLT M8×82                           |      |
| 17                             | 93301-80852218000   | 906184-009          | □□□ 8.5×2.2×18      | WASHER 8.5×2.2×18                    |      |
| 18                             | 9022K-LA73-0000     | 102294-003          | □□□□□□□□            | GASKET ASSY,CYLINDER HEAD            |      |
| 19                             | 91521-10002000000   | 102217-013          | □□□ 10×20           | DOWEL PIN 10×20                      |      |
| 20                             | 90101-20100000160   | 102120-054          | O□□□□ 10×1.6        | O-RING 10×1.6                        |      |
| 21                             | 1110B-LA73-0000-S11 | 102120-054          | □□□□□               | CYLINDER BLOCK COMP                  |      |
| 22                             | 90205-LA73-0001     | 102108-027          | □□□□□□              | GASKET,CYLINDER BLOCK                |      |




www.seacubemoto.com

配气机构  
VALVE MECHANISM

## VALVE MECHANISM


Page 2 of 12

| RefNo. | Elsődleges cikkszám                         | Másodlagos cikkszám | Chinese Description | English Description              | Q'ty |
|--------|---------------------------------------------|---------------------|---------------------|----------------------------------|------|
| 1      | 15701-LA66-0000V-S11<br>15701-LA66-0000-S11 | 104301-022          |                     | INLET VALVE                      |      |
| 2      | 15701-LA66-0000V-S11<br>15701-LA66-0000-S11 | 104302-022          |                     | OUTLET VALVE                     |      |
| 3      | 15706-I008-0000                             | 104306-009          |                     | SPRING SEAT VALVE                |      |
| 4      | 15708-I008-0000                             | 104305-005          |                     | INNER SPRING SEAT, VALVE         |      |
| 5      | 15703-I008-0000                             | 104304-013          |                     | OUTER SPRING                     |      |
| 6      | 15704-I008-0000                             | 104303-013          |                     | INNER SPRING                     |      |
| 7      | 15705-I006-0000                             | 104307-011          |                     | RETAINER, VALVE SPRING           |      |
| 8      | 15707-I006-0000                             | 104308-011          |                     | VALVE COTTER                     |      |
| 9      | 15403-I008-0000                             | 104416-007          |                     | ADJUSTING NUT, VALVE CLEARANCE   |      |
| 10     | 15404-I008-0000                             | 104415-007          |                     | ADJUSTING SCREW, VALVE CLEARANCE |      |
| 11     | 93301-80852218000                           | 102219-008          | 8.5×2.2×18          | WASHER 8.5×2.2×18                |      |
| 12     | 91180-IA20-0000                             | 104406-003          | M8×33               | BOLT M8×33                       |      |
| 13     | 1540A-IA20-0000<br>1540A-IA20-0000A         | 104410-011          |                     | ARM ROCKER ASSY                  |      |
| 14     | 15501-LA73-0000                             | 104105-002          |                     | PUSH LEVER STAND                 |      |
| 15     | 1532A-LA66-0200<br>1532A-LA66-0200A         | 104120-008          | CG200-A-3#          | PUSH LEVER COMP                  |      |
| 16     | 93303-51230220900                           | 104404-004          | 12.3×0.2×20.9       | WAVE WASHER 12.3×0.2×20.9        |      |
| 17     | 15407-I008-0000                             | 104401-002          |                     | LOWER ROCKER ARM                 |      |
| 18     | 15408-I008-0000                             | 104402-002          |                     | SHAFT, LOWER ROCKER ARM          |      |
| 19     | 90101-20180000250                           | 104403-004          | O 18×2.5            | O-RING 18×2.5                    |      |
| 20     | 15109-I008-0000                             | 104405-003          |                     | SPRING                           |      |
| 21     | 90101-20200000250                           | 104107-004          | O 20×2.5            | O-RING 20×2.5                    |      |
| 22     | 15105-J034-0000                             | 104106-002          |                     | AIR MLET CAM SHAFT               |      |
| 23     | 93301-51421024000                           | 116109-013          | 14.2×1×24           | THRUST WASHER 14.2×1×24          |      |
| 24     | 1510A-I008-0000                             | 104130-044          |                     | TIMING DRIVEN SPROCKET COMP      |      |




[www.seacubemoto.com](http://www.seacubemoto.com)

| CB CRANKCASE COVER Page 3 of 12 |                     |                     |                            |                                   |      |
|---------------------------------|---------------------|---------------------|----------------------------|-----------------------------------|------|
| RefNo.                          | Elsődleges cikkszám | Másodlagos cikkszám | Chinese Description        | English Description               | Q'ty |
| 1                               | B166740A0600407     | 115100-032          | □□□□ M6×40                 | BOLT M6×40                        |      |
| 2                               | B166740A0600167     | 115100-033          | □□□□ M6×16                 | BOLT M6×16                        |      |
| 3                               | B166740A0600507     | 115100-034          | □□□□ M6×50                 | BOLT M6×50                        |      |
| 4                               | B166740A0600257     | 115100-035          | □□□□ M6×25                 | BOLT M6×25                        |      |
| 5                               | 19001-1A20-0003     | 101411-004          | □□□□                       | WATER PUMP COVER                  |      |
| 6                               | 90101-30085000190   | 101432-001          | O□□□□ 8.5×1.9              | O-RING 8.5×1.9                    |      |
| 7                               | 91132-1A20-0000     | 101433-001          | □□□□□□ M8×10               | BOLT M8×10                        |      |
| 8                               | 91521-08001200063   | 906184-010          | □□□8×12×6.3                | DOWEL PIN 8×12                    |      |
| 9                               | 90101-30630000265   | 101412-007          | O□□□□63×2.65(□□)           | O-RING 65×2.65                    |      |
| 10                              | 90101-20087000190   | 100017-001          | CB125□□□□O□□□□8.7×1.9(□□□) | O-RING8.7×1.9                     |      |
| 11                              | 2242A-1006-0300     | 106320-013          | CB125-3□□□□□□□□            | CLUTCH LEVER ASSY                 |      |
| 12                              | 22427-1006-0000     | 106325-006          | CB125□□□□□□□□              | CLUTCH LEVER SPRING3*12           |      |
| 13                              | B0087901030120000   | 106301-008          | GB879.1□ 3×12              | POSITION PIN                      |      |
| 14                              | 12421-1A20-0301     | 106312-005          | SB125□□□□□-3# □□□□□        | R.CRANKCASE COVER ASSY            |      |
| 15                              | 14301-1006-0000     | 101401-285          | □□□□□                      | OIL RULER ASSY                    |      |
|                                 | 14301-1006-0000A    |                     |                            |                                   |      |
| 16                              | 90101-10180000300   | 100016-001          | O□□□□ 18×3                 | O-RING 18×3                       |      |
| 17                              | 91521-08001400000   | 101442-007          | □□□ 8×14                   | DOWEL PIN 8×14                    |      |
| 18                              | 90206-1008-0000     | 906184-011          | □□□□□□□□                   | GASKET,R.CRANKCASE COVER          |      |
| 19                              | B166740A0600207     | 101403-022          | □□□□ M6×20                 | BOLT M6×20                        |      |
| 20                              | B166740A0600287     | 115100-036          | □□□□ M6×28                 | BOLT M6×28                        |      |
| 21                              | B00818000600122     | 115100-037          | □□ M6×12                   | SCREW M6×12                       |      |
|                                 | 12301-1008-0000     | 115100-038          | □□□□□□(□□□)                | L.CRANKCASE COVER                 |      |
| 22                              | 12301-1008-0000A    |                     |                            |                                   |      |
|                                 | 12301-1008-0000B    |                     |                            |                                   |      |
| 23                              | 92102-1008-0001     | 101301-224          | CG125D□□□□(□□)             | NEEDLE BEARING (HK101410)         |      |
| 24                              | 90204-1008-0000     | 212211-010          | □□□□□□□□                   | GASKET□L.CRANKCASE COVER          |      |
| 25                              | 12303-G011-0000     | 101304-017          | □□□□                       | CAP, SMALL SIGHT HOLE             |      |
| 26                              | 90101-10132000265   | 101307-011          | O□□□□ 13.2×2.65            | O-RING 13.2×2.65                  |      |
| 27                              | 91521-10001400000   | 101313-005          | □□□ 10×14                  | DOWEL PIN 10×14                   |      |
| 28                              | B166740A0600257     | 116108-010          | □□□□ M6×25                 | BOLT M6×25                        |      |
|                                 | 12302-1008-1000     | 115100-035          | □□□□□□(□□□)                | BACK COVER,L.CRANKCASE            |      |
| 29                              | 12302-1008-1000A    |                     |                            |                                   |      |
|                                 | 100018-001          |                     |                            |                                   |      |
| 30                              | 90101-10274000265   | 100003-017          | O□□□□ 27.4×2.65            | O-RING 27.4×2.65                  |      |
| 31                              | 12307-1008-1000     | 101312-005          | □□□□□□□□□(□□□)             | DECORATE COVER ,L.CRANKCASE COVER |      |
|                                 | 12307-1008-1000B    |                     |                            |                                   |      |
| 32                              | 90101-10620000300   | 100018-001          | O□□□□ 62×3                 | O-RING 62×3                       |      |
| 33                              | 12308-1008-1000     | 101314-003          | □□□□□(□□□)                 | COVER,REDUCTION GEAR              |      |



[www.seacubemoto.com](http://www.seacubemoto.com)


| ( CB CLUTCH Page 4 of 12 |                     |                     |                     |                        |      |
|--------------------------|---------------------|---------------------|---------------------|------------------------|------|
| RefNo.                   | Elsődleges cikkszám | Másodlagos cikkszám | Chinese Description | English Description    | Q'ty |
| 1                        | 22000-LA73-0100-S11 | 106000-057          | CG200-A□□-2#□□□□□   | CLUTCH COMP            |      |
| 2                        | komplett            | 106114-009          | □□□□□               | PUSH ROD,CLUTCH        |      |
| 3                        | komplett            | 116101-021          | □□□□□M5×20(□□)      | BOLT M6×25             |      |
| 4                        | komplett            | 116210-026          | □□ (16003)          | BEARING (6001)         |      |
| 5                        | komplett            | 106108-004          | □□□□□□□             | END COVER,CLUTCH       |      |
| 6                        | komplett            | 106247-010          | □□□□□               | SPRING,CLUTCH          |      |
| 7                        | komplett            | 106206-003          | □□□□□ 20            | CIRCLIP 20             |      |
| 8                        | komplett            | 106240-005          | □□□□□□              | CENTRAL SLEEVE.,CLUTCH |      |
| 9                        | komplett            | 106243-011          | □□□□□□□□            | FRICTION PLATE ASSY    |      |
| 10                       | komplett            | 106244-010          | □□□□□□□□            | FRICTION PLATE ASSY    |      |
| 11                       | komplett            | 106249-003          | □□□□□               | CLUTCH PRESSING PLATE  |      |
| 12                       | komplett            | 106103-006          | □□□□□□□             | SPLINE WASHER          |      |
| 13                       | komplett            | 106260-005          | □□□□□□□             | CLUTCH OUTER CASE COMP |      |



# OIL PUMP Page 5 of 12

| RefNo. | Elsődleges cikkszám | Másodlagos cikkszám | Chinese Description | English Description      | Q'ty |
|--------|---------------------|---------------------|---------------------|--------------------------|------|
| 1      | 14200-1A20-0000     | 105200-009          | 机油泵总成               | OIL FILTER COMP          |      |
| 2      | komplett            | 105202-003          | 机油管                 | EX-TUBE,OIL              |      |
| 3      | komplett            | 115200-019          | GB819.1 M5×12(平)    | SCREW M5×12              |      |
| 4      | komplett            | 105203-003          | 机油管弹簧               | SPRING,EX TUBE           |      |
| 5      | komplett            | 105201-005          | 机油管盖                | COVER,OIL FILTER         |      |
| 6      | komplett            | 105205-004          | 机油管销                | COTTER PIN,OIL FILTER    |      |
| 7      | komplett            | 105204-001          | 机油管盖垫圈              | GASKET,FILTER HEAD COVER |      |
| 8      | komplett            | 105221-001          | 机油管体                | OIL FILTER BODY          |      |
| 9      | 23101-1006-0000     | 106001-020          | 机油泵驱动齿轮             | DRIVE GEAR               |      |
| 10     | B00819010600302     | 115200-020          | 机油泵 M6×30           | SCREW M6×30              |      |
| 11     | komplett            | 105115-001          | 机油泵驱动轴, 齿轮          | DRIVE SHAFT, GEAR        |      |
| 12     | komplett            | 105114-002          | 机油泵驱动齿轮             | DRIVE GEAR,OIL PUMP      |      |
| 13     | komplett            | 105116-001          | 机油泵壳体               | OIL PUMP CASING          |      |
| 14     | komplett            | 105113-002          | 机油泵外转子              | OUTER ROTOR,OIL PUMP     |      |
| 15     | komplett            | 105112-002          | 机油泵内转子              | INNER ROTOR,OIL PUMP     |      |
| 16     | komplett            | 105117-002          | 机油泵盖                | OIL PUMP COVER           |      |
| 17     | komplett            | 115200-021          | 机油泵 M4×12           | SCREW M4×12              |      |
| 18     | 90101-10094000240   | 105121-001          | O型圈 9.4×2.4         | O-RING 9.4×2.4           |      |
| 19     | 14100-LA73-0000     | 105110-032          | 机油泵总成               | OIL PUMP ASSY            |      |





[www.seacubemoto.com](http://www.seacubemoto.com)

曲轴箱


CRANKCASE

| CRANKCASE |                     |                     |                                 |                           |      |
|-----------|---------------------|---------------------|---------------------------------|---------------------------|------|
| RefNo.    | Elsődleges cikkszám | Másodlagos cikkszám | Chinese Description             | English Description       | Q'ty |
| 1         | B166740A0600657     | 115100-039          | □□□□ M6×65                      | BOLT M6×65                |      |
| 2         | 22422-I006-0001     | 101110-001          | CB125-2#□□□□□□                  | CLUTCH CABLE STAND        |      |
| 3         | 91212-I008-0000     | 102218-011          | □□ M8×32                        | NUT M8×32                 |      |
| 4         | 93301-C125202200B   | 102219-005          | □□□ 12.5×2×22                   | WASHER 12.5×2×22          |      |
| 5         | 91101-LA66-0200A    | 101104-016          | CG200-A-3#□□□□□A(□□20mm □□6.3)  | STUD A                    |      |
|           | 91101-LA66-0200     | 101104-016          | CG200-A-4#□□□□□A(□□22mm □□7.5)  |                           |      |
| 6         | 91101-LA66-0300     | 116101-019          | □□ M6×28                        | BOLT M6×28                |      |
| 7         | B05789000600287     | 101201-005          | □□□□□                           | BREATHER TUBE             |      |
| 8         | 12109-I006-0000     | 101210-001          | CG125D-1#□□□□□                  | CLIP BREATH TURE          |      |
| 9         | 12130-I008-0000     | 101203-009          | CG125D□□□□□□□                   | BREATHER TUBE             |      |
| 10        | 12105-I008-0000     | 101202-013          | □□□                             | BREATHER TUBE             |      |
|           | 18097-I008-0000     |                     |                                 |                           |      |
| 11        | 91521-10001400000   | 116108-010          | □□□ 10×14                       | DOWEL PIN 10×14           |      |
| 12        | 92102-000NK152312   | 212211-011          | □□□□ (NK152312)                 | NEEDLE BEARING (NK152312) |      |
| 13        | 92102-00000006006   | 902012-041          | □□ (6006)                       | BEARING (6006)            |      |
| 14        | 1222B-JZ02-0000-S11 | 101220-100          | □□□□□□                          | R.CRANKCASE ASSY          |      |
| 15        | 90303-I006-0000     | 101144-001          | □□□□ 20×34×7                    | OIL SEAL 20×34×7          |      |
| 16        | 92102-00000006204   | 116210-027          | □□ (6204)                       | BEARING (6204)            |      |
| 17        | 91102-LA66-0200A    | 101103-018          | CG200-A-3#□□□□□□B(□□22mm □□7.5) | STUDB                     |      |
|           | 91102-LA66-0200     |                     |                                 |                           |      |
| 18        | 90208-LA73-0001     | 101101-020          | □□□□□□                          | GASKET,CRANKCASE          |      |
|           | 90208-LA73-0001     |                     |                                 |                           |      |
| 19        | 1212B-JZ02-0000-S11 | 101140-268          | □□□□□□                          | L.CRANKCASE ASSY          |      |
| 20        | 92102-00000HK2110   | 212211-012          | □□□□ (HK2110)                   | NEEDLE BEARING (HK2110)   |      |
| 21        | 92102-0000006202Z   | 116210-028          | □□ (6202Z)                      | BEARING (6202Z)           |      |
| 22        | 12102-I008-0000     | 101145-001          | □□□□□                           | GEAR LOCATING PLATE       |      |
| 23        | B05783000600127     | 116101-020          | □□ M6×12                        | BOLT M6×12                |      |
| 24        | 90302-I008-0000     | 101160-005          | □□□□ 34×50×7                    | OIL SEAL 34×50×7          |      |
| 25        | 93301-71251520000   | 116109-014          | □□□ 12.5×1.5×20                 | WASHER 12.5×1.5×20        |      |
| 26        | 91103-D002-0000     | 101119-005          | □□□□ M12×1.5                    | DRAIN PLUG M12×1.5        |      |
| 27        | 1213B-I008-0000     | 101150-002          | □□□□□                           | PRESSING PIN ASSY         |      |
| 28        | 93301-60671014400   | 101155-001          | □□□□ 6.7×1×14.4                 | THRUST WASHER 6.7×1×14.4  |      |
| 29        | B05783000600257     | 906103-049          | □□ M6×25                        | BOLT M6×25                |      |
| 30        | 90301-I006-0000     | 108240-007          | □□□□□ 14×28×7                   | OIL SEAL 14×28×7          |      |
| 31        | 1431B-I006-0000     | 101130-006          | □□□□□□□                         | OIL MESH SCREEN COMP      |      |
| 32        | 14221-I006-0000     | 101116-009          | □□□□□□□                         | SPRING,OIL MESH SCREEN    |      |



|    |                 |            |                         |                          |  |
|----|-----------------|------------|-------------------------|--------------------------|--|
|    | 101-20350000300 | 101118-005 | O□□□□ 35×3              | O-RING 35×3              |  |
|    | 230-I006-0000   | 101117-009 | □□□□                    | VALVE COVER              |  |
|    | 102-I008-0001   | 101147-001 | CG125D□□□□(□□)          | NEEDLE BEARING           |  |
|    | 103-I008-0000   | 101115-005 | □□□                     | PLATE                    |  |
| 37 | B166740A0600127 | 115200-022 | □□□□ M6×12              | BOLT M6×12               |  |
| 38 | 15108-I008-0000 | 101146-001 | □□□□□                   | POSITION PLATE □CAMSHAFT |  |
| 39 | B166740A0600507 | 115100-034 | □□□□ M6×50              | BOLT M6×50               |  |
| 40 | B166740A0601007 | 115100-040 | □□□□ M6×100             | BOLT M6×100              |  |
| 41 | B166740A0600707 | 115100-041 | □□□□ M6×70              | BOLT M6×70               |  |
| 42 | B166740A0600607 | 115100-042 | □□□□ M6×60              | BOLT M6×60               |  |
|    |                 | LY250□□□□□ | SEPARATOR, FUEL AND AIR |                          |  |


[www.seacubemoto.com](http://www.seacubemoto.com)




曲轴 / 活塞 / 连杆部件  
 CRANKSHAFT/PISTON/CONNECTING ROD COMP

| / / CRANKSHAFT/PISTON/CONNECTING ROD COMP Page 7 of 12 |                     |            |                     |                                |      |
|--------------------------------------------------------|---------------------|------------|---------------------|--------------------------------|------|
| RefNo.                                                 |                     | Part No.   | Chinese Description | English Description            | Q'ty |
| 1                                                      | 1320B-LA73-0000-S11 | 103240-001 | 曲轴连杆总成              | CRANKSHAFT CONNECTING ROD ASSY |      |
| 2                                                      | 91106-I008-0000     | 103209-004 | 螺栓 M10×36           | BLOT M10×36                    |      |
| 3                                                      | komplett            | 103223-007 | 曲轴正时齿轮              | CRANKSHAFT TIMING GEAR         |      |
| 4                                                      | komplett            | 902012-042 | 轴承 (63/28-RS/P5)    | BEARING (63/28/P5/Z)           |      |
| 5                                                      | komplett            | 103203-009 | 半圆键 25×14×4         | SEMICIRCLE KEY 25×14×4         |      |
| 6                                                      | komplett            | 103240-001 | 连杆总成 3              | CONNECTING ROD COMP 3          |      |
| 7                                                      | komplett            | 902012-043 | 轴承 (63/28/P5)       | BEARING (63/28/P5)             |      |
| 8                                                      | 22004-I006-0000     | 103213-002 | 碟形垫圈                | DISH WASHER                    |      |
| 9                                                      | 91203-I008-0000     | 103237-001 | 螺母, 机油滤             | NUT, OIL FILTER                |      |
| 10                                                     | 13103-LA66-0100     | 103104-032 | CG200-A 活塞环 1       | PISTON RING 1                  |      |
| 11                                                     | 13104-LA66-0100     | 103105-030 | CG200-A 活塞环 2       | PISTON RING 2                  |      |
| 12                                                     | 13120-LA66-0000     | 103110-003 | 油环总成                | OIL RING ASSY                  |      |
| 13                                                     | 1310A-LA66-0300-S11 | 103120-033 | CG200-A 活塞环总成       | PISTON RING COMP               |      |
| 14                                                     | 91401-I006-0000     | 103103-015 | 卡簧, 活塞销             | CLIPCLIP, PISTON PIN           |      |
| 15                                                     | 13102-LA66-0000     | 103102-019 | 活塞销                 | PISTON PIN                     |      |
| 16                                                     | 13101-LA66-0200-S11 | 103101-040 | CG200-A 活塞          | PISTON                         |      |






| TRANSMISSION MECHANISM Page 8 of 12 |                                     |            |                     |                                  |      |
|-------------------------------------|-------------------------------------|------------|---------------------|----------------------------------|------|
| RefNo.                              |                                     | Part No.   | Chinese Description | English Description              | Q'ty |
| 1                                   | 23220-MZ01-0000-S11                 | 107100-047 | □□□□                | MAIN SHAFT ASSY                  |      |
| 2                                   | komplett                            | 107114-006 | □□□□ 15.2×1×25      | THRUST WASHER 15.2×1×25          |      |
| 3                                   | komplett                            | 107105-007 | □□2□□□              | MAINSHAFT 2ND SPEED GEAR         |      |
| 4                                   | komplett                            | 107330-005 | □□4□□□              | MAINSHAFT 4ND SPEED GEAR         |      |
| 5                                   | komplett                            | 107112-003 | □□□□                | SPACER WASHER                    |      |
| 6                                   | komplett                            | 107330-005 | □□φ18.5×1.2×φ22.1   | INNER CIRCLIP φ18.5×1.2×φ22.1    |      |
| 7                                   | komplett                            | 107118-001 | □□□□                | REVERSE GEAR,COUNTERSHAFT        |      |
| 8                                   | komplett                            | 107105-007 | □□3□□□              | MAINSHAFT 3TH SPEED GEAR         |      |
| 9                                   | komplett                            | 107105-007 | □□□□                | PIVOT, MAINSHAFT                 |      |
| 10                                  | komplett                            | 107114-007 | □□□□ 20×0.5×27      | THRUST WASHER 20×0.5×27          |      |
| 11                                  | komplett                            | 107120-001 | □□□□CG150D□□□□□□□□  | ASSEMBLY, STARTING GEAR          |      |
| 12                                  | 23240-MZ01-0000-S11                 | 10720-054  | □□□□                | ASSEMBLY, COUNTERSHAFT           |      |
| 13                                  | B0578300060010700                   | 106101-022 | □□ M6×10            | BOLT M6×10                       |      |
| 14                                  | 23402-I006-0000                     | 107222-005 | □□□□□□□□            | FIXING PLATE, DRIVE SPROCKET     |      |
| 15                                  | 23401-I008-0000                     | 107221-020 | □□□□                | DRIVE SPROCKET                   |      |
| 16                                  | komplett                            | 107114-007 | □□□□□□ 15.2×1×30    | THRUST WASHER 20×1×27            |      |
| 17                                  | komplett                            | 107208-007 | □□2□□□              | COUNTERSHAFT 2ND SPEED GEAR      |      |
| 18                                  | komplett                            | 116109-015 | □□4□□□              | 4ND SPEED GEAR                   |      |
| 19                                  | komplett                            | 107201-037 | □□□□                | PIVOT, COUNTERSHAFT              |      |
| 20                                  | komplett                            | 107211-007 | □□□□                | REVERSE GEAR,COUNTERSHAFT        |      |
| 21                                  | komplett                            | 107209-007 | □□3□□□              | COUNTERSHAFT 3RD SPEED GEAR      |      |
| 22                                  | komplett                            | 107202-007 | □□□□ 16.5×0.5×24    | THRUST WASHER 16.5×0.5×24        |      |
| 23                                  | komplett                            | 107207-002 | □□1□□□□□            | COUNTERSHAFT 4TH SPEED GEAR      |      |
| 24                                  | komplett                            | 107206-005 | □□□□CG250□□□□□1□□□  | SPACER WASHER                    |      |
| 25                                  | komplett                            | 107202-016 | □□□□ 16.5×0.5×24    | BUSH,COUNTERSHAFT 1ST SPEED GEAR |      |
| 26                                  | komplett                            | 107218-002 | □□□□CG150D□□□□□□□□  | COUNTERSHAFT 1ST SPEED GEAR      |      |
| 27                                  | 2360B-MZ01-0000A<br>2360B-MZ01-0000 | 107202-017 | □□□□□□□□            | GEAR,REOULTION ASSEMBLY          |      |
| 28                                  | 23608-JZ02-0000-S11                 | 107341-002 | □□□□                | SHAFT,REDUCTION GEAR             |      |
| 29                                  | komplett                            | 212211-013 | □□□□                | NEEDLE BEARING                   |      |
| 30                                  | komplett                            | 107342-001 | □□□□□□              | GEAR,REOULTION                   |      |
| 31                                  | komplett                            | 107337-002 | □□□□□ 12×1×18       | SHAFT,REDUCTION O-PING           |      |
| 32                                  | 23601-MZ01-0000A<br>23601-MZ01-0000 | 107340-006 | □□□□□□□□            | ASSEMBLY IDLE GEAR CONP          |      |
| 33                                  | komplett                            | 107337-001 | □□φ18.5×1.2×φ22.1   | THRUST WASHER φ18.5×1.2×φ22.1    |      |
| 34                                  | komplett                            | 107334-002 | □□                  | IDLE GEAR CONP                   |      |
| 35                                  | 23602-JZ02-0000-S11                 | 107332-003 | □□□□                | IDLE GEAR CONP STARTEAR          |      |
| 36                                  | komplett                            | 107334-001 | □□□□                | COUNTERSHAFT 1ST SPEED           |      |
| 37                                  | komplett                            | 107335-002 | □□□□                | LOCK UP PLY                      |      |
| 38                                  | komplett                            | 107114-007 | □□□□20.2×0.5×27     | THRUST WASHER 20.2×0.5×27        |      |
| 39                                  | komplett                            | 116109-015 | □□                  | WASHER                           |      |




## GEARSHIFT MECHANISM Page 9 of 12

| RefNo. |                                     | Part No.   | Chinese Description     | English Description             | Q'ty |
|--------|-------------------------------------|------------|-------------------------|---------------------------------|------|
| 1      | 24300-LA73-0100<br>24300-LA73-0100A | 108200-019 | □□□□□                   | ASSEMBLY, GEARSHIFT LEVER       |      |
| 2      | B0089401120000000                   | 108207-001 | □□ 12                   | CIRCLIP 12                      |      |
| 3      | 24303-I006-0000                     | 108202-000 | □□□□□□□□□□□□            | SPRING, GEARSHIFT LEVER         |      |
| 4      | 24319-I008-0000                     | 108203-000 | □□□□□□□□□□              | LEVEL, GEARSHIFT                |      |
| 5      | 24301-LA73-0000                     | 108220-000 | CG200-A□□□□□□□□□□□□     | GEARSHIFT SHAFT                 |      |
| 6      | 24302-I008-0000                     | 108204-002 | □□□□□□                  | RETURN SPRING, GEARSHIFT LEVER  |      |
| 7      | 93301-51400520000                   | 108208-000 | □□□□□ 14×0.5×20 □□□□□□□ | WASHER 14×0.5×20                |      |
| 8      | B0089401140000000                   | 108207-001 | □□ 14                   | CIRCLIP 14                      |      |
| 9      | 24400-I008-0016                     | 108300-040 | □□□□ (BT-16)            | PEDAL, GEARSHIFT (BT-16)        |      |
| 10     | 24107-I006-0000                     | 108126-001 | □□□                     | SHAFT, FORK                     |      |
| 11     | 24104-I006-0000                     | 108123-005 | □□□□□                   | RIGHT FORK, COUNTERSHAFT        |      |
| 12     | 24106-I006-0000                     | 108122-003 | □□□□                    | CENTER FORK, MAINSHAFT          |      |
| 13     | 24105-JZ02-0000                     | 108121-004 | □□□□□□□□□□              | LEFT FORK, COUNTERSHAFT         |      |
| 14     | B05783000600257                     | 116102-001 | □□ M6×25                | BOLT M6×25                      |      |
| 15     | B00093000600000                     | 113212-001 | □□ 6                    | WASHER 6                        |      |
| 16     | 24202-I008-0600                     | 108114-007 | □□□                     | STOPPING PLATE                  |      |
| 17     | B0011901040100000                   | 108116-004 | □□ 4×10                 | PIN 4×10                        |      |
| 18     | 24213-JZ02-0000                     | 108111-006 | □□□                     | GEARSHIFT DRUM                  |      |
| 19     | 88004-JZ02-0000                     | 108113-000 | □□□□□ □□□□□□□□          | CONTACT□GEARINDICATION          |      |
| 20     | 88031-JZ02-0000                     | 113200-053 | □□□□□□                  | CABLE ASSEMBLY, GEAR INDICATION |      |
| 21     | 9115B-JZ02-0000                     | 116105-003 | □□□□□□□M4×18            | BOLTM4×18                       |      |
| 22     | 91115-I008-00000B                   | 116102-048 | □□□□□□□M6×20(□□2.5mm)   | BOLTM6×20                       |      |
| 23     | 2434A-I008-0100                     | 108130-007 | □□□□□                   | LOCATING PLATE UNIT             |      |
| 24     | 24304-I006-0000                     | 108101-001 | □□□□□                   | RETURN SPRING, LOCATING PLATE   |      |



## MAGNETO COMP Page 10 of 12


| RefNo. | Part No.        | Chinese Description | English Description | Q'ty |
|--------|-----------------|---------------------|---------------------|------|
| 1      | 82100-I008-0000 | 111000-039          | MAGNETO             |      |
| 2      | 82130-I008-0000 | 111000-027          | ROTOR ASSY,MAGNETO  |      |
| 3      | 82120-I008-0100 | 111200-110          | STATOR ASSY,MAGNETO |      |
| 4      | B00823000500162 | 115200-023          | SCREW M5×16         |      |
| 5      | B05783000500257 | 115200-024          | BOLT M5×25          |      |



电启动机构  
ELECTRIC STARTING MECHANISM

## ELECTRIC STARTING MECHANISM Page 11 of 12

| Ref No. | Part No.          | Chinese Description | English Description  | Q'ty |
|---------|-------------------|---------------------|----------------------|------|
| 1       | 82200-LA73-2000A  | 112000-110          | STARTING MOTOR ASSY  |      |
|         | 82200-LA73-2000   |                     |                      |      |
| 2       | 21402-I008-0100   | 109211-006          | GEARSHAFT,CONNECTED  |      |
| 3       | 91522-03000600000 | 109222-001          | LOCATING PIN 3×6     |      |
| 4       | 93301-51050518000 | 116109-016          | WASHER 10.5×0.5×18   |      |
| 5       | 2140A-I008-0103   | 109231-006          | GEAR,CONNECTED,1     |      |
|         | 2140A-I008-0103-B |                     |                      |      |
|         | 2140A-I008-0103-C |                     |                      |      |
| 6       | 21401-I008-1100   | 109203-004          | GEAR,CONNECTED,2     |      |
|         | 21401-I008-1100-B |                     |                      |      |
|         | 21401-I008-1100-C |                     |                      |      |
| 7       | B0070010800187    | 115200-025          | SCREW M8×18          |      |
| 8       | 21300-LA73-0000   | 109110-008          | STARTER CLUTCH COMP. |      |
| 9       | 21422-LA73-0000   | 109211-004          | STARTER GEAR         |      |
|         | 21422-LA73-0000A  |                     |                      |      |



WATER COOLING SYSTEM

WATER COOLING SYSTEM Page 12 of 12

| RefNo. |                   | Part No.   | Chinese Description    | English Description                        | Q'ty |
|--------|-------------------|------------|------------------------|--------------------------------------------|------|
| 1      | 19520-IA20-0000   | 114001-002 | □□□□(13-23mm)          | WATER PIPE COLLAR CLAMP ASSY               |      |
| 2      | 19225-IA20-0006   | 114203-003 | □□□□□□ (13×20×300 □□□) | TUBE (13×20×300)                           |      |
| 3      | 19225-IA20-0002   | 114020-001 | □□□□□1 (13×20×225 □□□) | TUBE (13×20×225)                           |      |
| 4      | 1910B-IA20-0000   | 114050-003 | □□□□                   | COOLING FAN ASSY                           |      |
| 5      | B166740A0600207   | 116101-003 | □□□□ M6×20             | BOLT M6×20                                 |      |
| 6      | 19200-IA20-0000   | 114220-002 | □□□□                   | WATER COOLER                               |      |
| 7      | 1925A-IA20-0000   |            | □□□□                   | already cancelled                          |      |
| 8      | 91404-IA20-0000   | 114001-000 | □□□□                   | CLIP , WATER PIPE                          |      |
| 9      | 19207-IA20-0002   | 114204-001 | □□□□□□ (3.5×7×850)     | SMALL CIRCULATING FEEDING PIPE (3.5×7×850) |      |
| 10     | 19225-IA20-0008   | 114202-004 | □□□□□□ (13×20×400 □□□) | TUBE (13×20×400)                           |      |
| 11     | 19002-IA20-0000   | 114321-001 | □□□□                   | VANE WHEEL WATER PUMP                      |      |
| 12     | 19003-IA20-0000   | 101414-001 | □□□□                   | GASKET, VANE WHEEL WATER PUMP              |      |
| 13     | 1901B-IA20-0000   | 101413-001 | □□□□□                  | MECHANISM SEAL ASSY                        |      |
| 14     | 90326-I024-0000   | 114340-001 | □□□□□ 12×20×5          | OIL SEAL 12×20×5                           |      |
| 15     | 92102-00000006901 | 116210-028 | □□ (6901)              | BEARING (6901)                             |      |
| 16     | 19004-IA20-0000   | 114322-001 | □□□                    | SHAFT , WATER PUMP                         |      |
| 17     | 92102-00000006000 | 116210-001 | □□ (6000)              | BEARING (6000)                             |      |
| 18     | 1921B-IA20-0000   | 114501-008 | □□□□□(□□)              | CASE , THERMOSTAT                          |      |
| 19     | B166740A0600167   | 116101-043 | □□□□ M6×16             | BOLT M6×16                                 |      |
| 20     | 19206-I024-0000   |            | □□□□                   | already cancelled                          |      |
| 21     | 90101-30148000190 | 114502-002 | O□□□□ 14×2             | O-RING 14×2                                |      |
| 22     | 1920A-I024-0000   | 114510-001 | □□□                    | THERMOSTAT ASSY,COOLING                    |      |
| 23     | 19220-IA20-0000   | 114503-008 | □□□□                   | THERMOSTAT COVER                           |      |