





FRAME ASSEMBLY (1)

FRAME ASSEMBLY

S/N	PART NO.			DESCRIPTION	QUANTITY
1	540300-022			REAR SHOCK ABSORBER	1
2	309100-001			GUARD	1
3	511000-428			FRAME ASSY	1
4	906104-050			HEXANGULAR BOLT M10M10x1.25x115	2
5	507100-017			F/L SWING ARM	1
6	904216-005			FRAME PLUG	2
7	906104-015			HEXANGULAR BOLT M8>M8x16	2
8	510300-045			FRONT SHOCK ABSORBER	2
9	906162-002			LOCK NUT, HEXHEXMIGULARANGE M10M10x<1.25	6
10	906104-041			HEXANGULAR BOLT M10M10x1.25x45	6
11	536001-002			SUPPORT FOOTEST	1
12	507200-017			F/R SWING ARM	1
13	809006-003			SUPPORT BODY COVER	1


www.seacubemoto.com



ENGINE&WIRING ASSEMBLY (2)

ENGINE & WIRING ASSEMBLY

S/N	PART NO.			DESCRIPTION	QUANTITY
1	307000-235			MAIN CABLE COMP	1
2	171000-052			AIR FILTER	1
3	906103-002			BOLT M6 X 25	2
4	161000-014			CARBURETOR ASSY	1
5	100005-003			PLUMBAG 0 CUSHION	1
6	100013-001			PLASTIC GASKET, LNLET TUPE	1
7	100014-001			RING, INLET TUPE	1
8	100004-002			INLET TUBE	1
9	906103-003			BOLT M6 X 20	2
10	162002-028			WATER TUBE (6 4*(1) 8*180mm	1
11	162002-043			WATER TUBE (6 4*(1) 8*130mm	1
12	162002-091			WATER TUBE (b 4*(1) 8*220mm	1
13	162002-023			WATER TUBE d) 9*(b 13*230-30mm	1
14	162002-048			WATER TUBE (1) 9*(1) 13*230-30mm	1
15	162004-015			LEADING PIPE, INLET	1
16	110000-301			MOTOR ASSY	1
17	906104-005			HEXANGULAR BOLT M6 X 12	2
18	906201-004			STEEL WIRE NIP 4'7	6
19	906201-002			STEEL WIRE NIP .12	10
20	162002-065			WATER TUBE 4' 9*. 15*(40+100'50mm	1
21	162200-002			SEPARATOR, OIL AND AIR	1
22	162002-037			WATER TUBE 4'9*. 15*340mm	1
23	162001-034			HIGH TEMPERATURE MED) 9*(6 15*115+45mm	1
24	162006-001			SECOND-TIMED INLET	1
25	301000-002			STARTING RELAY	1
26	906103-015			BOLT M6 X 16	2
27	304000-008			IGNITION COIL	1
28	305000-006			CDI	1
29	302000-005			REGULATOR	1
30	906103-015			BOLT M6 X 16	2
31	303100-009			BATTERY ASSY	1
32	GB6187-86			NUT M10	2
33	902001-006			HEXANGULAR AXLE MI0*1.25*155	2
34	231000-005			CHAIN	1
35	181000-185			MUFFLER ASSY	1
36	906104-015			HEXANGULAR BOLT M8 X 16	1
37	906104-007			HEXANGULAR BOLT M6 X 20	2




COVERING PARTS ASSEMBLY (3)

COVERING FARTS ASSEMBLY

S/N	PART NO.			DESCRIPTION	QUANTITY
1	701000-849			SEAT CUSHION	1
2	306400-003			REAR REFLECTOR	2
3	332000-008			REAR LAMP ASSY	1
4	906104-016			HEXANGULAR BOLT tit i x 20	6
5	906170-001			SCREW M5*16	4
6	906150-002			WASHER BIG <i>cb</i> 5	4
7	904229-001			PAD d) 5	4
8	531100-017			LEFT FOOTREST PEDAL	1
9	906170-002			SCREW M6*16	8
10	906150-004			WASHER BIG d) 6	10
11	904229-001			PAD d) 6	10
12	809700-008			COVER BODY	1
13	360100-008			IGNITION SWITCH LOCK	1
14	906170-003			SCREW M6*20	4
15	906161-006			NUT, HEXANGULAR FLANGE M6	2
16	906176-008			SCREW 3. 5*16	2
17	903200-001			TOOLS	1
18	532100-017			RIGHT FOOTREST PEDAL	1
19	802000-005			FUEL SWITCH	1
20	801000-026			FUEL TANK ASSY	1
21	906104-009			HEXANGULAR BOLT M6 X 30	2
22	331000-015			HEAD LIGHT ASSY	1
23	361300-008			CAP, FUEL TANK	1
24	710100-001			MAST	1

www.seacubemoto.com




REAR WHEEL ASSEMBLY (4)

REAR WHEEL ASSEMBLY

S/N	PART NO.			DESCRIPTION	QUANTITY
1	408000-002			REAR TYRE	2
2	523100-001			REAR ARM ASSEMBLY	1
3	523200-005			CHAIN ADJUSTOR	1
4	906104-005			HEXANGULAR BOLT M6X12	14
5	400300-001			AIR CHAIN MOUTH	2
6	904206-001			DUSTPROOF RUBBER BOOT	2
7	906162-002			LOCK NUT, HEXANGULAR FLANGE M10X1.25	8
8	405100-005			SPROCKET WHEEL	1
9	243000-003			REAR AXLE ASSY	1
10	442001-002			REAR BRAKE DISC	1
11	405000-008			REAR TYRE HUB	2

www.seacubemoto.com




FRONT WHEEL ASSEMBLY (5)

www.seacubemoto.com

FRONT WHEEL ASSEMBLY

S/N	PART NO.			DESCRIPTION	QUANTITY
1	400300-001			AIR CHAIN MOUTH	2
2	404000-002			FRONT TYRE	2
3	906171-004			PIN COTTER 2.5)<30	2
4	904229-001			PLAT WASHER	2
5	906162-004		M14	NUT M14	2
6	505000-077			LEFT STEERING PARTS	1
7	430500-002			STEERING TIED-ROD COMP	1
8	904229-001			PLAT WASHER	4
9	906130-004			SPRING WASHER 10	4
10	906162-002			NUT M10	4
11	906171-002			PIN COTTER 2:<20	4
12	430500-002			STEERING TIED-ROD COMP	1
13	505000-077			RIGHT STEERING PARTS	1
14	426000-007			FRONT HUB COVER	1
15	906161-003		NUT M10	NUT M10	8
16	423100-024		LEFT BRAKE,FRONT	LEFT BRAKE,FRONT	1
17	423100-024			RIGHT BRAKE, FRONT	1
18	425000-007			FRONT-LEFT BRAKE	1
19	401000-065			FRONT TYRE HUB	2
20	505000-077			CROSS JOINT COVER	4
21	904206-006			DUSTPROOF RUBBER BOOT	2

www.seacubemoto.com




FRONT FORK ASSEMBLY (6)

FRONT FORK ASSY

S/N	PART NO.			DESCRIPTION	QUANTITY
1	442000-003			REAR DISC BRAKE ASSY	1
2	371100-009			LEFT HANDLEBAR SWITCH	1
3	600001-011			HANDLE BAR	1
4	904303-002			LEFT LEVER	2
5	503306-001			WIRE CLIP OF STEERING STEM	1
6	503301-005			STEERING ROD CLIP	2
7	503309-002			GASKET, HANDLE BAR CLIP	2
8	503002-002			STEERING STEM CLIP WASHER	1
9	902005-003			BUSH, STEERING STEM oh 13 X (1)9 X 39	1
10	906101-002			BOLT M8 X 50	2
11	906104-044			HEXANGULAR BOLT M8X60	4
12	503001-003			CLIP, HANDLE BAR	2
13	503200-002			HELEE,HANDLE UNDER	2
14	600002-002			BUSH HANDLE BAR PROTECT	1
15	372200-001			RIGHT HANDLE COMP	1
16	503300-023			STEERING STEM	1
17	605100-002			FRONT BRAKE CABLE (L)	1
18	605200-002			FRONT BRAKE CABLE (R)	1
19	607000-009			CABLE, THROTTLE	1
20	503308-002			COPPER SHEATHING	1
21	906152-005			WASHER(1)10	1
22	906108-002			CONE SLOT OF OPEN NUT MODEL M10	1
23	906171-003			PIN CUTTER 2*30	1

www.seacubemoto.com



www.seacubemoto.com

REAR AXLE ASSY

S/N	PART NO.			DESCRIPTION	QUANTITY
1	243000-002			REAR AXLE ASSY	1
2	243028-003			SLOTTED NUT M12	2
3	906150-020			WASHER	2
4	243040-002			DUST-PROOF COVER 18X45	2
5	243010-018			CONNECTOR PLATE	2
6	243033-001			BUSH 28X30X13	2
7	240001-007			OIL SEAL 30x42x7	2
8	243011-007			BEARING GB6905Z	2
9	243018-002			REAR SEAT	1
10	243012-013			REAR WHEEL AXLE	1
11	243022-005			LOCKED NUT M22x1.5	4
12	405101-004			SPROCKET WHEEL SET	2

www.seacubemoto.com