




PARTS CATALOGUE CATALOGO DE REPUESTOS

www.seacubemoto.com

YBR125ED (1NC1) ARGENTINA



1L1NC-276S1

()

www.seacubemoto.com

YBR125ED
CATALOGO DE REPUESTOS
©2011 por Yamaha Motor Co., Ltd.
1ª edición, noviembre 2011
Todos los derechos reservados.
Toda reproducción o uso no autorizado
sin el consentimiento escrito de
Yamaha Motor Co., Ltd.
quedan expresamente prohibidos
Impreso en Japón.

YBR125ED
PARTS CATALOGUE
©2011 by Yamaha Motor Co., Ltd.
1st edition, November 2011
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

PROLOGO

Este catálogo de repuestos corresponde a las piezas para el o los modelos que figuran en la página de portada. Al formular el pedido de repuestos, se ruega citar este catálogo y especificar correctamente el número y el nombre de las piezas.

1. Las modificaciones y agregados que se hayan realizado después de la edición de este Catálogo de Repuestos, serán anunciados en las Informaciones de Recambios. Es recomendable que se hagan las correcciones necesarias en el Catálogo de Repuestos de acuerdo con las Informaciones de Recambios.

2. Abreviaciones

En este. Catálogo de Repuestos se emplean las siguientes abreviaciones.

“UR” Usar el número de partes especificado

“UN” Usar la cantidad necesaria

“AP” Piezas sustitutivas

“LM” Fabricación local (Hay que pedir los repuestos en las cercanías)

“F#” N° de bastidor (N° aplicable a la máquina)

“O/S” Sobredimensionado

3. La cantidad de componentes para el montaje

- Los componentes, suministrados como conjunto, se describen con un punto (.) que precede al nombre del parte como se indica a continuación.
- La numeración que aparece a la derecha de cada descripción indica la cantidad de partes por cada unidad de conjunto.

CODIGO N°	DESCRIPCION	CANT.	OBSERVACIONES
2F5-83310-60	ENSAMBLAJE DE LA LUZ	2	
115-83311-60	.BOMBILLA (6V-18W)	1	

4. Los colores de los componentes se indican como sigue en la columna de “OBSERVACIONES”.

CODIGO N°	DESCRIPCION	CANT.	OBSERVACIONES
2N4-24110-00-X5	COMP. DEL TANQUE	2	MXR
3J1-24240-10	.GRAFICO, DEL TANQUE	1	PARA MXR

5. Debe tenerse en cuenta que las ilustraciones sirven como guía para la búsqueda de los números de partes y no deben usarse para el montaje. Durante el montaje, se recomienda usar el manual de taller correspondiente.

6. EL asterisco (*) antes del número de referencia indica los elementos modificados después de la primera edición.

www.seacubemoto.com



FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.


www.seacubemoto.com




FOREWORD

7. Applicable Serial No.

Frame Serial No.



Engine Serial No.



8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
BMC(*)	BLUE METALLIC C	0775
DBNM8(*)	DARK BLUISH GRAY METALLIC 8	0919
SMX	BLACK METALLIC X	0903
VRC7(*)	VIVID RED COCKTAIL 7	0580
YB	YAMAHA BLACK	0033

9. Applicable Starting Serial No.

Frame Serial No.

Serial No.	Name Of Q'ty Column	Model Code

Engine Serial No.

Serial No.	Name Of Q'ty Column	Model Code

www.seacubemoto.com

CONTENIDO

MOTOR

CILINDRO	1
CIGUENAL & PISTON	2
VALVULA	3
ARBOL DE LEVAS & CADENA	4
BOMBA DE ACEITE	5
ADMISION	6
CARBURADOR	7
DESCARGA	8
CARTER	9
CUBIERTA DE CARTER 1	10
ARRANQUE	11
EMBRAGUE DEL ARRANQUE	12
EMBRAGUE	13
TRANSMISION	14
LEVA DE CAMBIO & HORQUILLA	16
EJE DE CAMBIO & PEDAL	17

SHASIS

CUADRO	18
GUARDABARRO	19
CUBIERTA LATERAL	20
BRAZO TRASERO & SUSPENSION	21
DIRECCION	22
HORQUILLA DELANTERA	23
DEPOSITO DE COMBUSTIBLE	25
ASIENTO	28
RUEDA DELANTERA	29
CALIBRE FRENO DELANTERA	30
RUEDA TRASERA	31
MANILLAR & CABLE	33
CILINDRO MAESTRO DELANTERO	34
SOPORTE & APOYAPIE	35
GENERADOR	37
MOTOR DE ARRANQUE	38
LUZ DE DESTELLADOR	39
MEDIDOR	40
FARO DELANTERO	41
LUZ DE COLA	42
INTERRUPTOR DE MANILLAR&PALANC	43
EQUIPO ELECTRICO 1	44
EQUIPO ELECTRICO 2	45

INDICE

INDICE NUMERICO	46
-----------------------	----

www.seacubemoto.com

CONTENTS

ENGINE

CYLINDER	1
CRANKSHAFT & PISTON	2
VALVE	3
CAMSHAFT & CHAIN	4
OIL PUMP	5
INTAKE	6
CARBURETOR	7
EXHAUST	8
CRANKCASE	9
CRANKCASE COVER 1	10
STARTER	11
STARTER CLUTCH	12
CLUTCH	13
TRANSMISSION	14
SHIFT CAM & FORK	16
SHIFT SHAFT	17

CHASSIS

FRAME	18
FENDER	19
SIDE COVER	20
REAR ARM & SUSPENSION	21
STEERING	22
FRONT FORK	23
FUEL TANK	25
SEAT	28
FRONT WHEEL	29
FRONT BRAKE CALIPER	30
REAR WHEEL	31
STEERING HANDLE & CABLE	33
FRONT MASTER CYLINDER	34
STAND & FOOTREST	35
GENERATOR	37
STARTING MOTOR	38
FLASHER LIGHT	39
METER	40
HEADLIGHT	41
TAILLIGHT	42
HANDLE SWITCH & LEVER	43
ELECTRICAL 1	44
ELECTRICAL 2	45

INDEX

NUMERICAL INDEX	46
-----------------------	----

www.seacubemoto.com





FIG. 1 CILINDRO

CYLINDER

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	1NC1				OBSERV REMARK
1	5VL-E1111-01	CULATA CILINDRO 1 HEAD, CYLINDER 1	1				
2	2UJ-11133-10	.GUIA DE VALVULA 1 .GUIDE, VALVE 1	1				
3	22F-11134-10	.GUIA DE VALVULA 2 .GUIDE, VALVE 2	1				
4	93440-10109	.SEGURO .CIRCLIP	2				
5	90153-06803	.TORNILLO HEXAGONAL .SCREW, HEXAGON	1				
6	90430-06817	.JUNTA .GASKET	1				
7	5VL-E1185-00	CUBIERTA CULATA CIL.LAT.3 COVER, CYLINDER HEAD SIDE 3	1				
8	5VL-E1161-00	AMORTIGUADOR 1 ABSORBER 1	4				
9	93210-71801	ANILLO O O-RING	1				
10	95022-06020	PERNO, DE BRIDA BOLT, FLANGE	2				
11	5VL-E1186-00	CUBIERTA CULATA CIL.LAT.2 COVER, CYLINDER HEAD SIDE 2	2				
12	93210-44889	ANILLO O O-RING	2				
13	90105-08724	TORNILLO BOLT, FLANGE	4				
14	90201-088C3	ARANDELA PLANA WASHER, PLATE	4				
15	94700-00869	BUJIA (NGK CR6HSA) PLUG SPARK (NGK CR6HSA)	1				
16	5VL-E1181-00	JUNTA, DE CULATA 1 GASKET, CYLINDER HEAD 1	1				
17	99530-10114	PASADOR, DE ESPIGA PIN, DOWEL	2				
18	91312-06090	TORNILLO BOLT	2				
19	5VL-E1310-00	CILINDRO CYLINDER	1				
20	5VL-E1351-10	JUNTA, DE CILINDRO GASKET, CYLINDER	1				
21	93210-57897	ANILLO O O-RING	1				



2D0S415-H020

FIG. 2 CIGUENAL & PISTON

CRANKSHAFT & PISTON

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	2D0-W1140-00	CIGUENAL COMPLETO CRANKSHAFT ASSY	1				
2	2D0-W1141-00	.MANIVELA SEMI-ARMADA 1 .CRANK SUB ASSY 1	1				
3	5VL-E1681-00	.PASADOR MANIVELA 1 .PIN, CRANK 1	1				
4	93310-629Y3	.COJINETE DE RODILLOS .BEARING	1				
5	5VL-E1651-00	.BIELA .ROD, CONNECTING	1				
6	5VL-E1422-00	.MANIVELA 2 .CRANK 2	1				
7	5VL-Y1153-00	.ENGRANAJE TRACCION .GEAR, BALANCE WEIGHT ASSY.	1				
8	5VL-E1454-00	.PESO 1 .WEIGHT 1	1				
9	93210-11800	.ANILLO O .O-RING	2				
10	93306-205XJ	COJINETE BEARING	1				
11	5VL-E1631-00	PISTON (NORMA) PISTON (STD)	1				
12	5VL-E1633-00	PASADOR, PISTON PIN, PISTON	1				
13	93450-16812	SEGURO CIRCLIP	2				
14	5VL-W1161-00	JUEGO DE ANILLOS (NORMA) PISTON RING SET (STD)	1				
15	93306-202XN	COJINETE BEARING	2				
16	90280-03017	CUNA WOODRUFF KEY, WOODRUFF	1				
17	90201-122H1	ARANDELA PLANA WASHER, PLATE	1				
18	90179-12863	TUERCA NUT	1				


**VALVE**[illegible]



5VL1415-B041

FIG. 4 ARBOL DE LEVAS & CADENA CAMSHAFT & CHAIN

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERVACIONES REMARKS
1	5VL-E2171-00	ARBOL DE LEVAS 1 CAMSHAFT 1	1				
2	93306-003X6	COJINETE BEARING	1				
3	93306-002YU	COJINETE BEARING	1				
4	90387-167L5	ESPACIADOR COLLAR	1				
5	5VL-E111F-00	PLACA PLATE	1				
6	91312-06012	TORNILLO BOLT	1				
7	5VL-E2176-00	CATALINA DE CADENA (34T) SPROCKET, CAM CHAIN (34T)	1				
8	90201-08326	ARANDELA PLANA WASHER, PLATE	1				
9	90101-08820	TORNILLO BOLT	1				
10	94568-C1088	CADENA CHAIN	1				
11	5VL-E2231-00	TOPE DE GUIA 1 GUIDE, STOPPER 1	1				
12	5VL-E2241-00	TOPE DE GUIA 2 GUIDE, STOPPER 2	1				
13	5VL-E5598-00	COLLAR COLLAR	1				
14	95802-06020	TORNILLO DE REBORDE BOLT, FLANGE	1				
15	5VL-E2210-01	SENSOR CADENA DE LEVA TENSIONER ASSY, CAM CHAIN	1				
16	5VL-E2213-10	EMPAQUE DE CAJA SENSOR GASKET, TENSIONER CASE	1				
17	95022-06016	PERNO, DE BRIDA BOLT, FLANGE	2				
18	90430-06817	JUNTA GASKET	2				

[illegible]




FIG. 6 **ADMISSION**

INTAKE

REF. N°	CODIGO N° PART NO.	DESCRIPCION DESCRIPTION	INC				OBSERVATION REMARK
1	4P2-E3586-00	TOBERA DE CARBURADOR 1 JOINT, CARBURETOR 1	1				
2	93210-30611	ANILLO O O-RING	1				
3	91312-06025	TORNILLO BOLT	2				
4	90450-44804	BRIDA, MANGUERA HOSE CLAMP ASSY	1				
5	4P2-Y1441-01	FILTRO DE AIRE COMPLETO AIR CLEANER ASSY.	1				
6	5VL-E4411-00	.CAJA FILTRO DEL AIRE 1 .CASE, AIR CLEANER 1	1				
7	5VL-E4412-00	.TAPA CAJA DEL FILTRO 1 .CAP, CLEANER CASE 1	1				
8	5VL-E4450-01	.ELEMENTO COMP.FILTRO DE AIRE .ELEMENT ASSY, AIR CLEANER	1				
9	4P2-E4453-00	.UNION DEL FILTRO DEL AIRE 1 .JOINT, AIR CLEANER 1	1				
10	5VL-E4437-00	.CONDUCTO .DUCT	1				
11	5VL-E4452-00	.SELLO .SEAL	2				
12	5VL-E4462-00	.SELLO .SEAL	1				
13	97602-06220	.TORNILLO CON RONDONA .SCREW, PAN HEAD W/WASHER	5				
14	5VL-E443E-00	.TUBO, DRENAJE .PIPE, DRAIN	1				
15	5VL-E4424-01	.PRESILLA ACCESORIO DE TAPA .CLIP, CAP FITTING	1				
16	5VL-E4417-00	.CUBIERTA 1 .COVER 1	1				
17	90119-06869	TORNILLO CON ARANDELA BOLT, WITH WASHER	2				
18	90450-51802	BRIDA, MANGUERA HOSE CLAMP ASSY	1				




FIG. 7 CARBURADOR


CARBURETOR

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	1PX-E4301-00	CARBURADOR COMPLETO 1 CARBURETOR ASSY 1	1				
2	4P2-W149K-00	.CJTO. TORNILLO DEL RALENTI .THROTTLE SCREW SET	1				
3	4P2-W149J-00	.CJTO. AGUJA .NEEDLE SET	1				
4	4P2-E4286-00	.RESORTE .SPRING	1				
5	5LB-E4214-00	.TORNILLO DE CABEZA CON PLANA .SCREW, PAN HEAD	2				
6	5RS-E4341-00	.BOQUILLA PRINCIPAL .NOZZLE, MAIN	1				
7	5RS-E4341-10	.BOQUILLA PRINCIPAL .NOZZLE, MAIN	1				
8	288-E4343-60	.INYECTOR PRINCIPAL (#120) .JET, MAIN (#120)	1				
9	5LB-E4342-17	.ESPREA DE PILOTO (#34) .JET, PILOT (#34)	1				
10	4P2-W1415-00	.TORNILLO DE PILOTO .PILOT SCREW SET	1				
11	4P2-W149A-00	.CONTROL REMOTO .DIAPHRAGM SET 1	1				
12	5LB-E4293-00	.CUBIERTA .COVER 1	1				
13	97801-04010	.TORNILLO DE MUESCA .SCREW, PAN HEAD	2				
14	50M-E4355-00	.ASIENTO .NOZZLE, MAIN 2	1				
15	4P2-E4371-00	.EMBOLO DE ARRANQUE .PLUNGER, STARTER	1				
16	5LB-E4385-00	.BOIA .FLOAT	1				
17	5LB-E4386-00	.PASADOR DE BOIA .PIN, FLOAT	1				
18	1BV-E4390-00	.VALVULA DE AGUJA COMPLETA .NEEDLE VALVE ASSY	1				
19	30S-14325-00	.TORNILLO CABEZA REDONDA .SCREW, PAN HEAD	1				
20	5LB-E4384-00	.EMPAQUE DE CAMARA DE BOIA .GASKET, FLOAT CHAMBER	1				
21	4JP-E4323-00	.TORNILLO DE AJUSTE DE AIRE .SCREW, AIR ADJUSTING	1				
22	5LB-E4153-00	.PLACA,BAFFLE .PLATE,BAFFLE	1				
23	5LB-E4592-00	.TORNILLO .SCREW	4				
24	5FY-E4251-00	.NIPLE .NIPPLE	1				
25	5LB-E4292-00	.SOPORTE 2 .BRACKET 2	1				
26	4P2-E4197-00	.TUBO RESPIRADERO .PIPE	1				
27	1PX-E4196-00	.TUBO DE DRENASE .PIPE, OVER FLOW 1	1				

FIG. 8 DESCARGA

EXHAUST

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	1PX-E4710-00	TUBO DE ESCAPE COMPLETO 1 MUFFLER ASSY 1	1				
2	4TU-F4741-00	.COJIN DE ASIENTO .PAD, SEAT	1				
3	5VL-E4758-00	.PROTECTOR DE SILENCIADOR .PROTECTOR, SILENCER	1				
4	5VL-E4628-00	.PROTECTOR DE TUBO DE ESCAPE .PROTECTOR, EXHAUST PIPE	1				
5	98980-06012	.TORNILLO DE LIGAR .SCREW, BIND	2				
6	90201-05803	.ARANDELA PLANA .WASHER, PLATE	6				
7	90201-05804	.ARANDELA PLANA .WASHER, PLATE	6				
8	98980-06014	.TORNILLO DE LIGAR .SCREW, BIND	4				
9	1PX-E4738-00	PROTECTOR DE SILENCIADOR 3 PROTECTOR MUFFLER 3	1				
10	98980-06014	TORNILLO DE LIGAR SCREW, BIND	2				
11	92990-06200	ARANDELA PLANA WASHER, PLAIN	2				
12	5VL-E4613-00	JUNTA, TUBO DE ESCAPE GASKET, EXHAUST PIPE	1				
13	91312-06020	TORNILLO BOLT	2				
14	95812-08020	TORNILLO DE REBORDE BOLT, FLANGE	1				



1NC1276-L080





FIG. 9 CARTER

CRANKCASE

[illegible]

FIG. 10 CUBIERTA DE CARTER 1 CRANKCASE COVER 1



REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	5VL-E5411-10	CUBIERTA DE CARTER 1 COVER, CRANKCASE 1	1				
2	5VL-E5451-10	EMPAQ DE CUBIERTA DE CARTER GASKET, CRANKCASE COVER 1	1				
3	99530-10114	PASADOR, DE ESPIGA PIN, DOWEL	2				
4	95022-06035	PERNO, DE BRIDA BOLT, FLANGE	1				
5	95022-06050	PERNO, DE BRIDA BOLT, FLANGE	6				
6	90340-14810	TORNILLO, DE DRENAJE PLUG, STRAIGHT SCREW	1				
7	93210-14899	ANILLO O O-RING	1				
8	90340-32812	TORNILLO, DE DRENAJE PLUG, STRAIGHT SCREW	1				
9	93210-328A4	ANILLO O O-RING	1				
10	5VL-E5191-00	PLACA PLATE	1				
11	98512-06010	TORNILLO SCREW, PAN HEAD	1				
12	5VL-E5418-02	CUBIERTA DE CADENA COVER, CHAIN CASE	1				
13	98902-06016	TORNILLO DE AJUSTE SCREW, BIND	2				
14	5VL-E5421-00	TAPA DE CARTER DERECHA COVER, CRANKCASE 2	1				
15	5VL-E5461-10	JUNTA TAPA CARTER DERECHO 2 GASKET, CRANKCASE COVER 2	1				
16	99530-10114	PASADOR, DE ESPIGA PIN, DOWEL	2				
17	95022-06035	PERNO, DE BRIDA BOLT, FLANGE	7				
18	95022-06045	PERNO, DE BRIDA BOLT, FLANGE	2				
19	5VL-E5362-00	TAPON DEL NIVEL DE ACEITE PLUG, OIL LEVEL	1				
20	93210-19809	ANILLO O O-RING	1				
21	93101-10800	SELLO ACEITE OIL SEAL	1				




FIG. 11 ARRANQUE

STARTER

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1			OBSERV REMARK
1	5VL-E5660-01	EJE DEL PEDAL DE ARRAN.COMPLET KICK AXLE ASSY	1			
2	4FP-E5641-00	ENGRANAJE PEDAL ARRANQUE GEAR, KICK	1			
3	90468-26813	PRESILLA CLIP	1			
4	90201-208D5	ARANDELA PLANA WASHER, PLATE	1			
5	90508-26836	RESORTE DE TORSION SPRING, TORSION	1			
6	4FP-E5666-00	SEPARADOR SPACER	1			
7	5VL-E5651-00	PINON LIBRE, PEDAL ARRANQUE GEAR, KICK IDLE	1			
8	90201-152H7	ARANDELA PLANA WASHER, PLATE	2			
9	99009-15400	PRESILLA REDONDA CIRCLIP	2			
10	5VL-E5620-01	PEDAL DE ARRANQUE COMPLETO KICK CRANK ASSY	1			
11	47V-E5618-00	GOMA PROTECTORA, PEDAL .COVER, KICK LEVER	1			
12	90179-12813	TUERCA NUT	1			
13	93109-20806	SELLO ACEITE OIL SEAL	1			
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-




FIG. 13 EMBRAGUE

CLUTCH

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	5VL-E6111-00	ENGRANAJE TRACC.PRIMARIA GEAR, PRIMARY DRIVE	1				
2	90282-05001	CHAVETA, RECTA (5MMX16MM) KEY, STRAIGHT (5MMX16MM)	1				
3	90201-122H1	ARANDELA PLANA WASHER, PLATE	1				
4	90179-12813	TUERCA NUT	1				
5	5VL-E6300-10	EMBRAGUE COMPLETO CLUTCH ASSY	1				
6	5VL-E6150-00	.CAMPANA DE EMBRAGUE .PRIMARY DRIVEN GEAR COMP.	1				
7	5VL-E6154-00	.ARANDELA, DE EMPUJE 1 .PLATE, THRUST 1	1				
8	5VL-E6371-10	.CUBO, DE EMBRAGUE .BOSS, CLUTCH	1				
9	5VL-E6321-10	.PLACA DE FRICCION .PLATE, FRICTION	4				
10	5VL-E6324-00	.PLACA DE EMBRAGUE .PLATE, CLUTCH 1	3				
11	5VL-E6351-00	.PLATO DE PRESION .PLATE, PRESSURE 1	1				
12	5VL-E6333-10	.RESORTE DE EMBRAGUE 1 .SPRING, CLUTCH 1	4				
13	5VL-E6337-00	.TORNILLO DE RESORTE .SCREW, SPRING	4				
14	5VL-Y1635-10	CONJ. PALANCA DE EMPUJE PUSH LEVER COMP.	1				
15	92902-06200	ARANDELA WASHER	1				
16	95302-06600	TUERCA NUT	1				
17	5VL-E6164-10	PLACA DE EMPUJE 2 PLATE, THRUST 2	1				
18	90215-12211	ARANDELA DE CIERRE WASHER, LOCK	1				
19	90170-12060	TUERCA NUT	1				
20	93503-16824	ESFERA BALL	1				
21	5VL-E6357-01	VARILLA DE EMPUJE 2 ROD, PUSH 2	1				
22	5VL-E6381-02	CONJ. PALANCA DE EMPUJE PUSH LEVER COMP.	1				
23	90508-16800	RESORTE DE TORSION SPRING, TORSION	1				
24	93102-12802	SELLO ACEITE OIL SEAL	1				
25	99009-20500	PRESILLA REDONDA CIRCLIP	1				




FIG. 14 TRANSMISSION

TRANSMISSION

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	5VL-E7411-00	EJE PRIMARIO (14T) AXLE, MAIN (14T)	1				
2	5VL-E7151-00	ENGRANAJE PINON DE 5TA (24T) GEAR, 5TH PINION (24T)	1				
3	5VL-E7121-00	ENGRANAJE DE PINON DE 2DA(18T) GEAR, 2ND PINION (18T)	1				
4	5VL-E7131-00	ENGRANAJE PINON DE 3RA (19T) GEAR, 3RD PINION (19T)	1				
5	5VL-E7141-00	ENGRANAJE PINON DE 4TA (22T) GEAR, 4TH PINION (22T)	1				
6	90201-20266	ARANDELA, PLACA (T=1.0) WASHER, PLATE (T=1.0)	1				
7	93410-20809	SEGURO CIRCLIP	1				
8	93306-201Y8	COJINETE BEARING	1				
9	93306-203YT	COJINETE BEARING	1				
10	5VL-E7471-00	PLACA, DE CUBIERTA PLATE, COVER	1				
11	98512-06012	TORNILLO SCREW, PAN HEAD	2				
12	5VL-E7421-00	EJE SECUNDARIO AXLE, DRIVE	1				
13	90331-07031	TAPON PLUG	1				
14	5VL-E7251-00	ENGRANAJE RUEDA DE 5TA (21T) GEAR, 5TH WHEEL (21T)	1				
15	5VL-E7221-00	ENGRANAJE RUEDA DE 2DA (32T) GEAR, 2ND WHEEL (32T)	1				
16	5VL-E7231-00	ENGRANAJE RUEDA DE 3RA (25T) GEAR, 3RD WHEEL (25T)	1				
17	90201-20266	ARANDELA, PLACA (T=1.0) WASHER, PLATE (T=1.0)	1				
18	93410-20809	SEGURO CIRCLIP	1				
19	5VL-E7241-00	ENGRANAJE DE RUEDA 4TA (23T) GEAR, 4TH WHEEL (23T)	1				
20	5VL-E7211-00	ENGRANAJE RUEDA DE 1 RA (37T) GEAR, 1ST WHEEL (37T)	1				
21	90201-15700	ARANDELA PLANA WASHER, PLATE	1				
22	99009-15400	PRESILLA REDONDA CIRCLIP	1				
23	90201-20272	ARANDELA PLANA WASHER, PLATE	1				
24	93306-204YD	COJINETE BEARING	1				
25	93102-20854	SELLO ACEITE OIL SEAL	1				
26	93306-202XP	COJINETE BEARING	1				
27	93822-14813	CORONA (14T) SPROCKET, DRIVE (14T)	1				



FIG. 14 TRANSMISSION

TRANSMISSION

[illegible]

This diagram shows an exploded view of a mechanical assembly. The components are numbered as follows:

- 1**: A large cylindrical component with longitudinal grooves, likely a motor or actuator.
- 2**: A gear or sprocket with four teeth.
- 3**: A small pin or shaft passing through the gear (2) and the main cylinder (1).
- 4**: A screw or bolt used to secure the gear (2) to the pin (3).
- 5** and **6**: Two identical L-shaped brackets or levers, each featuring a circular hole at the bottom.
- 7**: A pin or shaft that fits into the circular holes of brackets 5 and 6.
- 8** and **9**: Two long, thin cylindrical rods or shafts.

Assembly lines indicate the following relationships:

- The pin (3) passes through the gear (2) and the main cylinder (1).
- The screw (4) secures the gear (2) to the pin (3).
- The pins (7) are inserted into the circular holes of the brackets (5 and 6).
- The rods (8 and 9) are positioned to be inserted into the main cylinder (1) and the brackets (5 and 6).

 5HP1100-0140




FIG. 16 EJE DE CAMBIO & PEDAL

SHIFT SHAFT

[illegible]





FIG. 17 CUADRO

FRAME

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	1INC1				OBSERV REMARK
1	1NC-F1110-00	ARMAZON COMPLETO FRAME COMP.	1				
2	42D-F1316-00	SOPORTE DE MOTOR 3 STAY, ENGINE 3	1				
3	95812-10080	TORNILLO DE REBORDE BOLT, FLANGE	2				
4	90105-08874	TORNILLO BOLT, FLANGE	2				
5	90179-10807	TUERCA NUT	2				
6	90179-08830	TUERCA NUT	2				
7	42D-F1317-00	SOPORTE DE MOTOR 3 STAY, ENGINE 3	1				
8	42D-F1318-00	SOPORTE DE MOTOR 5 STAY, ENGINE 5	1				
9	90105-088E4	TORNILLO BOLT, FLANGE	1				
10	90105-088E5	TORNILLO BOLT, FLANGE	2				
11	90179-08830	TUERCA NUT	3				
12	90105-08873	TORNILLO BOLT, FLANGE	1				
13	90105-088E6	TORNILLO BOLT, FLANGE	1				
14	90179-08830	TUERCA NUT	2				
15	90201-08840	ARANDELA PLANA WASHER, PLATE	1				
16	5VL-F8100-01	JUEGO DE HERRAMIENTAS TOOL KIT	1				
17	5VL-F811G-01	CINTA BAND	1				



FENDER

www.seacubemoto.com



SIDE COVER

20



REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1			OBSERVACIONES REMARKS
1	5VL-F2110-00	BRAZO TRASERO COMPLETO REAR ARM COMP.	1			
2	90386-18099	BUJE BUSH	2			
3	5VL-F2123-00	BUJE 1 BUSH 1	2			
4	5VL-F2128-01	TAPA DE EMPIJE 1 COVER, THRUST 1	2			
5	93109-18802	SELLO ACEITE OIL SEAL	2			
6	5VL-F2127-00	CUNA SHIM	1			
7	5VL-F2141-01	EJE DEL BARCULANTE SHAFT, PIVOT	1			
8	95602-12200	TUERCA DE AUTO-CIERRE NUT, SELF-LOCKING	1			
9	90201-12819	ARANDELA PLANA WASHER, PLATE	1			
10	5VL-F2151-10	SELLO DE GUARDA SEAL, GUARD	1			
11	5VL-F2311-00	CABRECADENA CASE, CHAIN	1			
12	90159-06830	TORNILLO CON VALONA SCREW, WITH WASHER	2			
13	5VL-F2210-01	AMORTIGUADOR TRASERO COMPLETO SHOCK ABSORBER ASSY, REAR	2			
14	90201-108C7	ARANDELA PLANA WASHER, PLATE	4			
15	90176-10810	TUERCA CORONA NUT, CROWN	4			
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-




FIG. 21 DIRECCION

STEERING

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	1NC1				OBSERVACIONES REMARKS
1	1KL-F3412-00	PISTA DE BOLAS 2 RACE, BALL 2	1				
2	4FP-F3411-00	PISTA DE BOLAS 1 RACE, BALL 1	1				
3	4FP-F3412-00	PISTA DE BOLAS 2 RACE, BALL 2	1				
4	5VL-F341E-00	RETEN DE COJINETE RETAINER, BALL BEARING	2				
5	4GU-F3416-00	CUBIERTA DE BASE DE BOLA 2 COVER, BALL RACE 2	1				
6	90179-25810	TUERCA NUT	2				
7	42D-F3418-00	ARANDELA ESPECIAL WASHER, SPECIAL	1				
8	90202-26142	ARANDELA DE PLANA WASHER, PLATE	1				
9	5VL-F3435-00-33	PLATINA SUPERIOR CROWN, HANDLE	1				YB
10	95022-08040	PERNO, DE BRIDA BOLT, FLANGE	2				YB
11	90176-22801	TUERCA CORONA NUT, CROWN	1				
12	90201-22804	ARANDELA PLANA WASHER, PLATE	1				
13	5VL-F3441-00	SOPORTE DE MANUBRIO HOLDER, HANDLE UPPER	2				
14	95022-08035	PERNO, DE BRIDA BOLT, FLANGE	4				
15	3D9-F3174-10	SOPORTE DEL FARO DELANTERO STAY, HEADLIGHT	1				
16	95822-06016	TORNILLO DE REBORDE BOLT, FLANGE	2				
17	4FP-F317J-00	AMORTIGUADOR 1 DAMPER 1	2				
18	18C-F3389-00	GUIA DE CABLE GUIDE, CABLE	1				
19	95822-06012	TORNILLO DE REBORDE BOLT, FLANGE	2				
20	4FP-F3395-10	EMBLEMA EMBLEM	1				
21	42D-F334G-00	SOPORTE 1 BRACKET 1	1				
22	97002-05012	PERNO BOLT	2				
23	90201-05802	ARANDELA PLANA WASHER, PLATE	2				




FIG. 22 HORQUILLA DELANTERA


FRONT FORK

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	5VL-F3102-B0	HORQUILLA DELANTERA COMPL.(MI) FRONT FORK ASSY (L.H)	1				
2	5VL-F3106-30	.TUBO EXTERIOR COMPLETO .OUTER TUBE COMP.	1				
3	4GU-F3145-00	..RETEN DE ACEITE ..OIL SEAL	1				
4	5AP-F3153-00	..ANILLO DE ENGANCHE ..RING, SNAP	1				
5	4GU-F3144-00	..GUARDAPOLVO ..SEAL, DUST	1				
6	5HH-F3110-22	.TUBO INTERIOR COMPLETO 1 .INNER TUBE COMP.1	1				
7	5VL-F3170-01	.CILINDRO COMPL DE HORQ DELANT .CYLINDER COMP., FRONT FORK	1				
8	4GU-F3173-01	.VASTAGO AHUSADO .SPINDLE, TAPER	1				
9	4TU-F3479-00	.EMPAQUE .GASKET	1				
10	5LK-F3356-01	.PERNO 2 .BOLT 2	1				
11	5VL-F3141-40	.RESORTE HORQUILLA DELANT. .SPRING, FRONT FORK	1				
12	5AP-F3427-00	.ARANDELA .WASHER	1				
13	5HH-F3118-10	.SEPARADOR .SPACER	1				
14	5AP-F3147-00	.ARO .O-RING	1				
15	5VL-F3111-20	.PERNO DE TAPA .BOLT, CAP	1				
16	5VL-F3154-00	.TAPÓN TUBO INTERIOR .CAP	1				
17	5VL-H5110-01	.REFLECTOR COMPLETO .REFLECTOR ASSY	1				
18	5VL-F3103-B0	HORQUILLA DELANTERA COMPL.(MD) FRONT FORK ASSY (R.H)	1				
19	5VL-F3107-40	.TUBO EXTERIOR COMPLETO (MD) .OUTER TUBE COMP. (R.H)	1				
20	4GU-F3145-00	..RETEN DE ACEITE ..OIL SEAL	1				
21	5AP-F3153-00	..ANILLO DE ENGANCHE ..RING, SNAP	1				
22	4GU-F3144-00	..GUARDAPOLVO ..SEAL, DUST	1				
23	5HH-F3110-22	.TUBO INTERIOR COMPLETO 1 .INNER TUBE COMP.1	1				
24	5VL-F3170-01	.CILINDRO COMPL DE HORQ DELANT .CYLINDER COMP., FRONT FORK	1				
25	4GU-F3173-01	.VASTAGO AHUSADO .SPINDLE, TAPER	1				
26	4TU-F3479-00	.EMPAQUE .GASKET	1				
27	5LK-F3356-01	.PERNO 2 .BOLT 2	1				



FRONT FORK


www.seacubemoto.com



1NC1276-L230

FIG. 23 DEPOSITO DE COMBUSTIBLE FUEL TANK


REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	1PX-W2411-00-P0	DEPOSITO DE COMBUSTIBLE COMP. FUEL TANK ASSY	1				UR PARA VRC7 UR FOR VRC7
	1PX-W2411-00-P1	DEPOSITO DE COMBUSTIBLE COMP. FUEL TANK ASSY	1				UR PARA BMC UR FOR BMC
	1PX-W2411-00-P2	DEPOSITO DE COMBUSTIBLE COMP. FUEL TANK ASSY	1				UR PARA DBNM8 UR FOR DBNM8
2	18C-F4188-00	.MOLDURA DEPOSITO COMBUST. .MOLD, FUEL TANK	1				
3	5PA-21568-01	.ETIQUETA DE PRECAUCION .LABEL, WARNING	1				
4	18C-F4244-00	.CALCOMANIA DEPOSITO COMBUST.1 .GRAPHIC, FUEL TANK 1	1				UR PARA VRC7 UR FOR VRC7
	18C-F4244-10	.CALCOMANIA DEPOSITO COMBUST.1 .GRAPHIC, FUEL TANK 1	1				UR PARA BMC UR FOR BMC
	18C-F4244-20	.CALCOMANIA DEPOSITO COMBUST.1 .GRAPHIC, FUEL TANK 1	1				UR PARA DBNM8 UR FOR DBNM8
5	18C-F4245-00	.CALCOMANIA DEPOSITO COMBUST.2 .GRAPHIC, FUEL TANK 2	1				UR PARA VRC7 UR FOR VRC7
	18C-F4245-10	.CALCOMANIA DEPOSITO COMBUST.2 .GRAPHIC, FUEL TANK 2	1				UR PARA BMC UR FOR BMC
	18C-F4245-20	.CALCOMANIA DEPOSITO COMBUST.2 .GRAPHIC, FUEL TANK 2	1				UR PARA DBNM8 UR FOR DBNM8
6	2B9-F411B-00	.EMBLEMA .EMBLEM	2				
7	4FP-F4181-00	AMORTIGUADOR DE MONTAJE 1 DAMPER, LOCATING 1	2				
8	5VL-F4183-00	AMORTIGUADOR DE MONTAJE 3 DAMPER, LOCATING 3	1				
9	5VL-F4182-00	AMORTIGUADOR DE MONTAJE 2 DAMPER, LOCATING 2	1				
10	90201-088P2	ARÁNDELA PLANA WASHER, PLATE	1				
11	97002-08016	PERNO BOLT	1				
12	5VL-F4500-00	GRIFO DE COMBUSTIBLE 1 FUEL COCK ASSY 1	1				
13	5VL-F4534-00	.SELLO DE GRIFO .SEAL, COCK	1				
14	97880-03008	.TORNILLO DE CABEZA CON PLANA .SCREW, PAN HEAD	2				
15	5VL-F4512-00	.EMPAQUE .GASKET	1				
16	5VL-F4523-00	.VALVULA .VALVE	1				
17	5VL-F4515-00	.RED DE FILTRO 2 .NET, FILTER 2	1				
18	5VL-F4524-01	LLAVE DEL GRIFO LEVER, COCK	1				
19	90157-03800	TORNILLO CABEZA CONICA PLANA .SCREW, PAN HEAD	1				
20	90159-06820	TORNILLO CON VALONA .SCREW, WITH WASHER	2				
21	90430-05800	JUNTA GASKET	2				




1NC1276-L230

FIG. 23 DEPOSITO DE COMBUSTIBLE FUEL TANK

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	1NC1				OBSERV REMARK
22	4P2-F4311-00	TUBO DE COMBUSTIBLE 1 PIPE, FUEL 1	1				
23	90467-09854	PRESILLA CLIP	2				
24	18C-W137W-00-P0	CUBIERTA DE GUIA DE AIRE 1 SCOOP, AIR 1	1				UR PARA VRC7 UR FOR VRC7
	18C-W137W-00-P1	CUBIERTA DE GUIA DE AIRE 1 SCOOP, AIR 1	1				UR PARA BMC UR FOR BMC
	18C-W137W-00-P2	CUBIERTA DE GUIA DE AIRE 1 SCOOP, AIR 1	1				UR PARA DBNM8 UR FOR DBNM8
25	90480-15878	.TAPON .GROMMET	1				
26	99236-00100	.EMBLEMA, YAMAHA .EMBLEM, YAMAHA	1				
27	18C-F4255-00	.CALCOMANIA DEP. COMBUSTIBLE 8 .GRAPHIC, FUEL TANK 8	1				UR PARA VRC7 UR FOR VRC7
	18C-F4255-10	.CALCOMANIA DEP. COMBUSTIBLE 8 .GRAPHIC, FUEL TANK 8	1				UR PARA BMC UR FOR BMC
	18C-F4255-20	.CALCOMANIA DEP. COMBUSTIBLE 8 .GRAPHIC, FUEL TANK 8	1				UR PARA DBNM8 UR FOR DBNM8
28	18C-F137U-00	GUIA DE AIRE 1 GUIDE, AIR 1	1				
29	18C-W137X-01-P0	CUBIERTA DE GUIA DE AIRE 2 SCOOP, AIR 2	1				UR PARA VRC7 UR FOR VRC7
	18C-W137X-01-P1	CUBIERTA DE GUIA DE AIRE 2 SCOOP, AIR 2	1				PARA BMC FOR BMC
	18C-W137X-01-P2	CUBIERTA DE GUIA DE AIRE 2 SCOOP, AIR 2	1				UR PARA DBNM8 UR FOR DBNM8
30	90480-15878	.TAPON .GROMMET	1				
31	99236-00100	.EMBLEMA, YAMAHA .EMBLEM, YAMAHA	1				
32	18C-F4188-10	.MOLDURA DEPOSITO COMBUST. .MOLD, FUEL TANK	1				
33	18C-F4256-00	.CALCOMANIA DEP. COMBUSTIBLE 9 .GRAPHIC, FUEL TANK 9	1				UR PARA VRC7 UR FOR VRC7
	18C-F4256-10	.CALCOMANIA DEP. COMBUSTIBLE 9 .GRAPHIC, FUEL TANK 9	1				UR PARA BMC UR FOR BMC
	18C-F4256-20	.CALCOMANIA DEP. COMBUSTIBLE 9 .GRAPHIC, FUEL TANK 9	1				UR PARA DBNM8 UR FOR DBNM8
34	18C-F137V-00	GUIA DE AIRE 2 GUIDE, AIR 2	1				
35	97702-50016	TORNILLO ROSCA HEMBRA SCREW, TAPPING	4				
36	95802-06012	TORNILLO DE REBORDE BOLT, FLANGE	2				
37	18C-F4216-00	SOPORTE STAY	1				
38	95802-06020	TORNILLO DE REBORDE BOLT, FLANGE	2				
39	90387-06879	ESPACIADOR COLLAR	2				
40	90202-09800	ARANDELA DE PLANA WASHER, PLATE	2				

[illegible]



1NC1276-L240

FIG. 24 ASIENTO


SEAT


REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	18C-F4730-01	SILLIN DOBLE COMPLETO DOUBLE SEAT ASSY	1				
2	4TU-F4741-00	COJIN DE ASIENTO PAD, SEAT	6				
3	90119-06869	TORNILLO CON ARANDELA BOLT, WITH WASHER	2				
4	18C-F471K-00-P0	CUBIERTA, DE COLA 1 COVER, TAIL 1	1				UR PARA VRC7 UR FOR VRC7
	18C-F471K-00-P1	CUBIERTA, DE COLA 1 COVER, TAIL 1	1				UR PARA BMC UR FOR BMC
	18C-F471K-00-P2	CUBIERTA, DE COLA 1 COVER, TAIL 1	1				UR PARA DBNM8 UR FOR DBNM8
5	18C-F472K-00-P0	CUBIERTA, DE COLA 2 COVER, TAIL 2	1				UR PARA VRC7 UR FOR VRC7
	18C-F472K-00-P1	CUBIERTA, DE COLA 2 COVER, TAIL 2	1				UR PARA BMC UR FOR BMC
	18C-F472K-00-P2	CUBIERTA, DE COLA 2 COVER, TAIL 2	1				UR PARA DBNM8 UR FOR DBNM8
6	18C-Y2475-00-P0	CUBIERTA DE COLA COVER, TAIL ASSY	1				UR PARA VRC7 UR FOR VRC7
	18C-Y2475-00-P1	CUBIERTA DE COLA COVER, TAIL ASSY	1				UR PARA BMC UR FOR BMC
	18C-Y2475-00-P2	CUBIERTA DE COLA COVER, TAIL ASSY	1				UR PARA DBNM8 UR FOR DBNM8
7	99234-00080	.EMBLEMA, YAMAHA .EMBLEM, YAMAHA	1				
8	9770N-50012	TORNILLO ROSCA HEMBRA SCREW, TAPPING	6				
9	90119-06869	TORNILLO CON ARANDELA BOLT, WITH WASHER	4				
10	90480-01868	TAPON GROMMET	2				
11	18C-F4773-00	MANIJA DE ASIENTO HANDLE, SEAT	1				
12	90338-16148	TAPON PLUG	2				
13	95812-08020	TORNILLO DE REBORDE BOLT, FLANGE	4				
14	18C-F474K-01	SOPORTE STAY 3	1				
15	18C-F474L-01	SOPORTE STAY 4	1				



FRONT WHEEL

[illegible]

[illegible]




1NC1276-L270

FIG. 27 RUEDA TRASERA

REAR WHEEL


REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	1NC1				OBSERV RE MARK
1	1PX-F5338-00-33	RUEDA FUNDIDA TRASERA CAST WHEEL, REAR	1				YB YB
2	90387-15809	ESPACIADOR COLLAR	1				
3	93306-202Y4	COJINETE BEARING	1				
4	93306-252X5	COJINETE BEARING	1				
5	93104-22802	SELLO ACEITE OIL SEAL	1				
6	93210-42807	ANILLO O O-RING	1				
7	1KL-F5364-00	AMORTIGUADOR DAMPER	4				
8	5VL-F5321-01-33	PLACA DE ZAPATA DE FRENO PLATE, BRAKE SHOE	1				YB YB
9	3D9-W2533-00	JUEGO DE ZAPATA DE FRENO BRAKE SHOE KIT	1				
10	90506-12801	RESORTE DE TENSION SPRING, TENSION	1				
11	90506-15802	RESORTE DE TENSION SPRING, TENSION	1				
12	4GU-F5351-02	ARBOL DE LEVAS CAMSHAFT	1				
13	5VL-F5355-01	PALANCA DE ARBOL DE LEVAS LEVER, CAMSHAFT	1				
14	90101-06848	TORNILLO BOLT	1				
15	95302-06600	TUERCA NUT	1				
16	4GU-F533A-01	PLACA INDICADOR PLATE, INDICATOR	1				
17	5VL-F5366-00	EMBRAGUE DE MASA CLUTCH, HUB	1				
18	93306-004YL	COJINETE BEARING	1				
19	93106-26804	SELLO ACEITE OIL SEAL	1				
20	42D-F5387-00	EJE DE CORONA AXLE, SPROCKET	1				
21	5VL-F5445-01	CORONA (45D) SPROCKET, DRIVEN (45T)	1				
22	90109-08864	PERNO BOLT	4				
23	5LK-F5412-01	ARANDELA WASHER	2				
24	90179-08639	TUERCA NUT	4				
25	94109-18816	NEUMATICO (90/90-18 S180 57P) TIRE (90/90-18 S180 57P TT)	1				
26	94227-18808	TUBO (2.75-18 TR4) TUBE (2.75-18 TR4)	1				CHENG SHIN CHENG SHIN
27	93900-00826	VALVULA VALVE, RIM	1				

FIG. 27 RUEDA TRASERA REAR WHEEL



1NC1276-L270

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	1NC1				OBSERV. REMARK
28	5VL-F5371-00	BARRA TENSORA BAR, TENSION	1				
29	90109-08847	PERNO BOLT	1				
30	90109-08848	PERNO BOLT	1				
31	95702-08500	TUERCA DE BRIDA NUT, FLANGE	2				
32	91402-20012	CHAVETA PIN, COTTER	2				
33	5VL-F5381-01	EJE DE RUEDA AXLE, WHEEL	1				
34	95602-14200	TUERCA DE AUTO-CIERRE NUT, SELF-LOCKING	1				
35	42D-F5386-00	COLLAR EJE DE RUEDA DENTADA COLLAR, SPROCKET AXLE	1				
36	42D-F5377-00	COLLAR DE RUEDA COLLAR, WHEEL	1				
37	5VL-F5388-01	TIRADOR DE CADENA 1 PULLER, CHAIN 1	2				
38	95312-08600	TUERCA HEXAGONAL NUT	2				
39	90153-08804	TORNILLO HEXAGONAL SCREW, HEXAGON	2				
40	5VL-F53C0-00	CADENA (DID 428 98LL) CHAIN (DID 428 98LL)	1				
41	94668-83001	.CONECTOR DE CADENA (DID 428) .JOINT, CHAIN (DID 428)	1				



STEERING HANDLE & CABLE

www.seacubemoto.com





FIG. 29 CILINDRO MAESTRO DELANTERO FRONT MASTER CYLINDER

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC			OBSERVACIONES REMARKS
1	2B9-W583T-02	CILINDRO MAESTRO COMPLETO MASTER CYLINDER ASSY	1			
2	3D9-W0041-02	.JUEGO DE CILINDRO MAESTRO .CYLINDER KIT, MASTER	1			
3	4KL-F5854-00	.EMPAQUE,DIAFRAGMA .DIAPHRAGM, RESERVOIR	1			
4	4KL-F5852-00	.TAPA DE TANQUE DE RESERVA .CAP, RESERVOIR	1			
5	4KL-F589H-01	.TORNILLO .SCREW	2			
6	5VL-H3922-21	PALANCA 2 LEVER 2	1			
7	3D9-F589F-01	PERNO DE PALANCA BOLT, LEVER	1			
8	3D9-F586F-01	TUERCA AUTOBLOCANTE NUT, U	1			
9	5VL-F5867-00	SOPORTE DE CILINDRO MAESTRO BRACKET, MASTER CYLINDER	1			
10	3D9-F5865-01	RESORTE DE ASIENTO SPRING, SEAT	1			
11	5VL-F5872-11	MANGUERA DE FRENO 1 HOSE, BRAKE 1	1			
12	90401-10811	PERNO DE UNION BOLT, UNION	2			
13	90201-108J9	ARANDELA PLANA WASHER, PLATE	4			
14	5VL-F5887-00	SOPORTE DE MANGUERA FRENO HOLDER, BRAKE HOSE	1			
15	5VL-F5886-00	SOPORTE DE MANGUERA FRENO HOLDER, BRAKE HOSE	1			
16	5VL-F5875-01	SOPORTE DE MANGUERA FRENO 1 HOLDER, BRAKE HOSE 1	1			
17	5VL-F5876-00	SOPORTE DE MANGUERA FRENO 2 HOLDER, BRAKE HOSE 2	1			
18	95022-06016	PERNO, DE BRIDA BOLT, FLANGE	1			
19	95022-06025	PERNO, DE BRIDA BOLT, FLANGE	2			




1NC1276-L300

FIG. 30 SOPORTE & APOYAPIE

STAND & FOOTREST

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	42D-F7111-00	PUNTAL PRINCIPAL STAND, MAIN	1				
2	5VL-F7112-11	EJE DE PUNTAL PRINCIPAL SHAFT, MAIN STAND	1				
3	5VL-F7115-01	CONEXION DE PUNTAL PRINCIPAL LINK, MAIN STAND	1				
4	90506-32800	RESORTE DE TENSION SPRING, TENSION	1				
5	3D9-F7211-00	PEDAL DE FRENO PEDAL, BRAKE	1				
6	90508-40801	RESORTE DE TORSION SPRING, TORSION	1				
7	5VL-F7231-01	VARILLA DE FRENO ROD, BRAKE	1				
8	91402-20012	CHAVETA PIN, COTTER	1				
9	92902-06200	ARANDELA WASHER	2				
10	90501-10806	RESORTE DE COMPRESION SPRING, COMPRESSION	1				
11	90249-12808	PASADOR PIN	1				
12	90179-06826	TUERCA NUT	1				
13	42D-F7411-00	APOYAPIE 1 FOOTREST 1	1				
14	42D-F743H-00	TOPE, 3 STOPPER, 3	1				
15	90119-06869	TORNILLO CON ARANDELA BOLT, WITH WASHER	1				
16	5VL-H2109-00	UNION, TUBO JOINT, HOSE	1				
17	5VL-F7413-00	CUBIERTA DE APOYAPIE COVER, FOOTREST	2				
18	95812-08020	TORNILLO DE REBORDE BOLT, FLANGE	2				
19	90201-08840	ARANDELA PLANA WASHER, PLATE	1				
20	42D-F7311-00	PUNTAL LATERAL STAND, SIDE	1				
21	90506-29800	RESORTE DE TENSION SPRING, TENSION	1				
22	90445-21814	TUBO HOSE	1				
23	90101-10818	TORNILLO BOLT	1				
24	90185-10813	TUERCA AUTOBLOCANTE NUT, SELF-LOCKING	1				
25	1P6-F7313-01	COLLAR COLLAR	1				
26	90201-10831	ARANDELA PLANA WASHER, PLATE	2				
27	42D-F7452-00	SOPORTE, DE APOYAPIE 1 BRACKET, FOOTREST 1	1				




REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
28	42D-F7462-00	SOPORTE, DE APOYAPIE 2 BRACKET, FOOTREST 2	1				
29	95812-08020	TORNILLO DE REBORDE BOLT, FLANGE	1				
30	95812-08025	TORNILLO DE REBORDE BOLT, FLANGE	1				
31	92902-08200	ARANDELA WASHER	2				
32	5VL-F7430-01	APOYAPIE POSTERIOR COMPLETO 1 REAR FOOTREST ASSY 1	1				
33	5VL-F7433-00	.CUBIERTA APOYAPIE TRASERO .COVER, REAR FOOTREST	1				
34	5VL-F7445-01	PLACE 1 PLATE 1	1				
35	5VL-F7440-01	APOYAPIE POSTERIOR COMPLETO 2 REAR FOOTREST ASSY 2	1				
36	5VL-F7444-00	.CUBIERTA APOYAPIE TRASERO .COVER, REAR FOOTREST	1				
37	5VL-F7445-01	PLACE 1 PLATE 1	1				
38	90249-06800	PASADOR PIN	2				
39	92902-06200	ARANDELA WASHER	2				
40	99002-05600	PRESILLA REDONDA CLIP	2				
41	5VL-F7414-00	AMORTIGUADOR DE APOYAPIE DAMPER, FOOTREST	2				



GENERATOR

[illegible]

[illegible]




FIG. 33 LUZ DE DESTELLADOR

FLASHER LIGHT

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	3D9-H3310-10	DESTELLADOR DE LUZ DELANT. FRONT FLASHER LIGHT ASSY 1	1				
2	3D9-H3311-10	.BOMBILLA (12V-10W) .BULB, FLASHER (12V-10W)	1				
3	3D9-H333A-00	.LENTES COMPLETO 1 .LENS COMP 1	1				
4	3D9-H3333-10	.TORNILLO ACCESORIO DE LENTE .SCREW, LENS FITTING	1				
5	3D9-H3320-10	DESTELLADOR DE LUZ DELANT. FRONT FLASHER LIGHT ASSY 2	1				
6	3D9-H3311-10	.BOMBILLA (12V-10W) .BULB, FLASHER (12V-10W)	1				
7	3D9-H334A-00	.LENTES COMPLETO 2 .LENS COMP 2	1				
8	3D9-H3333-10	.TORNILLO ACCESORIO DE LENTE .SCREW, LENS FITTING	1				
9	3D9-H3330-10	DESTELLADOR DE LUZ TRAS.COMPL. REAR FLASHER LIGHT ASSY 1	1				
10	3D9-H3311-10	.BOMBILLA (12V-10W) .BULB, FLASHER (12V-10W)	1				
11	3D9-H334A-00	.LENTES COMPLETO 2 .LENS COMP 2	1				
12	3D9-H3333-10	.TORNILLO ACCESORIO DE LENTE .SCREW, LENS FITTING	1				
13	3D9-H3340-10	DESTELLADOR DE LUZ TRAS.COMPL. REAR FLASHER LIGHT ASSY 2	1				
14	3D9-H3311-10	.BOMBILLA (12V-10W) .BULB, FLASHER (12V-10W)	1				
15	3D9-H333A-00	.LENTES COMPLETO 1 .LENS COMP 1	1				
16	3D9-H3333-10	.TORNILLO ACCESORIO DE LENTE .SCREW, LENS FITTING	1				
17	3D9-H3318-10	SOPORTE DE DESTELLADOR 1 STAY, FLASHER 1	4				




FIG. 34 MEDIDOR

METER

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV REMARK
1	1PX-H3500-00	METRO COMPLETO METER ASSY	1				
2	1PX-H350A-00	.MEDIDOR COMPLETA .METER COMP.	1				
3	18C-H353H-00	.CAJA INFERIOR .CASE, UNDER	1				
4	5VL-H350E-00	.SOPORTE .BRACKET	1				
5	5VL-H3543-00	.AMORTIGUADOR DE SOPORTE .DAMPER, BRACKET	4				
6	18C-H3524-00	.ARANDELA ESPECIAL .WASHER, SPECIAL	4				
7	5VL-H354P-00	.TUERCA .NUT	4				
8	1PX-H3509-00	.ENCASTRE DE CABLE COMPLETO .SOCKET COBD ASSY	1				
9	4FP-H3517-10	.AMPOLLETA (12V-1.7W) .BULB (12V-1.7W)	4				
10	4GU-H3517-10	.AMPOLLETA (14V-3W) .BULB (14V-3W)	4				
11	5VL-H357H-00	.PERILLA .KNOB	1				
12	5VL-H353S-00	.TORNILLO / SCRESORIO DE PERILLA .SCREW, KNOB FITTING	1				
13	95022-06016	PERNO, DE UNIDA BOLT, FLANGE	2				
14	5VL-H3550-12	CABLE DE VELOCIMETRO COMPLETO SPEEDOMETER CABLE ASSY	1				
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-




FIG. 35 FARO DELANTERO

HEADLIGHT

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1			OBSERV REMARK
1	5VL-H4300-23	FARO DELANTERO COMPLETO HEADLIGHT ASSY	1			
2	5VL-H4314-20	.BOMBILLA (12V-35/35W) .BULB, HEADLIGHT (12V-35/35W)	1			
3	5VL-H4347-10	.BOMBILLA (12V-5W) .BULB (12V-5W)	1			
4	5VL-H4310-22	.UNIDAD DE FARO DELANTERO COMPL .HEADLIGHT UNIT ASSY	1			
5	5VL-H4315-21	.ARO DE FARO DELANTERO .RIM, HEADLIGHT	1			
-	6	5VL-H4312-10 .CABLE COMPLETA .CORD ASSY	1			
7	5VL-H4159-10	.CABLE DE FARO DELANTERO .CORD, HEADLIGHT	1			
8	5VL-H4526-00	.TORNILLO .SCREW	2			
9	5VL-H4330-22	.CUERPO COMPLETO .BODY ASSY	1			
10	5VL-H4145-00	..COLLAR ACCESORIO DE CUERPO ..COLLAR, BODY FITTING	2			
-	11	5VL-H4163-00 ..AMORTIGUADOR ..DAMPER	2			
12	5VL-H4164-00	..AMORTIGUADOR ..DAMPER	2			
13	95023-08030	TORNILLO BOLT	2			
14	90201-08830	ARANDELA PLANA WASHER, PLATE	2			
15	95302-08800	TUERCA NUT, CROWN	2			
-						
-						
-						
-						

TAILLIGHT


18C1415-H430



1NC1276-L370

FIG. 37 INTERRUPTOR DE MANILLAR&PALANC HANDLE SWITCH & LEVER

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC				OBSERV REMARK
1	90123-08813	PERNO BOLT	1				
2	90179-08862	TUERCA NUT	1				
3	5VL-H3980-01	INTERRUP. DE PARADA DELANTERO FRONT STOP SWITCH ASSY	1				
4	5VL-H3973-01	INTERRUPTOR DE MANIJA 3 SWITCH, HANDLE 3	1				
5	98507-05043	.TORNILLO DE CABEZA PLANA .SCREW, PAN HEAD	1				
6	98507-05025	.TORNILLO DE CABEZA PLANA .SCREW, PAN HEAD	1				
7	42D-H3976-00	INTERRUPTOR DE MANIJA 1 SWITCH, HANDLE 1	1				
8	98507-05030	.TORNILLO DE CABEZA PLANA .SCREW, PAN HEAD	1				
9	98507-05050	.TORNILLO DE CABEZA PLANA .SCREW, PAN HEAD	1				
10	4FP-H2911-00	SOPORTE DE LEVA 1 HOLDER, LEVER 1	1				
11	5VL-H3912-00	PALANCA 1 LEVER 1	1				
12	90109-06850	PERNO BOLT	1				
13	95602-06100	TUERCA U NUT, U	1				
14	97590-06522	PERNO CON ARANDELA BOLT, WITH WASHER	1				
15	5VL-H2917-11	INTERRUPTOR SWITCH	1				
16	90464-70801	BRIDA CLAMP	1				
17	4TU-H3936-00	BANDA DE CABLE DE INTERRUPTOR BAND, SWITCH CORD	2				



1NC1276-L380


FIG. 38 EQUIPO ELECTRICO 1

ELECTRICAL 1

REF. Nº	CODIGO Nº PART NO.	DESCRIPCION DESCRIPTION	INC1				OBSERV RE MARK
1	5VL-H2100-00	BATERIA COMPLETA (CB5L-B) BATTERY ASSY (CB5L-B)	1				
2	90445-08830	TUBO HOSE	1				
3	5VL-H2131-01	TIRANTE DE BATERIA BAND, BATTERY	1				
4	5VL-H2115-00	CABLE CONDUCTOR POSITIVO WIRE, PLUS LEAD	1				
5	5VL-H2116-00	CABLE CONDUCTOR NEGATIVO WIRE, MINUS LEAD	1				
6	2D0-H1960-00	RECTIFICADOR Y REGULADOR RECTIFIER & REGULATOR ASSY	1				
7	95802-06020	TORNILLO DE REBORDE BOLT, FLANGE	2				
8	5VL-H1940-01	CONJUNTO ARRANCADOR RELEVO STARTER RELAY ASSY	1				
9	4FP-H2151-00	.FUSIBLE (15A) .FUSE (15A)	2				
10	95302-06600	TUERCA NUT	2				
11	90201-068C2	ARANDELA PLANA WASHER, PLATE	2				
12	1NC-H2021-00	JUEGO DE LLAVE KEY SET	1				
13	1NC-H2501-00	.LLAVE DE IGNICION COMPLT .MAIN SWITCH STEERING LOCK	1				
14	5VL-F4610-02	.TAPA COMPLETA .CAP ASSY	1				
15	5VL-F1780-01	.CERRADURA COMPLETA .LOCK ASSY	1				
16	91312-06020	TORNILLO BOLT	2				
17	90201-068C2	ARANDELA PLANA WASHER, PLATE	2				
18	3S9-H2530-01	INTERRUPTOR DE PARADA COMPLETO STOP SWITCH ASSY	1				
19	1NC-H2590-00	CONJUNTO DE CABLES WIRE HARNESS ASSY	1				
20	5VL-H1980-10	.CONJUNTO DIODO .DIODE ASSY	1				
21	90464-35820	BRIDA CLAMP	3				
22	5VL-H3936-00	BANDA DE CABLE DE INTERRUPTOR BAND, SWITCH CORD	1				
23	90464-35820	BRIDA CLAMP	2				
24	18C-H5752-01	UNIDAD TRANSM. MED. COMBUST. SENDER UNIT ASSY, FUEL METER	1				
25	4FP-H5753-00	EMPAQUE DE UNIDAD TRANSMISORA GASKET, SENDER UNIT	1				
26	90119-05022	TORNILLO CON ARANDELA BOLT, WITH WASHER	4				

ELECTRICAL 2

www.seaclubmoto.com



INDICE NUMERICO
NUMERICAL INDEX

CODIGO Nº PART NO.	REF. Nº	CODIGO Nº PART NO.	REF. Nº	CODIGO Nº PART NO.	REF. Nº	CODIGO Nº PART NO.	REF. Nº	CODIGO Nº PART NO.	REF. Nº	CODIGO Nº PART NO.	REF. Nº
90506-29800	30 - 21	93306-202Y4	25 - 3	95602-14200	25 - 12	99530-10114	9 - 2				
90506-32800	30 - 4		27 - 3		27 - 34		9 - 10				
90508-16800	13 - 23	93306-203YT	14 - 9	95702-08500	27 - 31		10 - 3				
90508-26836	11 - 5	93306-204YD	14 - 24	95802-06012	23 - 36		10 - 16				
90508-32801	16 - 5	93306-205XJ	2 - 10	95802-06020	4 - 14						
90508-40801	30 - 6	93306-252X5	27 - 4		23 - 38						
90560-15293	25 - 2	93310-629Y3	2 - 4		38 - 7						
91312-05010	14 - 29	93410-20809	14 - 7	95812-08020	8 - 14						
91312-06012	4 - 6		14 - 18		24 - 13						
91312-06014	31 - 4	93440-10109	1 - 4		30 - 18						
91312-06020	8 - 13	93450-16812	2 - 13		30 - 29						
	38 - 16	93503-16824	13 - 20	95812-08025	30 - 30						
91312-06025	6 - 3	93604-10837	15 - 3	95812-10080	17 - 3						
	31 - 3	93608-30839	16 - 8	95822-06012	21 - 19						
91312-06090	1 - 18	93822-14813	14 - 27	95822-06016	21 - 16						
91312-08016	12 - 8	93900-00826	27 - 27	95822-06020	18 - 5						
91402-20012	27 - 32	94109-18816	27 - 25	97002-05012	21 - 22						
	30 - 8	94127-18848	25 - 5	97002-08016	23 - 11						
92902-06200	13 - 15	94227-18808	25 - 6	97022-06020	16 - 11						
	30 - 9		27 - 26	97590-06522	37 - 14						
	30 - 39	94568-C1088	4 - 10	97602-06220	6 - 13						
92902-08200	30 - 31	94668-83001	27 - 41	97702-50016	23 - 35						
92990-06200	8 - 11	94700-00869	1 - 15	9770N-50012	24 - 8						
93101-10800	10 - 21	95022-06016	4 - 17	97801-04010	7 - 13						
93101-12812	16 - 4		29 - 18	97880-03008	23 - 14						
93102-12802	13 - 24		34 - 13	98502-05010	28 - 5						
93102-20854	14 - 25		39 - 2	98507-05025	37 - 6						
93102-20857	25 - 4	95022-06020	1 - 10	98507-05030	37 - 8						
93104-22802	27 - 5	95022-06025	29 - 19	98507-05043	37 - 5						
93106-26804	27 - 19		32 - 8	98507-05050	37 - 9						
93109-18802	20 - 5	95022-06030	9 - 7	98512-06010	10 - 11						
93109-20806	11 - 13	95022-06035	10 - 4	98512-06012	12 - 4						
93210-11800	2 - 9		10 - 17		14 - 11						
93210-14899	10 - 7	95022-06045	9 - 8	98902-05008	32 - 6						
93210-19809	10 - 20		10 - 18	98902-06016	10 - 13						
93210-30611	6 - 2	95022-06050	10 - 5	98980-06012	8 - 5						
93210-328A4	10 - 9	95022-06055	9 - 9	98980-06014	8 - 8						
93210-42807	27 - 6	95022-08035	21 - 14		8 - 10						
93210-44889	1 - 12	95022-08040	21 - 10	99002-05600	5 - 3						
93210-55669	32 - 3	95023-08030	35 - 13		30 - 40						
93210-57897	1 - 21	95302-06600	13 - 16	99002-10600	16 - 6						
93210-71801	1 - 9		27 - 15	99009-15400	11 - 9						
93306-002YU	4 - 3		38 - 10		14 - 22						
93306-003X6	4 - 2	95302-08800	35 - 15	99009-20500	13 - 25						
93306-004YL	27 - 18	95312-08600	27 - 38	99234-00080	24 - 7						
93306-201Y8	14 - 8	95602-05100	39 - 12	99236-00100	23 - 26						
93306-202XN	2 - 15	95602-06100	37 - 13		23 - 31						
93306-202XP	14 - 26	95602-12200	20 - 8	99530-10114	1 - 17						

www.seacubemoto.com