




PARTS CATALOGUE

www.seacubemoto.com

YD110 (1DE8)



1R1DE-600EA

()

2016/4/21

NEWS NO.	DATE	COMMENT
PE0-MC-150094	Nov.,10,2015	COR:FIG.31 HEADLIGHT LIST CORRECTION
PE0-MC-160034	Apr.,18,2016	MOD:FIG.6 INTAKE LIST/ILLUSTRATION REVISION

www.seacubemoto.com

YD110
PARTS CATALOGUE
©2015 by Yamaha Motor Co., Ltd.
1st edition, June 2015
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

www.seacubemoto.com





FOREWORD

7. Applicable Serial No.

Frame Serial No.

Engine Serial No.



8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
CNM(*)	CANDY MAROON	00H6
YB(*)	YAMAHA BLACK	0033

9. Applicable Starting Serial No.

Frame Serial No.

Serial No.	Name Of Q'ty Column	Model Code

Engine Serial No.

Serial No.	Name Of Q'ty Column	Model Code

www.seacubemoto.com

CONTENTS

ENGINE

- CYLINDER 1
- CRANKSHAFT & PISTON 2
- VALVE 3
- CAMSHAFT & CHAIN 4
- OIL PUMP 5
- INTAKE 6
- CARBURETOR 7
- EXHAUST 8
- CRANKCASE 9
- CRANKCASE COVER 1 10
- STARTER 11
- CLUTCH 12
- TRANSMISSION 13
- SHIFT CAM & FORK 15
- SHIFT SHAFT 16

CHASSIS

- FRAME 17
- FENDER 18
- SIDE COVER 19
- REAR ARM & SUSPENSION 20
- STEERING 21
- FRONT FORK 22
- FUEL TANK 24
- SEAT 25
- FRONT WHEEL 26
- REAR WHEEL 28
- STEERING HANDLE & CABLE 30
- STAND & FOOTREST 31
- GENERATOR 33
- FLASHER LIGHT 34
- METER 35
- HEADLIGHT 36
- TAILLIGHT 37
- HANDLE SWITCH & LEVER 38
- ELECTRICAL 1 39
- ELECTRICAL 2 40

INDEX

- NUMERICAL INDEX 41

www.seacubemoto.com








FIG. 3 VALVE

www.seacubemoto.com



FIG. 4 CAMSHAFT & CHAIN

www.seacibemoto.com



www.seacubemoto.com

5




FIG. 6 INTAKE

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5KA-E3586-10	JOINT, CARBURETOR 1	1				
2	4LS-E3569-00	PLUG, BLIND	1				
3	90467-10819	CLIP	1				
4	93210-32801	O-RING	1				
5	5KA-E3595-02	JOINT	1				
6	93210-27800	O-RING	1				
7	90105-06868	BOLT, FLANGE	4				
8	5KA-E4411-20	CASE, AIR CLEANER 1	1				
9	5KA-E4412-00	CAP, CLEANER CASE 1	1				
10	5KA-E4450-10	ELEMENT ASSY, AIR CLEANER	1				
12	5DG-E4451-00	.ELEMENT, AIR CLEANER	1				
13	5DG-E4461-00	.ELEMENT, AIR CLEANER 2	1				
14	5KA-E4453-00	JOINT, AIR CLEANER 1	1				
15	5DG-E4487-00	SPRING	1				
16	4LS-E4462-00	SEAL	1				
17	97607-06225	SCREW, WITH WASHER	3				
18	4LS-E443E-00	PIPE, DRAIN	1				
19	90467-11106	CLIP	1				
20	5KA-E447F-00	ELEMENT 3	1				
21	5TS-E443E-00	PIPE, DRAIN	1				
22	90467-15012	CLIP	1				
23	90119-06108	BOLT, WITH WASHER	2				
24	90387-066K1	COLLAR	2				
25	90460-43053	CLAMP, HOSE	1				





FIG. 7 CARBURETOR

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5KA-E4101-10	CARBURETOR ASSY 1	1				
2	5KA-1490J-20	.NEEDLE SET	1				
3	5KA-14131-00	.SPRING, THROTTLE VALVE	1				
4	5KA-14106-00	.CABLE ADJUST SCREW SET	1				
5	4LS-14198-00	.GASKET	1				
6	5KA-14112-30	.VALVE, THROTTLE 1	1				
7	5HH-14103-00	.THROTTLE SCREW SET	1				
8	4TL-14191-00	.PLUG, DRAIN	1				
9	5KA-14239-00	.SEAL	1				
10	5KA-1414G-10	.PIPE, MAIN BLEED	1				
11	5KA-14142-20	.JET, PILOT (# 20)	1				
12	5KA-1414A-69	.JET, MAIN (# 2.5)	1				
13	5HH-14185-00	.FLOAT	1				
14	5KA-14150-00	.NEEDLE ASSY	1				
15	127-14186-00	.PIN, FLOAT	1				
16	5KA-14197-00	.PIPE	1				
17	97607-04114	.SCREW, WITH WASHER	4				
18	3TU-14193-00	.PIPE	1				
19	5KA-14181-00	.BODY, FLOAT CHAMBER 1	1				
20	5KA-14158-00	.TOP, MIXING CHAMBER	1				
21	5KA-WF141-00	.STARTER ASSY 1	1				
22	241-14147-00	.O-RING	1				
23	5KA-14104-00	.AIR SCREW SET	1				
24	5KA-14141-13	.NOZZLE, MAIN	1				
25	5KA-14139-00	.CLIP, PIPE	1				

FIG. 8 EXHAUST

[illegible]

1DE4600-N080






FIG. 10 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5TS-E5411-00	COVER, CRANKCASE 1	1				
2	5YY-E5451-00	GASKET, CRANKCASE COVER 1	1				
3	91830-21014	PIN, DOWEL	2				
4	95027-06035	BOLT, FLANGE	1				
5	95027-06045	BOLT, FLANGE	6				
6	90340-14814	PLUG, STRAIGHT SCREW	1				
7	93210-14899	O-RING	1				UR
	93210-14812	O-RING	1				UR
8	90340-32808	PLUG, STRAIGHT SCREW	1				
9	93210-328A4	O-RING	1				UR
	93210-32813	O-RING	1				UR
10	5KA-E5191-20	PLATE	1				
11	98507-06010	SCREW, PAN HEAD	1				
12	5DG-E5418-01	COVER, CHAIN CASE	1				
13	98907-06016	SCREW, BIND	2				
14	5TS-E5421-10	COVER, CRANKCASE 2	1				
15	5YY-E5461-01	GASKET, CRANKCASE COVER 2	1				
16	91830-21014	PIN, DOWEL	2				
17	95027-06035	BOLT, FLANGE	7				
18	95027-06045	BOLT, FLANGE	2				
19	4LS-E5362-00	PLUG, OIL LEVEL	1				
20	93210-19809	O-RING	1				
21	93101-10838	OIL SEAL	1				UR
	93101-10805	OIL SEAL	1				UR

15D2200-F110

FIG. 11 STARTER

REF. NO.	PART NO.	DESCRIPTION	1DE8				REMARK
1	5US-E5661-03	AXLE, KICK	1				
2	5YY-E5641-00	GEAR, KICK (28T)	1				
3	90468-26048	CLIP	1				
4	90201-202L3	WASHER, PLATE (0.5T)	2				
5	5YY-E5671-00	WHEEL, RATCHET	1				
6	90508-26667	SPRING, TORSION	1				
7	5KA-E5666-00	SPACER	1				
8	5TS-E5651-00	GEAR, KICK IDLE	1				
9	90201-177G4	WASHER, PLATE	2				
10	99009-17400	CIRCLIP	1				
11	5KA-E5620-10	KICK CRANK ASSY	1				
12	5US-E5621-00	.BOSS, KICK CRANK	1				
13	90501-12081	.SPRING, COMPRESSION	1				
14	93507-32819	.BALL	1				
15	90201-15809	.WASHER, PLATE	1				
16	99001-10600	.CIRCLIP	1				
17	36L-E5618-00	.COVER, KICK LEVER	1				
18	90179-12802	NUT	1				
19	93109-20821	OIL SEAL	1				




FIG. 12 CLUTCH

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5TS-E6111-10	GEAR, PRIMARY DRIVE	1				
2	90282-05001	KEY, STRAIGHT (5MMX16MM)	1				
3	90201-122H1	WASHER, PLATE	1				
4	90179-12800	NUT	1				
5	5KA-E6150-10	PRIMARY DRIVEN GEAR COMP.	1				
6	5KA-E6371-10	BOSS, CLUTCH	1				
7	5KA-E6321-10	PLATE, FRICTION	5				
8	5RE-E6324-10	PLATE, CLUTCH 1	4				
9	5RE-E6351-00	PLATE, PRESSURE 1	1				
10	90501-216A6	SPRING, COMPRESSION	4				
11	90119-05801	BOLT, WITH WASHER	4				
12	4LS-E6358-00	PLATE, PUSH 1	1				
13	4LS-E6356-00	ROD, PUSH 1	1				
14	92907-06200	WASHER	1				
15	95307-06600	NUT	1				
16	5YY-E6154-00	PLATE, THRUST 1	1				
17	90215-12815	WASHER, LOCK	1				
18	90170-12060	NUT	1				
19	93503-16807	BALL	1				
20	4LS-E6357-01	ROD, PUSH 2	1				
21	4LS-E6381-20	PUSH LEVER COMP.	1				
22	90508-14857	SPRING, TORSION	1				
23	93102-12877	OIL SEAL	1				
24	99009-20500	CIRCLIP	1				




FIG. 13 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5TS-E7411-00	AXLE, MAIN (11T)	1				
2	5TS-E7131-10	GEAR, 3RD PINION (20T)	1				
3	90209-17285	WASHER	1				
4	93410-20809	CIRCLIP	1				
5	5TS-E7121-10	GEAR, 2ND PINION (16T)	1				
6	5TS-E7141-20	GEAR, 4TH PINION (24T)	1				
7	90201-127E1	WASHER, PLATE	1				
8	93306-201YE	BEARING	1				UR
	93306-201Y4	BEARING	1				UR
9	93306-253Y8	BEARING	1				UR
	93306-203X2	BEARING	1				UR
10	4LS-E7471-00	PLATE, COVER	1				
11	98502-06014	SCREW, PAN HEAD	2				
12	5TS-WE740-30	DRIVE AXLE ASSY	1				
13	5TS-E7221-10	GEAR, 2ND WHEEL (27T)	1				
14	90209-18208	WASHER	1				
15	93410-22039	CIRCLIP	1				
16	5TS-E7231-10	GEAR, 3RD WHEEL (24T)	1				
17	5TS-E7211-10	GEAR, 1ST WHEEL (33T)	1				
18	90201-177G4	WASHER, PLATE	2				
19	5RE-E7258-00	COLLAR 1	1				
20	93306-204XG	BEARING	1				UR
	93306-204Y6	BEARING	1				UR
21	93102-20876	OIL SEAL	1				
22	93306-253Y7	BEARING	1				UR
	93306-203X9	BEARING	1				UR
23	93812-14823	SPROCKET, DRIVE (14T)	1				



This exploded view diagram illustrates the assembly of a mechanical component, likely a motor or actuator. The parts are numbered as follows:

- 1:** The main cylindrical body or motor housing, shown at the bottom right.
- 2:** A gear or sprocket with four teeth, positioned to be mounted onto the shaft of part 1.
- 3:** A small pin or bush, shown inserted into the gear (2) and the main body (1).
- 4:** A screw or bolt, shown positioned to secure the gear (2) to the main body (1).
- 5:** A bracket or lever arm, shown positioned to be mounted onto the side of the main body (1).
- 6:** A second bracket or lever arm, shown positioned to be mounted onto the side of the main body (1).
- 7:** A long cylindrical rod or shaft, shown positioned to pass through the brackets (5 and 6) and the main body (1).
- 8:** A shorter cylindrical rod or shaft, shown positioned to pass through the brackets (5 and 6).

Thin lines indicate the alignment and assembly path for each component.

www.seacubemoto.com





www.seacubemoto.com




FIG. 16 FRAME

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5KA-F1110-31	FRAME COMP.	1				
2	5DG-F1316-00	STAY, ENGINE 2	1				
3	90105-08809	BOLT, FLANGE	2				
4	90105-088A6	BOLT, FLANGE	2				
5	95707-08500	NUT, FLANGE	4				
6	5KA-F1318-00	STAY, ENGINE 4	1				
7	90105-08809	BOLT, FLANGE	2				
8	90105-08002	BOLT, FLANGE	1				
9	90201-08808	WASHER, PLATE	1				
10	95707-08500	NUT, FLANGE	3				
11	90105-08006	BOLT, FLANGE	1				
12	90105-08007	BOLT, FLANGE	1				
13	95707-08500	NUT, FLANGE	2				
14	1DE-F1298-00	PROTECTOR, FOOT REST	1				
15	1DE-F1299-00	PROTECTOR, FOOT REST 2	1				
16	9580N-08020	BOLT, FLANGE	3				
17	5KA-F8418-00	GUARD, ENGINE 1	1				
18	5KA-F8436-00	BRACKET 2	2				
19	5TS-F8415-00	DAMPER 1	2				
20	9580N-08014	BOLT, FLANGE	2				
21	9580N-08040	BOLT, FLANGE	2				
22	9570N-08500	NUT, FLANGE	4				
23	90338-18122	PLUG	2				
24	5KA-F8100-30	TOOL KIT	1				





FIG. 17 FENDER

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARKS
1	5KA-F1510-01	FRONT FENDER COMP.	1				
2	9580N-06016	BOLT, FLANGE	4				
3	5RE-F1518-00	HOLDER, CABLE	1				
4	36L-F1521-00	FLAP, FRONT FENDER	1				
5	90201-05725	WASHER, PLATE	2				
6	97607-05212	SCREW, WITH WASHER	2				
7	9530N-05600	NUT	2				
8	5DG-F1611-03	FENDER, REAR	1				
9	90464-10829	CLAMP	2				
10	90119-06848	BOLT, WITH WASHER	1				
11	5TS-F1685-00	BRACKET, LICENSE	1				
12	90119-06108	BOLT, WITH WASHER	4				
13	5KA-F177F-10	COVER	1				
14	5DG-F1621-00	FLAP	1				
15	5DG-F1575-00	SEAL 1	2				

FIG. 18 SIDE COVER



REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	90480-13861	GROMMET	2				
2	5DG-F1778-00	DAMPER, LOCATING 1	2				
3	5KA-F8490-01	LOCK ASSY 2	1				
4	36L-H398X-00	WASHER, PLATE	1				
5	5KA-F176V-00	SPRING, LOCK 2	1				
6	5KA-F1717-00	DAMPER	1				
7	90119-06843	BOLT, WITH WASHER	1				
8	5DG-F177G-00	BOX, BATTERY	1				
9	5DG-F177E-00	LID	1				
10	5KA-F179E-00	BAND	1				
11	5KA-F1747-00	DAMPER	2				
12	90119-06108	BOLT, WITH WASHER	2				
13	5KA-XF171-C0-1X	COVER, SIDE 1	1				UR FOR YB
	5KA-XF171-D0-5X	COVER, SIDE 1	1				UR FOR CNM
14	5KA-F173E-C0	.GRAPHIC 1	1				UR FOR YB
	5KA-F173E-D0	.GRAPHIC 1	1				UR FOR CNM
15	5KA-XF172-C0-1X	COVER, SIDE 2	1				UR FOR YB
	5KA-XF172-D0-5X	COVER, SIDE 2	1				UR FOR CNM
16	5KA-F173F-C0	.GRAPHIC 2	1				UR FOR YB
	5KA-F173F-D0	.GRAPHIC 2	1				UR FOR CNM



REF. NO.	PART NO.	DESCRIPTION	IDEB				REMARK
1	5KA-WF211-30	REAR ARM COMP.	1				
2	36L-F2123-00	.BUSH 1	2				
3	4LS-F2141-00	SHAFT, PIVOT	1				
4	90170-12065	NUT	1				
5	92907-12200	WASHER	1				
6	4LS-F2151-00	SEAL, GUARD	1				
7	5KA-F2310-11	CHAIN CASE ASSY	1				
8	90159-06843	SCREW, WITH WASHER	2				
9	90159-06844	SCREW, WITH WASHER	2				
10	36L-F2315-00	CAP	1				
11	34C-F2210-00	SHOCK ABSORBER ASSY, REAR	2				
12	90201-10052	WASHER, PLATE	2				
13	90176-10073	NUT, CROWN	4				
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-
-	-	-	-	-	-	-	-




FIG. 20 STEERING

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5KA-F3412-00	RACE, BALL 2	1				
2	5KA-F3413-00	RACE, BALL 3	1				
3	5KA-F3414-00	RACE, BALL 4	1				
4	4LS-F341E-10	RETAINER, BALL BEARING	1				
5	4LS-F341E-00	RETAINER, BALL BEARING	1				
6	5YY-F3416-00	COVER, BALL RACE 2	1				
7	90179-25002	NUT	2				
8	4LS-F3418-00	WASHER, SPECIAL	1				
9	90202-26142	WASHER, PLATE	1				
10	5KA-F3448-10	SPACER	1				
11	5KA-F3435-10	CROWN, HANDLE	1				
12	90101-10802	BOLT	1				
13	90209-10160	WASHER	1				
14	5TS-F3441-10	HOLDER, HANDLE UPPER	2				
15	5TS-F3442-00	HOLDER, HANDLE LOWER	2				
16	5KA-F3174-10	STAY, HEADLIGHT	1				
17	9582N-06016	BOLT, FLANGE	2				
18	4LS-F317J-00	DAMPER 1	2				
19	5KA-F3466-01	CLAMP	1				
20	9580N-06016	BOLT, FLANGE	1				
21	5KA-F3395-00	EMBLEM	1				
22	90159-05065	SCREW, WITH WASHER	2				
23	95022-08055	BOLT, FLANGE	4				




FIG. 21 FRONT FORK

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5KA-F3100-60	FRONT FORK ASSY	1				
2	5KA-F3102-60	..FRONT FORK ASSY (L.H)	1				
3	5KA-F3126-60	..TUBE, OUTER (L.H)	1				
4	35B-F3110-10	..INNER TUBE COMP.1	1				
5	5KA-F3170-10	..CYLINDER COMP., FRONT FORK	1				
6	35B-F3157-00	..RING, PISTON	1				
7	35B-F3173-00	..SPINDLE, TAPER	1				
8	35B-F3151-00	..SPRING, REBOUND	1				
9	35B-F3158-00	..GASKET	1				
10	35B-F3181-00	..BOLT, HEXAGON SOCKET HEAD	1				
11	35B-F3145-00	..OIL SEAL	1				
12	35B-F3156-00	..RING, SNAP	1				
13	35B-F3144-00	..SEAL, DUST	1				
14	5KA-F3141-20	..SPRING, FRONT FORK	1				
15	35B-F3114-00	..GASKET	1				
16	5TS-F3154-50	..CAP	1				
17	5KA-F3118-00	..SPACER	1				
18	35B-F3149-00	..WASHER, SPRING UPPER	1				
19	5TS-F3111-50	..BOLT, CAP	1				
20	5KA-F3103-60	..FRONT FORK ASSY (R.H)	1				
21	5KA-F3136-60	..TUBE, OUTER	1				
22	35B-F3110-10	..INNER TUBE COMP.1	1				
23	5KA-F3170-10	..CYLINDER COMP., FRONT FORK	1				
24	35B-F3157-00	..RING, PISTON	1				
25	35B-F3173-00	..SPINDLE, TAPER	1				
26	35B-F3151-00	..SPRING, REBOUND	1				
27	35B-F3158-00	..GASKET	1				




FIG. 21 FRONT FORK


REF. NO.	PART NO.	DESCRIPTION	1DE8				REMARK
28	35B-F3181-00	..BOLT, HEXAGON SOCKET HEAD	1				
29	35B-F3145-00	..OIL SEAL	1				
30	35B-F3156-00	..RING, SNAP	1				
31	35B-F3144-00	..SEAL, DUST	1				
32	5KA-F3141-20	..SPRING, FRONT FORK	1				
33	35B-F3114-00	..GASKET	1				
34	5TS-F3154-00	..CAP	1				
35	5KA-F3118-00	..SPACER	1				
36	35B-F3149-00	..WASHER, SPRING UPPER	1				
37	5TS-F3111-50	..BOLT, CAP	1				
38	5KA-F3340-10	..UNDER BRACKET COMP.	1				
39	35B-F3346-00	..BOLT 1	2				
40	35B-F3159-00	..WASHER, SPRING, LOWER	2				
41	5KA-F3411-00	..RACE, BALL	1				
42	35B-F3392-00	..WASHER, SPECIAL	1				
43	5YY-F3462-00	..SEAL, DUST	1				



REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5KA-XF41A-30-33	FUEL TANK COMP.	1				UR FOR YB
	5KA-XF41A-40-H6	FUEL TANK COMP.	1				UR FOR CNM
2	5KA-F4246-00	.GRAPHIC 3	2				UR FOR YB
	5KA-F4246-10	.GRAPHIC 3	2				UR FOR CNM
3	5KA-F4244-00	.GRAPHIC, FUEL TANK 1	1				UR FOR YB
	5KA-F4244-10	.GRAPHIC, FUEL TANK 1	1				UR FOR CNM
4	5KA-F4245-00	.GRAPHIC, FUEL TANK 2	1				UR FOR YB
	5KA-F4245-10	.GRAPHIC, FUEL TANK 2	1				UR FOR CNM
5	4UU-F4181-01	DAMPER, LOCATING 1	2				
6	4LS-F4183-00	DAMPER, LOCATING 3	1				
7	4UU-F4183-01	DAMPER, LOCATING 3	1				
8	4UU-F4186-00	WASHER, SPECIAL	1				
9	9700N-08030	BOLT	1				
10	4LS-F4500-03	FUEL COCK ASSY 1	1				
11	90157-06801	SCREW, PAN HEAD	2				
12	90202-05807	WASHER, PLATE	2				
13	4UU-F4650-01	CAP ASSY	1				
14	98507-05010	SCREW, PAN HEAD	2				
15	90445-10806	HOSE	1				
16	90467-09006	CLIP	2				

FIG. 24 FRONT WHEEL

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5TR-F5111-00	HUB, FRONT	1				
2	36L-F5116-00	FLANGE, SPACER 2	1				
3	93306-301XN	BEARING	2				UR
	93306-301XX	BEARING	2				UR
4	93102-18802	OIL SEAL	1				
5	5US-F5395-00	NIPPLE, SPOKE	36				
6	5US-F5196-00	SPOKE, INNER 1	18				
7	5US-F5197-00	SPOKE, OUTER 1	18				
8	5US-F5144-00	RIM (1.60-18)	1				
9	94125-18807	TIRE (2.50-18)	1				FALCON
10	94227-18803	TUBE (2.75-18)	1				FALCON
11	94325-18822	BAND, RIM (2.50-18)	1				
12	36L-F5121-10	PLATE, BRAKE SHOE	1				
13	5YY-F5351-00	CAMSHAFT	1				
14	36L-F513A-00	PLATE, INDICATOR	1				
15	36L-F5155-00	LEVER, CAMSHAFT 1	1				
16	90101-06814	BOLT	1				
17	9530N-06600	NUT, HEX	1				
18	5YY-WF533-00	BRAKE SHOE KIT	1				
19	90506-15001	SPRING, TENSION	1				
20	90506-12001	SPRING, TENSION	1				
21	90201-20269	WASHER, PLATE	2				
22	36L-F5135-11	GEAR, DRIVE	1				
23	93410-20808	CIRCLIP	1				
24	93105-47801	OIL SEAL	1				
25	36L-F5138-11	GEAR, METER	1				
26	90201-07076	WASHER, PLATE	1				




1DE1600-H240



www.seacubemoto.com

[illegible]



1DE2600-L250

FIG. 25 REAR WHEEL

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5TR-F5311-00	HUB, REAR	1				
2	5YY-F510B-00	SPACER ASSY	1				
3	93306-252YH	BEARING	1				
4	93306-252YH	BEARING	1				
5	93104-22805	OIL SEAL	1				
6	93210-42807	O-RING	1				
7	4LS-F5364-00	DAMPER	4				
8	5US-F5395-00	NIPPLE, SPOKE	36				
9	5US-F5196-00	SPOKE, INNER 1	18				
10	5US-F5197-00	SPOKE, OUTER 1	18				
11	5US-F5144-00	RIM (1.60-18)	1				
12	94127-18826	TIRE (2.75-18 SPR)	1				FALCON
13	94227-18803	TUBE (2.75-18)	1				FALCON
14	94325-18822	BAND, RIM (2.50-18)	1				
15	5US-F5321-00	PLATE, BRAKE SHOE	1				
16	5YY-WF533-00	BRAKE SHOE KIT	1				
17	90506-12001	SPRING, TENSION	1				
18	90506-15001	SPRING, TENSION	1				
19	5YY-F5351-00	CAMSHAFT	1				
20	4LS-F5355-00	LEVER, CAMSHAFT	1				
21	90101-06814	BOLT	1				
22	9530N-06600	NUT, HEX	1				
23	36L-F533A-00	PLATE, INDICATOR	1				
24	36L-F5366-10	CLUTCH, HUB	1				
25	93420-42801	CIRCLIP	1				
26	93306-054Y5	BEARING	1				
27	93106-26801	OIL SEAL	1				





FIG. 25 REAR WHEEL

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
28	5KA-F5387-00	AXLE, SPROCKET	1				
29	1DE-F5444-00	SPROCKET, DRIVEN (44T)	1				
30	90109-08864	BOLT	4				
31	36L-F5412-00	WASHER	2				
32	90179-08816	NUT	4				
33	4LS-F5371-00	BAR, TENSION	1				
34	90109-08831	BOLT	1				
35	90109-08063	BOLT	1				
36	9290N-08100	WASHER, SPRING	2				
37	95307-08600	NUT	1				
38	95307-08700	NUT	1				
39	90468-12007	CLIP	2				
40	36L-F5389-00	PULLER, CHAIN 2	2				
41	90153-08011	SCREW, HEXAGON	2				
42	95307-08700	NUT	2				
43	5KA-F5381-00	AXLE, WHEEL	1				
44	5KA-F5376-00	COLLAR, WHEEL	1				
45	5KA-F5377-00	COLLAR, WHEEL	1				
46	90171-14800	NUT, CASTLE	1				
47	90252-55800	PIN, COTTER	1				
48	94568-E3112	CHAIN (J 420 112L)	1				



REF. NO.	PART NO.	DESCRIPTION	1DE8				REMARK
1	1DE-F6111-00	HANDLEBAR	1				
2	5KA-F6311-10	CABLE, THROTTLE 1	1				
3	5KA-F6335-11	CABLE, CLUTCH	1				
4	5TS-F6372-00	COVER, HANDLE LEVER 1	1				
5	5KA-F6341-22	WIRE, BRAKE 1	1				
6	5TS-F6372-00	COVER, HANDLE LEVER 1	1				
7	90123-06010	BOLT	1				
8	90179-06143	NUT	1				
9	4UU-F6241-00	GRIP	1				
10	5KA-F6240-00	GRIP ASSY	1				
11	4UU-F6242-00	GRIP (RIGHT)	1				
12	36L-F6281-10	CAP, GRIP UPPER	1				
13	5KA-F6282-10	CAP, GRIP UNDER	1				
14	90157-05116	SCREW, PAN HEAD	2				
15	5YY-F6280-00	REAR VIEW MIRROR ASSY (LEFT)	1				
16	5YY-F6290-00	REAR VIEW MIRROR ASSY (RIGHT)	1				




FIG. 27 STAND & FOOTREST

REF. NO.	PART NO.	DESCRIPTION	IDE8				REMARK
1	5KA-F7111-00	STAND, MAIN	1				
2	5KA-F7112-00	SHAFT, MAIN STAND	1				
3	4LS-F7115-00	LINK, MAIN STAND	1				
4	90506-29054	SPRING, TENSION	1				
5	90252-55800	PIN, COTTER	1				
6	90201-15013	WASHER, PLATE	1				
7	5KA-F7211-10	PEDAL, BRAKE	1				
8	90508-40803	SPRING, TORSION	1				
9	36L-F7231-00	ROD, BRAKE	1				
10	9290N-06600	WASHER	1				
11	90252-35802	PIN, COTTER	1				
12	9290N-06600	WASHER	1				
13	90501-10815	SPRING, COMPRESSION	1				
14	90249-12008	PIN	1				
15	90179-06806	NUT	1				
16	5KA-F7411-21	FOOTREST	1				
17	97027-08020	BOLT, HEXAGON	2				
18	92907-08200	WASHER	2				
19	5KA-F7413-10	COVER, FOOTREST	2				
20	95817-08020	BOLT, FLANGE	2				
21	90506-25047	SPRING, TENSION	1				
22	90109-08032	BOLT	1				
23	95307-08700	NUT	1				
24	5KA-F7432-10	BRACKET 1	1				
25	5KA-F7442-10	BRACKET 2	1				
26	4UU-F7431-00	FOOTREST, REAR 1	1				
27	4UU-F7441-00	FOOTREST, REAR 2	1				



www.seacubemoto.com

REF. NO.	PART NO.	DESCRIPTION	1DE8				REMARK
1	5KA-H1450-30	ROTOR ASSY	1				
2	5KA-H1410-30	STATOR ASSY	1				
3	90157-06805	SCREW, PAN HEAD	3				
4	90157-06802	SCREW, PAN HEAD	2				



PARTS SOLUTION

www.seacubemoto.com




FIG. 29 FLASHER LIGHT

[illegible]




FIG. 30 METER

[illegible]

This exploded view diagram illustrates the components of a vehicle headlight assembly. The main assembly is shown within a dashed rectangular box labeled 1. The components are numbered as follows:


- 2**: The headlight lens, featuring a grid pattern.
- 3**: The headlight housing or bezel.
- 4**: A conical dust cap or protective shield.
- 5**: The headlight bulb and its base.
- 6**: The main headlight housing or mounting bracket.
- 7**: A mounting screw or bolt.
- 8**: A small circular gasket or washer.
- 9**: A small screw or pin used for mounting.

Wavy lines indicate the assembly sequence or fit of the components. The diagram shows the lens (2) and housing (3) being mounted onto the main housing (6), with the bulb (5) and dust cap (4) positioned for installation into the housing.

36



www.seacibemoto.com

[illegible]

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
95022-08055	20 - 23	97607-06225	6 - 17						
95027-06010	13 - 25	9760N-06216	34 - 6						
95027-06020	1 - 4	97701-06020	32 - 4						
95027-06035	10 - 4	97707-06112	29 - 4						
	10 - 17		29 - 8						
95027-06045	10 - 5		29 - 13						
	10 - 18		29 - 17						
95301-05600	30 - 9	98502-06014	13 - 11						
95307-06600	12 - 15	98507-05010	22 - 14						
	32 - 9	98507-06010	10 - 11						
95307-08600	25 - 37	98517-06012	32 - 12						
95307-08700	25 - 38	98907-06016	10 - 13						
	25 - 42	98907-06025	35 - 2						
	27 - 23	98980-06012	8 - 4						
9530N-05600	17 - 7	99001-10600	11 - 16						
9530N-06600	24 - 17		15 - 7						
	25 - 22	99009-17400	11 - 10						
9530N-08600	31 - 9	99009-20500	12 - 24						
95707-06300	33 - 5								
	33 - 11								
95707-08500	16 - 5								
	16 - 10								
	16 - 13								
95707-12500	2 - 14								
9570N-08500	16 - 22								
9570N-12500	29 - 9								
	29 - 18								
95802-06020	4 - 12								
95807-08025	8 - 10								
9580N-06012	30 - 10								
9580N-06016	17 - 2								
	20 - 20								
9580N-08014	16 - 20								
9580N-08016	23 - 5								
9580N-08020	16 - 16								
9580N-08040	16 - 21								
95817-08020	27 - 20								
	27 - 32								
9582N-06016	20 - 17								
97007-08025	31 - 7								
9700N-08030	22 - 9								
97027-06020	15 - 11								
97027-08020	27 - 17								
97507-06425	33 - 6								
9750M-06425	33 - 12								
97517-06520	34 - 9								
97607-04114	7 - 17								
97607-05212	17 - 6								

www.seacubemoto.com