



发动机ENGINE					
		NO	PART CODE		QTY
		1	10001-MH06-ZJ4002	发动机 Engine	1
		2	12302-M954-00000P	发动机左后罩 left rear cover,engine	1
		3	B166740106003570L	螺栓 Bolt M6×30	1
		4	B166740106003570L	螺栓 Bolt M6×35	1
		5	12318-M954-00000L	发动机前罩 Before the supporting plate	1
		6	B166740106001670L	螺栓 Bolt	1
		7	18092-0000-8100	废气再循环管 Exhaust gas recirculation pipe	1
		8	72403-I258-000066	油门拉线夹 Clip,throttle cable	1
		9			
		10			
		11			
		12			
		13			
		14			
		15			
		16			
		17			
		18			
		19			
		20			

PROTECTOR DE MOTOR POST IZQ

水箱 WATER TANK				
		NO	PART CODE	QTY
		1	19100-M954-0000	1
		2	19100-I772-0000	1
		3	1921A-M954-000066	1
		4	1921C-M954-000066	1
		5	1921P-M954-0000	1
		6	1921R-M954-0000	1
		7	1924C-M954-0000	1
		8	1924D-M954-0000	1
		9	71210-M954-000066	1
		10	71220-M954-000066	1
		11	9A137-1060-02070L	8
		12	6222A-0000-1200	6
		13	B166740106002070L	4
		14	91301-0060-25020L	2
		15	19234-M954-0200	1
		16	19234-M954-0100	1
		17	1921D-M954-0000	1
		18	19208-M954-0000	1
		19	1921H-J257-0000	4
		20	91302-0060-18070L	10
		21	1921U-M954-0000	1

VENTILADOR IZQ

VENTILADOR DER

RADIADOR DE ENFRIAMIENTO DER

RADIADOR DE ENFRIAMIENTO ZQ

ENVASE DE RADIADOR IZQ

ENVASE DE RADIADOR DER

REJILLA DE VENTILACION IZQ

REJILLA DE VENTILACION DER

MASCARA DE FARO DELT
PERNOS DE MICA DE FARO DE
FARO DELT COMPL
FOCO DE FARO 12V35/35W

仪表 METER


NO	PART CODE		QTY
1	87100-M954-0000	Instrument assembly	1
2	63716-M954-00000P	Instrument decorative covers,L	1
3	63716-M954-01000P	Instrument decorative covers,R	1
4	B000700105000870G	Screw M5×8	2
5	B00923000500000L	Nut M5	2
6	B061770006000060L	Nut M6	3
7	6222B-0000-0900	I-section pads	3
8	91302-0060-18070L	Flange gasket	3
9	35101-I256-0000	Chain box buffering rubber ring	2
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			



TABLERO DE INSTRUMENTOS 6 CAMBIOS

ADORNO IZQ TABLERO DE INSTRUMENTOS

ADORNO DER TABLERO DE INSTRUMENTOS


转向灯 TURNING LAMP				
		NO	PART CODE	QTY
		1	86300-J0A2-0200	2
		2	86400-J0A2-0200	2
		3	86390-J237-00000L	2
		4	7222S-J0A2-00000H	2
		5	B00093001000000	4
		6	91301-0100-23130C	4
		7	B06172011000006	4
		8		
		9		
		10		
		11		
		12		
		13		
		14		
		15		
		16		
		17		
		18		
		19		
		20		

FARO DIRECC DELT/POST IZQ

FARO DIRECC DELT/POST DER

PLATINA BASE DE FARO DIRECC

KIT CHAPA DE COANTACTO C/TAPA TANQUE
CUBIERTA CHAPA CONTACTO
SEGURO DE CHAPA CAJA DE MALETA
CHAPA CAJA DE MALETA


软轴/拉索 SOFT AXLE/CABLE			
NO	PART CODE		QTY
	1 72900-M954-0000	Seat cushion lock cable	1
	2 72600-M954-0000	Cable, clutch	1
	3 72400-M954-0000	Cable,throttle	1
	4		
	5		
	6		
	7		
	8		
	9		
	10		
	11		
	12		
	13		
	14		
	15		
	16		
	17		
	18		
	19		
	20		

CABLE CHAPA ASIENTO

CABLE EMBRAGUE

CABLE DE ACELERADOR

手把/后视镜 GRIP/BACK VIEW MIRROR

NO		PART CODE		QTY
	1	69110-M954-0000	Left rear view mirror	1
	2	72100-J257-C100	Tube,steering hadnlebar	1
	3	69120-M954-0000	Right rear view mirror	1
	4	72010-J257-C100	Rubber bush,left handlebar	1
	5	72020-J257-C100	Rubber bush assembly,right handlebar	1
	6	72201-M954-0000	Left switch assembly	1
	7	72301-M954-0000	Right switch assembly	1
	8	72209-M954 -0000	Handlebar,clutch	1
	9	08216-0000-1400	Tie belt	2
	10			
	11			
	12			
	13			
	14			
	15			
	16			
	17			
	18			
	19			
	20			

ESPEJO RETROVISOR IZQ

ESPEJO RETROVISOR DER

TIMON

MANUBRIO IZQ


MANUBRIO DER

COMANDO IZQ DE LUCES

COMANDO DER ENCENDIDO

MANIJA EMBRAGUE C/BASE

燃油箱 FUEL TANK

		NO	PART CODE		QTY
		1	61111-M954-0000	Front buffer bush,fuel tank	1
		2	61100-M954-00000P	Fuel tank	1
		3	61112-M256-0000	Rear buffer bush,fuel tank	1
		4	B166740108002570L	Bolt M8×25	1
		5	91301-0080-28020L	Washer φ8×Φ28×2	1
		6	91304-0085-12070L	Straight liner	1
		7	87200-M954-0000	Fuel sensor	1
		8	87205-M954-0000	Seal ring,sesor	1
		9	B061770006000060L	Nut M6	2
		10	87233-M954-0000	Washer 6	2
		11	B0009701060000K	Washer 6	2
		12	B057830005001670L	Bolt M5×16	6
		13	17970-M954-0000	Fuel Pump	1
		14	17980-J966-0000	Fuel Filter	1
		15	85430-M954-0000	Fuel Hose Assy (I)	1
		16	62143-0000-0200	Single tubing	1
		17	85430-M954-0100	Fuel Hose Assy (II)	1
		18			
		19			
		20			

JEBE TANQUE DELT

TANQUE COMBUSTIBLE S/ACCESS

JEBE TANQUE POST

FLOTADOR DE TANQUE COMPL


BOMBA DE GASOLINA

FILTRO DE GASOLINA

MANGUERA TRIPLE COMBUSTIBLE


MANGUERA

MANGUERA COMBUSTIBLE

座垫 Seat					
		NO	PART CODE		QTY
	1	41200 -M954-0000	Z	Single seat cushion	1
	2	41300-M954-0000	Z	Attach the seat cushion	1
	3	41102-M954-00000L	S	Seat cushion after stent	1
	4	B166740106001670L	—	Bolt M6×16	2
	5	83210-F121-C000	—	Battery strap	2
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

ASIENTO COPILOTO

ASIENTO CHOFER

电器元件 Electric parts				
		NO	PART CODE	QTY
	1	85100-M954-0000	ZS Main cable	1
	2	85500-J257-0000	ZS Horn	1
	3	B166740106001270L	— Bolt M6×12	1
	4	82290-1357-0000	ZS Starting relay	1
	5	85600-M954-0000	ZS Flasher	1
	6	83100-M954-0000	ZS Rectifier	1
	7	B166740106002070L	— Bolt M6×20	2
	8	85400-M954-0000	ZS ECU	1
	9	B166740106001670L	— Bolt M6×16	2
	10	81100-M954-0100	ZS Ignition coil	1
	11	B166740106003570L	法 Bolt M6×35	1
	12	8229C-M954-0000	启 The insurance sheet	2
	13	81301-MH06-0000	N Cap,spark plug	1
	14	08216-0000-2200	— Cable tie L=250mm	22
	15	17910-M954-0000	— Fuel Injector	1
	16	B166740106001670L	法 Bolt M6×16	2
	17	85181-J966-C000	ZS Support of Fuel Pump Relay and fuses	1
	18	17950-M954-0000	ZS Oxygen sensor	1
	19	17930-M954-0000	ZS Air intake pressure/temperature sensor	1
	20	85440-M954-0000	ZS Engine stop switch	1
	21	B008450004202520L	— Screw ST4.2×25	2
	22	B0009601050000K0L	— Washer 5	2

www.seacubemoto.com

RAMAL PRINCIPAL

CLAXON

RELAY ARRANQUE

FLASHER

RECTIFICADOR CONTINUO

ECU

BOBINA ENCENDIDO


CAPUCHON DE BUJIA


INYECTOR COMBUSTIBLE


SENSOR DE OXIGENO


SENSOR DE TEMPERATURA


SWITCH DE STOK

炭罐CARBON POT				
NO		PART CODE		QTY
	1	61165-M954-0000	Z S Carbon pot	1
	2	17960-J648-0000	Z S Solenoid valve,carbon pot	1
	3	61161-M954-0000	— Vacuum pipe	1
	4	61164-M954-0000	— Vacuum pipe,carbon pot	1
	5	17626-M954-0000	Z S Connecting pipe, carbon pot	1
	6	17626-M954-0100	— Connecting pipe, carbon pot I	1
	7			
	8			
	9			
	10			
	11			
	12			
	13			
	14			
	15			
	16			
	17			
	18			
	19			
	20			


工具/电池支架 tool/battery bracket			
NO	PART CODE		QTY
	1 06000-J257-0000	Z Vehicle tools	1
	2 83200-0000 7500	Z Battery	1
	3 B166740106601276L	Z Bolt M6×16	4
	4 83210-I126-0300	Band,Battery	1
	5 83220-M954-000066	Z Bracket ,battery	1
	6		
	7		
	8		
	9		
	10		
	11		
	12		
	13		
	14		
	15		
	16		
	17		
	18		
	19		
	20		


后挡泥板 rear fender				
		NO	PART CODE	QTY
		1	63201-M954-0000	Z S 1 Rear fender front
		2	63202-M954-0000	Z S 1 After the rear fender
		3	85680-1239-0100	S 1 After the reflector
		4	B061770006000060L	3 Nut M6
		5	6222A-0000-1200	4 I-section pads
		6	B166740106001270L	2 Bolt M6×12
		7	B0009601060000K0L	4 Washer 6
		8	B008450004201320L	7 Screw ST4.2×13
		9	9A137-1060-01270L	3 Screw M6×12
		10	9A137-1060-02070L	4 Screw M6×20
		11	91205-1042-01700L	5 Self tapping screw clamp
		12	33315-M954-0000	Z S 1 In beach
		13	B0009601040000K0L	3 Washer 4
		14		
		15		
		16		
		17		
		18		
		19		
		20		


尾灯 Rear lamp assembly					
NO		PART CODE		QTY	
	1	86200-M954-0000	尾	Tail light assembly	1
	2	86700-J0A2-0000	线	After the license plate lamp	1
	3	B508160005160026L	螺	Screw M5×10	1
	4	B061770005000060L		Nut M5	1
	5	B008450004201320L		Screw ST4.2×13	6
	6	86730-J0A2-0000	线	After the license plate lamp harness	1
	7	86720-0000-0000		bulb(12V/5W), rear licence plate lamp	1
	8	86710-J0A2-0000	背	After the license plate lamp body	1
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

空滤器 AIR CLEANER				
NO	PART CODE			QTY
	1	16100-M954-0000	Air cleaner	1
	2	B166740106001670L	Bolt M6×16	3
	3	91267-106001960L	Thread clamp M6-19×11-3	3
	4	16104-M954-0000	I air filter shell	1
	5	16123-M954-0000	Joint clip,air filter I	1
	6	16123-M954-0100	Joint clip,air filter II	1
	7	16103-M954-0000	Connecting end,air filter	1
	8	16102-M954-0000	II air filter shell	
	9	16121-M954-0000	Air filter element bracket	1
	10	16101-M954-0000	Core,air cleaner	1
	11	16114-M954-0000	Filtering net,air cleaner	1
	12	16148-M954-0000	Cap,air cleaner	1
	13	9A112-1050-01620C	Screw	5
	14	B0009701050000K	Screw	5
	15	16108-M954-0000	Air filter sealing ring	1
	16	16108-M954-0100	Air filter sealing ring I	1
	17	16108-M954-0200	Air filter sealing ring II	1
	18			
	19			
	20			

节流阀体 throttle parts			
NO	PART CODE		QTY
	1	B000700106001670G	内六角 Bolt M6×16
	2	15800-M954-0000	进气管 Intake pipe
	3	17000-M954-0000	节流阀体 Throttle parts
	4		
	5		
	6		
	7		
	8		
	9		
	10		
	11		
	12		
	13		
	14		
	15		
	16		
	17		
	18		
	19		
	20		

消声器 MUFFLER			
NO	PART CODE		QTY
	1	18000-M954-0000	Exhaust muffler
	2	9A123-1080-01670L	Bolt M8×16
	3	91262-1060-01830L	Nut M8×17.5
	4	18007ME30-0000	Seal pad,ex muffler
	5	18801-M954-0000	Rear part,exhaust tube
	6	18040-M954-0000	After the exhaust pipe cover
	7	B00070020600167	Screw M6×16
	8	B00818000600162	Screw M6×16
	9	18010-M954-0000	The exhaust pipe in
	10	1804C-M954-0000	Before the exhaust pipe cover
	11	18043-M954-0000	Clip,muffler
	12	B166741108003570X	Flange bolt M8×35(concave)
	13	18238-M954-0000	Bush
	14	18070-M954-0000	Catalytic Converter
	15		
	16		
	17		
	18		
	19		
	20		


脚踏操纵件 foot control parts				
		NO	PART CODE	QTY
		1	24400- M954-000071	1
		2	52100-M954-000071	1
		3	52100-M954-00000L	1
		4	5210C-J257-0000	1
		5	52201-M954-00000L	1
		6	B057830006002070G	1
		7	B061870108000060L	1
		8		
		9		
		10		
		11		
		12		
		13		
		14		
		15		
		16		
		17		
		18		
		19		
		20		


前后脚踏 FRONT REAR PEDAL ASSEMBLY				
NO		PART CODE		QTY
	1	32106-J257-030071	左 S 前脚踏	1
	2	32107-J257-030071	右 S 前脚踏	1
	3	32106-J257-00000	橡胶衬套,前脚踏	2
	4	B008940110000000N	— Circ clip,shaft 10(65Mn)	2
	5	91301-0100-16030L	— Plane padφ10×φ16×3	2
	6	32112-J257-00000L	左 S Torsion spring,front footstep	2
	7	B008820010005000L	— Pin shaftφ10×50 (groove distance 47)	2
	8	32415-M954-0000	左 支 后脚踏支架	1
	9	32425-M954-0000	右 支 后脚踏支架	1
	10	32430-M954-0000	左 后脚踏	1
	11	32440-M954-0000	右 后脚踏	1
	12	32416-M954-0000	左 S Rubber bush,rear footpeg	2
	13	32449-J257-0000	后 脚 Limit disc, rear pedal	2
	14	32437-J257-0000	弹 簧 Rear pedal spring	2
	15	B00896000400000	开 口 Circ clip	2
	16	B0009701060000K	平 垫 Flat pad	2
	17	71205-0000-0000	钢 球 Steel ball	2
	18	32471-J257-0000	销 轴 Pin shaft,rear pedal	2
	19	B0007001080030700	— Hex bolt with tapered end M8×30	4
	20	32410-M954-000071	左 S Left rear footpeg assembly	1
	21	32420-M954-000071	右 S Right rear footpeg assembly	1

方向柱 STEERING STEM

www.seacubemoto.com


NO	PART CODE		QTY
1	71104-J257-00000L	Z S Cap nut,steering post	1
2	71123-J257-00000G	Z S Plane washer,steering post	1
3	71114-J257-00000	Z S Clip,steering post	2
4	B0007001080030700	—	Hex socket head bolt M8×30
5	71110-J257-0000	方	Clip seat,steering post
6	9A157-1100-02570L	—	Screw M10×1.25×25
7	71101-M954-0000	上	Upper connecting board
8	71120-M954-0000	—	Lower connecting board
9	71105-J257-00000L	Z S Adjusting nut,steering post	1
10	71200-J257-0000	Z S Bearing,steering post(32005)	2
11	71124-J257-00000L	Z S Dustproof ring,steering post	1
12	71100-M954-000071	Z S Steering post assemby	1
13			
14			
15			
16			
17			
18			
19			
20			

前减震器 FRONT SHOCK ABSORBER				
		NO	PART CODE	QTY
	1	34100-M954-000071	Left front damper	1
	2	34200-M954-000071	Right front damper	1
	3	B166740108604576L	Bolt M8×45	2
	4	85105-M954-0000	mileage of the clamp	1
	5	B008180005160020L	Cross recessed pan head screws M5×16	1
	6	B061700005000060L	General six hexagon nuts M5	1
	7			
	8			
	9			
	10			
	11			
	12			
	13			
	14			
	15			
	16			
	17			
	18			
	19			
	20			


前挡水板front waterproof board				
NO		PART CODE		QTY
	1	63130-M954-00000P	Z S Prior to the manger	1
	2	B008450004201320L	Screw ST4.2×13	1
	3	9A137-1000-02070L	Screw M6×20	2
	4	91205-1042-01700L	Self tapping screw clamp	3
	5	6222A-0000-1200	I-section pads	2
	6			
	7			
	8			
	9			
	10			
	11			
	12			
	13			
	14			
	15			
	16			
	17			
	18			
	19			
	20			


前碟刹总成 Front disc brake assembly


NO	PART CODE		QTY
1	53000-M954-000066	Z S Front disc brake assembly	1
2	92309-M954-0000	— Front brake handlebar	1
3	53012-M954-0000	— Upper pump,front disc brake	1
4	53002-M954-0000	— Oil pipe,front disc brake	1
5	53014-M954-0000	— Lower pump,front disc brake	1
6	53013-M954-0000	— Left friction plate assembly,front disc brake	1
7	53013-M954-0100	— Right friction plate assembly,front disc brake	1
8	B166740108005070L	— Bolt M8×50	2
9	53001-M954-0000	Z S Front brake disc	1
10	9A137-1060-01670L	— Screw M6×16	6
11	53032-M954-00000L	Z S Front disc brake oil pipe line clip	2
12	B166740106001070L	— Bolt M6×10	2
13			
14			
15			
16			
17			
18			
19			
20			




后制动器rear brake

NO		PART CODE		QTY
	1	53100-M954-000066	Z S Rear dish brake assy	1
	2	53115-M954-0000	/后 油 The brake switch	1
	3	53105-M954-0000	/后 油 Upper pump, rear disc brake	1
	4	53121-M954-0000	— Connecting oil pipe, rear disc brake	1
	5	53104-M954-0000	— Lower pump, rear disc brake	1
	6	53101-M954-0000	Z S Rear brake disc	1
	7	B000700206001670L	— Screw M6×16	6
	8	5312A-J257-0000	Z S Oil pipe clip, rear brake	1
	9	9A137-1060-01270L	— Screw M6×12	1
	10	B166740106002570L	— Bolt M6×25	2
	11	53124-J257-0000	— dustproof cover	1
12				
13				
14				
15				
16				
17				
18				
19				
20				

前轮 FRONT WHEEL			
NO		PART CODE	QTY
	1	51103-M954-0000	Shoe,front wheel
	2	51205-0000 0000	Pad belt,rear wheel
	3	51104-M954-0000	Inner tube,front wheel
	4	51181-M954-00000L	Axle,front wheel
	5	51101-J257-00000L	Left bush,front wheel
	6	B061870214000060L	Nut M14×1.5
	7	87330-M954-0000	Speedcounter
	8	51116-0000-0400	Oil seal
	9	92102-0006302-2RS	Bearing
	10	51108-0000-0300	Support Ring
	11	51117-0000-9800	Inner bush,hub
	12	51110-M954-000066	Rear wheel with spoke
	13		
	14		
	15		
	16		
	17		
	18		
	19		
	20		

后轮 rear wheel				
		NO	PART CODE	QTY
	1	51203-M954-0000	Z Shoe, rear wheel	1
	2	51204-M954-0000	Z Inner tube, rear wheel	1
	3	51205-0000-0000	Z Pad bell, rear wheel	1
	4	51210-M954-000066	Z Rear wheel with spoke	1
	5	B061870214000060L	Nut M14×1.5	1
	6	51201-J257-00000L	Z Left bush, rear wheel	1
	7	51281-J257-00000L	Z Axle, rear wheel	1
	8	51202-M954-00000L	Z Rear right sleeve	
	9	35010-J257-00008G	Z Adjuster, chain	1
	10	B061700008000060L	Nut M8	4
	11	51116-0000-0400	Oil seal	1
	12	92102-0006302-2RS	Bearing	2
	13	51117-0000-9900	Inner bush, hub	1
	14	51108-0000-0300	Oil seal	1
	15			
	16			
	17			
	18			
	19			
	20			


平叉/后减震器 rear fork/rearshock absorber				
NO		PART CODE		QTY
	1	35210-J257-0000	Z S Decorative cover,fork shaft	1
	2	B000700111006070L	Screw M12×1.25×60	1
	3	91301-0120-28020L	Washerφ12×φ28×2	1
	4	B061870212000060L	Nut M12×1.25	1
	5	33300-M954-0000	Z S Rear absorber shock	1
	6	91302-0060-15070H	Flanged washerφ6×φ14.5×7-1	2
	7	6222A-0000-0500	I-section pads	2
	8	9A137-1060-01670L	Screw M6×16(Φ14)	2
	9	9A137-1060-01270L	Screw M6×12(Φ14)	2
	10	35001-M954-0000	Protecting clip,chain	1
	11	35200-M954-00008F	Z S Fork assembly	1
	12	35281-M954-0000	Z S Shaft,fork	1
	13	35242-M954-0000	衬套 Inner bush,fork	2
	14	35212-M954-0000	平叉 Oil seal,fork 24×16×5	4
	15	92102-00000NK2016	轴承 Bearing	4
	16	35241-M954-0000	轴套 Tube	2
	17	35289-M954-0000	Z S Dustproof cap,fork	2
	18	B061870216000060L	Nut M16×1.5	1
	19			
	20			


链盒/链条 chain box/chain				
NO		PART CODE		QTY
	1	35110-J257-0000	Z S Semi-chain box	1
	2	9A137-1060-01270L	Inner hexagon screw	1
	3	25400-5201-0110	Chain	1
	4	55002-M954-00000X	Z S Sprocket	1
	5	9A123-1080-03270L	Inner hexagon bolt	6
	6	B061870108000060L	Self-lock nut	6
	7	91206-1060-02000L	Nut clip	1
	8	6222A-0000-0500	H shape rubber pad	2
	9	91302-0060-15070L	Flanged pad	2
	10	9A137-1060-01670L	Inner hexagon screw M6×16	2
	11			
	12			
	13			
	14			
	15			
	16			
	17			
	18			
	19			
	20			

油箱护板 PROTECTING BOARD, FUEL TANK

NO		PART CODE		QTY	
		1	61131-M954-00000P	Left decoration cover tank	1
		2	61132-M954-00000P	Right decoration cover tank	1
		3	63373-M954-0000	Tank left guard	1
		4	63374-M954-0000	Tank right guard	1
		5	63371-M954-00000P	Tank left decorative	1
		6	63372-M954-00000P	Tank right decorating plate	1
		7	61125-M954-0000	Decorative pieces right	1
		8	63383-M954-0000	Decorative pieces left	1
		9	91302-0060-18070L	Flanging mat	2
		10	91206-1060-02000L	The nut clips	2
		11	9A137-1060-02070L	Screw M6×20	2
		12	B008450004201320L	Screw ST4.2×13	24
		13	B0081800050100020L	Screw M5×10	4
		14	91207-1050-01930L	Thread clamp	4
		15	9A118-1060-016700	Bolt M6×16	4
		16	91205-1042-01700L	Self tapping screw clamp	6
		17	6222A-0000-1200	I-section pads	2
		18	63342-H206-0200	Car body cover rubber plug	2
		19			
		20			

侧盖 side cap


NO		PART CODE			QTY
	1	63301-M954-0000	Z S S	Left side cap	1
	2	63332-M954-0000	Z S S	Right side cap	1
	3	63341-M954-0000P	Z S S	Cap,vehicle left part	1
	4	63352-M954-00000P	Z S S	Cap,vehicle right part	1
	5	B008450004201320L		Screw ST4.2×13	10
	6	91205-1042-01700L		Self tapping screw clamp ST4.2-17×11	2
	7	63342-H206-0200		Car body cover rubber plug	4
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

尾箱THE TRUNK				
NO		PART CODE		QTY
	1	42417-M954-0000	The trunk	1
	2	42430-M954-0000	Box on the left	1
	3	42450-M954-0000	On the right side of the carton	1
	4	42418-M954-0000	The tail box cover	3
	5	4243D-M954-0000	clip	6
	6	42413-M954-0000	Tail box pad peel	1
	7	4242S-M954-0000	The tail box back of a chair	1
	8	B008450004201620L	Screw ST4.2×16	3
	9	4242J-M954-0000	The tail box sealing strip	3
	10	6222A-I538-0000	I-section pads	3
	11			
	12			
	13			
	14			
	15			
	16			
	17			
	18			
	19			
	20			

尾箱拉索TRUNK CABLE

NO	PART CODE		QTY
1	4242B-B320-0000	The trunk cable assembly	2
2	4243P-M954-0000	Side box and cable	2
3	4243P-M954-0100	Side box and cable	2
4	4243H-M954-00000L	Edge cases line hook	12
5	B008450004201320L	Screw ST4.2×13	18
6	91205-1042-01700L	Self tapping screw clamp	6
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			


GANCHO DE APERTURA DE MALETA




边箱支架side box bracket			
NO	PART CODE		QTY
1	42435-M954-00008G	Z Left side box bracket	1
2	42436-M954-00008G	Z Right side box bracket	1
3	42465-M954-00008G	S Side box bracket connecting rod	1
4	42466-M954-00008G	Z Side box bracket connecting rod	1
5	42432-M954-00008G	Z Edge cases after hanging	1
6	42446-M954-0000	S Cushioning pads of the edge cases	2
7	B166740108008070L	— Bolt M8×80	2
8	B166740108006070L	— Bolt M8×60	1
9	B166740108004570L	— Bolt M8×45	2
10	B166740108004070L	— Bolt M8×40	1
11	B166740108003570L	— Bolt M8×35	2
12	B166740108002070L	— Bolt M8×20	8
13	91302-0085-22080L	— Flanging mat	8
14			
15			
16			
17			
18			
19			
20			

www.seacubemoto.com

后扶手 Rear armrest			
NO	PART CODE		QTY
1	42200-M954-000071	后扶手	1
2	9A137-1060-02070L	螺丝 M6×30	2
3	9A137-1060-03070G	螺丝 M6×35	2
4	4241S-M954-000071	尾箱支撑板	1
5	9A137-1060-02070L	螺丝 M6×20	3
6	91301-0060-25020L	垫圈 φ6×φ25×2	3
7	B166740108008570L	螺栓 M8×85	1
8	4241S-M954-0400	尾箱支撑板 IV	1
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			


侧支架 Side bracket			
NO		PART CODE	QTY
	1	32130-M954-00008G	Side stand
	2	32102-J0A2-00000L	Spring,side bracket
	3	B001770210000000L	Flanged nut M10×1.25
	4	91113-6100-03570L	Bolt M10×1.25×47
	5		
	6		
	7		
	8		
	9		
	10		
	11		
	12		
	13		
	14		
	15		
	16		
	17		
	18		
	19		
	20		

保险杠 A BUMPER

NO		PART CODE		QTY
	1	68112-M954-00008G	Z S	Bumper front1
	2	68113-M954-00008G	Z S	Right after the bumper section1
	3	68103-M256-0100	Z S	Bumper bracket1
	4	68116-M954-00008G	Z S	Bumper bushing2
	5	B061770006000060L		Nut M62
	6	B166740108005070L		Bolt M8×502
	7	B166740108004570L		Bolt M8×452
	8	B166740108001670L		Bolt M8×161
	9	B061870108000060L		Nut M82
	10			
	11			
	12			
	13			
	14			
	15			
	16			
	17			
	18			
	19			
	20			


NO	PART CODE	QTY
1	31130-M954-00008G	1
2	31130-M954-01008G	1
3	B166740108003070L	2
4	B166740108003070L	4
5	B166740108001270L	4
6	B000970108000000L	8
7	B061870108000060L	6
8	6222A-0000-2700	8
9	91701-0080-10000L	4

车架 frame			
NO	PART CODE		QTY
1	3110D-M954-00008F	Z S Frame front	1
2	3110S-M954-00008G	Z S Frame late	1
3	31150-M954-00008G	Z S Engine bracket	1
4	31210-M954-00008G	Z S Connecting plate on the engine	2
5	B166740210013070L	Flange bolt M10×1.25×130	1
6	B166740210011570L	Flange bolt M10×1.25×115	1
7	B166740210010570L	Flange bolt M10×1.25×105	1
8	B166740108006070L	Flange bolt M8×60	5
9	B166740210004570L	Flange bolt M10×1.25×45	2
10	B061870108000060L	Nut M8	5
11	B061870210000060L	Nut M10×1.25	9
12	31168-M954-00000L	Z S Clamps	2
13	41490-M954-00000L	Z S Bridge pad locks	1
14	B0081800061120020L	Screw M6×12	2
15	31204-M954-0000	Frame decoration cover	1
16	31110-M954-00008G	Z S Under the engine protection plate	1
17	9A137-1060-01270L	Screw M6×12	5
18	B166740210003270L	Flange bolt M10×1.25×32	2
19	B166740210003570L	Flange bolt M10×1.25×35	2
20			



www.seacubemoto.com

摇架ROCKING FRAME

NO		PART CODE		QTY	
		1	B057850012009570L	Flange bolt M12×1.25×95	1
		2	35421-M954-0000	Rear subassembly bush, rocking frame	1
		3	92102-0000RNA0901	Needle bearing	2
		4	35212-M567-0000	Fork oil seal	8
		5	35422-M954-0000	Rear subassembly bush, rocking framell	1
		6	B166740212007270L	Flange bolt M12×1.25×72	1
		7	35420-M954-000071	Rear subassembly, rocking frame	1
		8	B061870212000060L	Self-lock nut M12×1.25	3
		9	B166740212010570L	Flange bolt M12×1.25×105	1
		10	3541D-J257-C0008R	Front subassembly, rocking frame	1
		11	35411-J257-0000	Front subassembly bush, rocking frame	2
		12	B166740210005070L	Flange bolt M10×1.25×50	1
		13	35423-M954-0000	Rear subassembly bush, rocking frame	1
		14	B061870210000060L	Self-lock nut M10×1.25	1
		15	92102-000HK202614	Needle bearing HK202614	2
		16	92102-00000HK2020	Needle bearing HK2020	1
		17	92102-00000F02010	Needle bearing F02010	1
		18			
		19			
		20			