


ZS150-48A Motorcycle

(1408-176)

www.seacubemoto.com


NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	10001-J0A2-00B566	发动机(ZY150、国际档、电/脚启动)	Engine	1
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




www.seacubemoto.com

油器INTAKE PIPE/CARBURETOR


Revision Number Page:4




NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	17100-J0A2-1900	ZS150-48A化油器(ZY150/国II、自动风门、升级版)	Carburetor	1
2	90101-30300000250	V250进气管O形圈30×2.5(氟硅胶)	O ring,seal pad,intake pipe	1
3	90214-I096-0000	C120化油器隔热垫	Bakelite gasket	1
4	90101-10290000240	C120化油器隔热垫O形圈29×2.4(丁腈胶)	Asbestos pad,intake pipe	1
5	15800-J0A2-0300	ZS150-48A进气管(ZY发动机、环保)	Intake pipe	1
6	B061770106000060L	法兰面螺母M6(磨盘齿)	Nut M6	2
7	B166740106002071L	法兰面螺栓(φ11)M6×16(抛光头)	Bolt M6×16	2
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				


	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	18090-I398-0000	ZS125-50S(GC10国III)CG125D空气泵(带防尘胶套)	Gas pump	1
	2	B166741106002070L	法兰面螺栓M6×20 (凹穴)	Bolt m6×20	2
	3	61302-0000-A026	复合油管(φ4×φ8×(L型(400+25))、耐油、φ8片卡2件)	Oil pipe(φ4×φ8×(L(400+25)))	1
	4	18092-0000-7000	废气循环橡胶管φ9×φ15×(60+35)、带卡箍2件)	Rubber tubeφ9×φ15×(60+35)	1
	5	B166741106001270L	法兰面螺栓M6×12 (凹穴)	Bolt m6×12	2
	6	12105-I126-0000	通气管 (ZS125-2)	Vent pipe	1
	7	18098-0000-5300	二次补气阀连接管(φ11×φ16×390\两个夹箍)	Connecting pipe(φ11×φ16×390)	1
	8	61314-0000-2600	复合油管(φ4×φ8×150)、耐油、φ8片卡2件)	Oil pipe(φ4×φ8×150)	8
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seacubemoto.com

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	B008180005001620L	十字槽盘头螺钉M5×16	Screw M5×16	1
	2	91205-1042-01700L	自攻卡子ST4.2×17	Clip ST4.2×17	2
	3	91207-1050-01800L	螺纹卡子M5×17.5×11	Clip M5×17.5×11	1
	4	9A133-1042-013X0L	自攻螺钉(盘φ9)ST4.2×13	Screw ST4.2×13	2
	5	9A133-1042-016X0L	自攻螺钉(盘φ9)ST4.2×16	Screw ST4.2×16	2
	6	86100-J0A2-0100	ZS150-48B前照灯	Front lamp	1
	7	8610Z-J0A2-0000	前照灯反光碗及灯罩组合(S)	Reflector and lampshade assembly	1
	8	86112-0000-0500	前照灯位置灯泡(12V5W、飞利浦)	Bulb 12V5W, position lamp	1
	9	86160-0000-C000	前照灯灯泡(12V35/35W尖形、三爪、飞利浦)	Bulb, front lamp(12V35/35W)	1
	10	86120-J0A2-0000	线缆组合	Cable assembly	1
	11	86154-J0A2-0000	ZS150-48A前照灯后护板	Headlight rear protective cover	1
	12	91218-1060-022T0U	弹性翻边螺纹卡子M6-22.3×15	Clip M6-22.3×15	1
	13	B166741106001670L	法兰面螺栓M6×16（凹穴）	Bolt M6×16	2
	14	91302-0060-18070L	翻边垫φ6×φ18×7-1.5	Flanged washer φ6×φ18×7-1.5	1
	15				
	16				
	17				
	18				
	19				
	20				

NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	B061770210000060L	法兰面螺母M10×1.25(磨盘齿)	Nut M10×1.25	4
2	7222S-J0A2-00000H	ZS150-48A转向灯定位块(黑锌)	Turning light positional plate	4
3	86300-J0A2-0200	ZS150-48A前左转向灯(加电容)	Left turning lamp, front	2
4	86400-J0A2-0200	ZS150-48A前右转向灯(加电容)	Right turning lamp, front	2
5	86200-J0A2-0100	ZS150-48A尾灯总成(加电容)	Rear lamp assembly	1
6	9A133-1042-013X0L	自攻螺钉 (盘Φ9) ST4.2×13	Screw ST4.2×13	3
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				







NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	86175-J0A2-000068	ZS150-48A前大灯右装饰罩(黑闪金黑)	Headlight right decorative cover	1
1	86175-J0A2-000098	ZS150-48A前大灯右装饰罩(MANA850红)	Headlight right decorative cover	1
1	86175-J0A2-0000HF	ZS150-48A前大灯右装饰罩(秘鲁蓝)	Headlight right decorative cover	1
2	87100-J0A2-C700	ZS150-48A仪表总成(ZY150、升级、取消ZONGSHEN字样及标徽)	Meter assembly	1
3	B166741106001270L	法兰面螺栓M6×12(凹穴)	Bolt M6×12	3
4	9A118-1060-016700	锥头内六角螺钉M6×16(盘Φ13.5)	Screw M6×16	2
5	86174-J0A2-000068	ZS150-48A前大灯左装饰罩(黑闪金黑)	Headlight left decorative cover	1
5	86174-J0A2-000098	ZS150-48A前大灯左装饰罩(MANA850红)	Headlight left decorative cover	1
5	86174-J0A2-0000HF	ZS150-48A前大灯左装饰罩(秘鲁蓝)	Headlight left decorative cover	1
6	87118-J0A2-0000	ZS150-48A仪表胶圈(防水胶条)	Rubber ring	1
7	91302-0060-18099L	翻边垫Φ6×Φ18×9-1.5	Flanged washer Φ6×Φ18×9-1.5	3
8	91302-0060-18070L	翻边垫Φ6×Φ18×7-1.5	Flanged washer Φ6×Φ18×7-1.5	2
9	86193-J0A2-00006N	ZS150-48A前照灯支架(珍珠黑)	Bracket, front lamp	1
10	B061770106000060L	法兰面螺母M6(磨盘齿)	Nut M6	5
11	6222A-0000-2000	工字形胶垫(Φ8×Φ12×Φ17-2.5+2+2.5、天然胶)	H shape rubber washer(Φ8×Φ12×Φ17-2.5+2+2.5)	6
12	87102-I256-0200	ZS125-70仪表支架减震垫 I	Instrument bracket damping pad	2
13				
14				
15				
16				
17				
18				
19				

镜HANDLEBAR/REAR VIEW MIRROR


Revision Number Page:11

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	69110-J0A2-0000	ZS150-48A左后视镜	Frosted black	1
	2	69120-J0A2-0000	ZS150-48A右后视镜	Frosted black	1
	3	72201-J0A2-0000	ZS150-48A左开关总成(带风门开关)	Left switch assembly	1
	4	72301-J0A2-0000	ZS150-48A右开关总成	Right switch assembly	1
	5	72035-J0A2-000066	ZS150-48A装饰头本体(亚黑)	Decoraton head	2
	6	72010-J0A2-0000	ZS150-48A左手把胶套	Rubber bush,left handlebar	1
	7	72020-J0A2-0000	ZS150-48A右手把胶套组合(含加油器)	Rubber bush assembly,right handlebar(including greaser)	1
	8	72209-I357-C00066	ZS125-2S(GH02)离合手柄(阻力臂30MM抛光/座亚黑)	Handlebar,clutch	1
	9	72150-J0A2-000071	ZS150-48A左方向把管(银白)	Tube, left steering handlebar	1
	10	B0007002060020700	GB/T70. 2内六角螺钉M6×20	Hexagonal round head screw M6×20	2
	11	0A118-1080-030500	锥头内六角螺钉M8×30(盘Φ17)	Conical head hexagonal	2
	12	08216-0000-0300	橡胶扎带60×12mm(带钮扣式)	Strap 60×12mm	2
	13	72160-J0A2-000071	ZS150-48A右方向把管(银白)	Tube, right steering handlebar	1
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com



NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	53000-J0A2-C60065	ZS150-48A前碟刹总成(0000状态改手柄抛光,上下泵珍珠黑)	Front disc brake assembly	1
2	53014-J0A2-C600	前碟刹下泵	Lower pump,front disc brake	1
3	71183-J0A2-00006N	ZS150-48A碟刹管夹(粉亮黑)	Disc brake oil pipe clip	1
4	53002-J0A2-0000	前碟刹油管	Oil pipe,front disc brake	1
5	53012-J0A2-C600	前碟刹上泵	Upper pump,front disc brake	1
6	72309-J0A2-C600	制动手柄	Brake handlebar	1
7	53001-J0A2-0200	ZS150-48A前制动盘(花盘)	Front brake disc	1
8	B000700108002070G	内六角盘头螺钉M8×20	Screw m8×20	4
9	87340-J0A2-0000	计速器转子	Rotator,speedcounter	1
10	87330-J0A2-0000	ZS150-48A计速器	Speedcounter	1
11	B166740106001371H	法兰面螺栓(φ11)M6×12(抛光头)	Bolt M6×12	1
12				
13				
14				
15				
16				
17				
18				
19				
20				




NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	B0007001080020700	内六角圆柱头螺钉M8×20	Screw M8×20	2
2	91301-0100-28020G	平垫圈φ10×φ28×2	Washer φ10×φ28×2	1
3	71203-I377-0000	ZS125-24轴承上座圈	Upper seat ring,bearing	1
4	71204-I377-0000	ZS125-24轴承下座圈	Lower seat ring,bearing	1
5	71201-I377-0000	ZS125-24轴承上挡圈	Upper check ring,bearing	1
6	71202-I377-0000	ZS125-24轴承下挡圈	Lower check ring,bearing	1
7	71208-I377-0000	ZS125-24上保持架	Upper retaining bracket	1
8	71209-I377-0000	ZS125-24下保持架	Lower retaining bracket	1
9	71100-J0A2-000071	ZS150-48A方向柱总成(分体式、银白)	Steering post assemby	1
10	71108-J0A2-00000G	ZS150-48A方向柱螺栓	Bolt(M10×1.25×28),steering post	1
11	71105-J0A2-00000L	ZS125-11(S04)方向柱调节螺母(军绿)	Adjusting nut,steering post	1
12	71107-J0A2-0000	方向柱防尘盖	Dustproof cap	1
13	71101-J0A2-0000	上连接板	Upper connecting board	1
14	71120-J0A2-0000	下连接板及立管组合	Lower connecting board and standing tube component	1
15	B0009701100000K0L	平垫 φ10	Washer 10	2
16	B000930010000000L	弹垫 φ10	Elastic pad 10	2
17	B057830010003570L	六角头螺栓M10×1.5×35	Bolt M10×1.5×35	2
18	34100-J0A2-000071	ZS150-48A左前减震器(780mm、银白)	Left front damper	1
19	34200-J0A2-000071	ZS150-48A右前减震器(780mm、银白)	Right front damper	1
20	34110-J0A2-0000	ZS150-48A前减震器挡盖(PA6)	Retaining cap, front absorber shock	2
21	7110A-J0A2-000071	ZS150-48A方向柱组件(分体式,拆分状态,银白)	Steering post component	1


	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	85850-J257-0000	ZS150GY-10侧反射器	Side reflector	2
	2	B166741106001270L	法兰面螺栓M6×12（凹穴）	Bolt M6×12	1
	3	B008180005001620L	十字槽盘头螺钉M5×16	Screw M5×16	1
	4	B061700005000060L	六角螺母M5	Nut M5	1
	5	72619-J0A2-00006N	ZS150-48A离合线夹(粉亮黑)	Cable clip,clutch	1
	6	85105-J0A2-02006N	ZS150-48A里程线夹(上、粉亮黑)	Clip(upper), odometer	1
	7	85105-J0A2-00006N	ZS150-48A里程线夹(粉亮黑)	Clip, odometer	1
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


meter decorative cover

Revision Number Page:15


		NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
		1	63758-J0A2-0100	ZS150-48A前挡风玻璃(S)茶色	Front windshield	1
		2	9A133-1042-013X0L	自攻螺钉(盘φ9)ST4.2×13	Screw st4.2×13	2
		3	63716-J0A2-0100	ZS150-48A仪表装饰罩（改装版）	Meter decorative cover	1
		4	63764-J0A2-0100	ZS150-48A前挡风玻璃附件(不带橡胶螺母)(S)	Accessories front windshield	1
		5	93010-0000-0000	橡胶螺母M5	Rubber nut M5	4
		6				
		7				
		8				
		9				
		10				
		11				
		12				
		13				
		14				
		15				
		16				
		17				
		18				
		19				
		20				

www.seacubemoto.com


CONTROL CABLE		Revision Number Page:16			
	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	72900-J0A2-0000	ZS150-48A座垫锁拉索	Cable,seat lock	1
	2	72700-J0A2-00000L	ZS150-48A风门拉索(军绿)	Cable,choke	1
	3	72400-J0A2-00000L	ZS150-48A油门拉索(军绿)	Cable,throttle	1
	4	72600-J0A2-00000L	ZS150-48A离合拉索(军绿)	Cable,clutch	1
	5				
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				



NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	91205-1042-01700L	自攻卡子ST4.2×17	Clip ST4.2×17	2
2	9A133-1042-013X0L	自攻螺钉(盘φ9)ST4.2×13	Screw ST4.2×13	4
3	B008450003801420L	自攻螺钉ST3.8×14	Screw ST3.8×14	2
4	63602-J0A2-000066	ZS150-48A尾盖(亚黑)	Tail cap	1
5	63341-J0A2-C0N4A7	ZS150-48A左车体盖(有孔,6010+6008、N4#)	Cap, vehicle left part	1
5	63341-J0A2-C0N392	ZS150-48A左车体盖(有孔,1530+6008、N3#)	Cap, vehicle left part	1
5	63341-J0A2-C0N3RU	ZS150-48A左车体盖(有孔,4521+6008、N3#)	Cap, vehicle left part	1
6	B166741106002070L	法兰面螺栓M6×20(凹穴)	Bolt M6×20	2
7	91302-0060-18090L	翻边垫Φ6×φ18×9-1.5	Flanged washer Φ6×φ18×9-1.5	2
8	63342-H206-0100	ZS110-26(Ⅱ)车体盖胶塞	Rubber plug,vehicle	2
9	41474-J0A2-0000	座垫锁卡簧	Check spring,seat lock	1
10	41473-J0A2-0000	座垫锁安装支架	Mounting,seat lock	1
11	41470-J0A2-0000	座垫锁	Seat lock	1
12	84200-J0A2-0000	点火开关锁	Ignition key	1
13	61110-J0A2-C000	油箱盖锁	Fuel tank cap	1
14	08310-I126-0000	全车钥匙	Keys	2
15	07002-J0A2-C000	ZS150-48A全车锁(国Ⅱ状态、出口)	Vehicle lock	1
16	63352-J0A2-C0N4A7	ZS150-48A右车体盖(有孔,6010+6008、N4#)	Cap,vehicle right part	1
16	63352-J0A2-C0N392	ZS150-48A右车体盖(有孔,1530+6008、N3#)	Cap,vehicle right part	1
16	63352-J0A2-C0N3RU	ZS150-48A右车体盖(有孔,4521+6008、N3#)	Cap,vehicle right part	1
17	6222A-0000-1200	工字形胶垫(φ8.5×φ12×φ17-(2.5+3+2.5))	H shape rubber washe	4
18	B008180006001620L	十字槽盘头螺钉M6×16	Screw M6×16	2
19	B0007001050012Z00	GB/T70.1内六角螺钉M5×12(不锈钢)	Screw M5×12	5
20	B0007001050020Z00	GB/T70.1内六角螺钉M5×20(不锈钢)	Screw M5×20	3





NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	B061870214000060L	法兰面锁紧螺母M14×1.5	Nut M14×1.5	1
2	35281-J0A2-00000L	ZS150-48A平叉轴(军绿)	Shaft,fork	1
3	35001-J0A2-C200	ZS150-48A链条护卡(哥伦比亚修模加厚状态)	Protecting clip,chain	1
4	3500A-J0A2-0000	ZS150-48B链条上护卡(黑坏)	Upper protecting clip,chain	1
5	91302-0060-18070L	翻边垫φ6×φ18-7(军绿)	Flanged washer 6×φ18-7	1
6	35200-J0A2-C4006N	ZS150-48A平叉总成(内挡泥板、升级版、中心后减、粉亮黑)	Fork assembly	1
7	B061870210000060L	法兰面锁紧螺母M10×1.25	Nut M10×1.25	1
8	B061870212000060L	法兰面锁紧螺母M12×1.25	Nut M12×1.25	1
9	33300-J0A2-0500	ZS150-48B后减震器(单)	Rear absorber shock	1
10	B166741210005572L	法兰面螺栓M10×1.25×55	Bolt M10×1.25×55	1
11	B1667412120060T0L	GB/T16674-2螺栓M12×1.25×60(军绿9.8级)	Bolt M12×1.25×60	1
12	26402-0000-0100	链条滑块	Chain slider	1
13	9A114-1060-01670L	十字大扁头螺钉M6×16(φ16、军绿8.8级)	Screw M6×16	1
14				
15				
16				
17				
18				
19				
20				




www.seacubemoto.com

NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	63127-J0A2-0000	ZS150-48A前挡泥板左装饰盖	Left decoration cap,front fender	1
2	91218-1060-022T0U	弹性翻边螺纹卡子M6-22.3×15	Clip M6-22.3×15	2
3	63126-J0A2-0000	ZS150-48A前挡泥板右装饰盖	Right decoration cap,front fender	1
4	63104-J0A2-C0N468	ZS150-48A前挡泥板(黑闪金黑、N4#)	Front fender	1
4	63104-J0A2-C0N398	ZS150-48A前挡泥板(MANA850红、N3#)	Front fender	2
4	63104-J0A2-C0N3HF	ZS150-48A前挡泥板(秘鲁蓝、N3#)	Front fender	3
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	51103-J0A2-C100	ZS150-48A前轮外胎(不带中文字样)(90/90-17/正新/真空)	Shoe,front wheel	1
	2	51120-J0A2-000065Q	ZS150-48A前铝轮(2.15-17/真空/红圈/珍珠黑)	Front aluminum wheel	1
	3	51122-J0A2-000065	前铝轮主体	Main body, front aluminum wheel	1
	4	51116-0000-2000	油封18×37×6	Oil seal 18×37×6	1
	5	92102-00006301-RS	轴承6301-RS	Bearing	2
	6	51108-0000-0500	支承圈φ31×φ18×4	Supporting ring φ31×φ18×4	1
	7	51117-0000-B000	轮毂内衬套φ18×φ13.5×51	Inner bush φ18×φ13.5×51,Hub	1
	8	B061870212000060L	法兰面锁紧螺母M12×1.25	Nut m12×1.25	1
	9	51101-J0A2-00000L	ZS150-48A前轮左衬套(军绿)	Left bush,front wheel	1
	10	51181-J0A2-00000L	ZS150-48A前轮轴(军绿)	Axle,front wheel	1
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				





NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	51203-J0A2-C100	ZS150-48A后轮外胎(不带中文字样)(110/80-17/正新/真空)	Shoe,rear wheel	1
2	51220-J0A2-C20065Q	ZS150-48B后铝轮(碟/2.75-17/真空/黑色+窄红圈/升级版)	Rear aluminum wheel	1
3	51223-J0A2-C20065	后铝轮主体	Main body, rear aluminum wheel	1
4	92102-0006302-RS	轴承6302-RS	Bearing 6302-rs	1
5	51108-0000-0600	支撑圈φ31xφ22x4	Supporting ring	1
6	51117-0000-B100	轮毂内衬套轮毂内衬套φ22×φ16×62	Inner bush φ22×φ16×62,hub	1
7	92102-0006202-RS	轴承6202-RS	Bearing 6202-rs	1
8	35014-J0A2-00000L	ZS150-48A链条调节器本体(军绿)	Adjuster,chain	2
9	35004-J0A2-010071	ZS150-48B链条调节器压块(铝合金、银白)	Pressing block,chain adjuster	2
10	B061870214000060L	法兰面锁紧螺母M14×1.5	Nut m14×1.5	1
11	51202-J0A2-01000L	ZS150-48B后轮右衬套(军绿)	Right bush,rear wheel	1
12	51201-J0A2-00000L	ZS150-48A后轮左衬套(军绿)	Left bush,rear wheel	1
13	51281-J0A2-00000L	ZS150-48A后轮轴(军绿)	Axle,rear wheel	1
14	51218-0000-3300	后轮缓冲块	Buffer block,rear wheel	1
15				
16				
17				
18				
19				
20				

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	55000-J0A2-00000B	ZS150-48A缓冲体总成(42齿,自带标件,链盘白锌)	Buffer assembly	1
	2	B057820008003070B	螺栓 M8×33	Bolt m8×33	4
	3	B061700008000060B	螺母 M8	Nut m8	4
	4	55007-I126-1000	缓冲体锁片	Lock of buffer	2
	5	55002-J0A2-0000	链 轮	Chain wheel	1
	6	92102-0006204-2RS	轴 承 6204-2RS	Bearing 6204-2RS	1
	7	55005-0000-1100	缓冲体油封 27×47×7/11	Oil seal of buffer 27×47×7/11	1
	8	55015-I219-0000	缓冲体内衬套	Inner bush of buffer	1
	9	55001-I219-0000	缓冲单体	Buffer	1
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

CLEANER

Revision Number Page:26


	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	16100-J0A2-0200	ZS150-48B空滤器(中心后减、PB150)	Air cleaner	1
	2	B166741106001670L	法兰面螺栓M6×16（凹穴）	Bolt m6×16	2
	3	B0009601060000K0L	大平垫6	Washer 6	2
	4	B008450004201220C	十字槽盘头自攻螺钉ST4.2×12	Screw st4.2×12	5
	5	16105-J0A2-0000	空滤器盖	Cap,air cleaner	1
	6	1611A-J0A2-0000	空滤器滤芯组件	Core,air cleaner	1
	7	16116-J0A2-0000	空滤器外壳	Shell,air cleaner	1
	8	16114-J0A2-0000	空滤器滤网	Filtering net,air cleaner	1
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				



www.seacubemoto.com

Revision Number Page:27


NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	41100-J0A2-0000	ZS150-48A连体座垫	Seat	1
2	42411-J0A2-0000	ZS150-48A杂物箱(黑坯)	Tidy	1
3	41490-H418-00000C	ZS110-53座垫锁座(彩锌)	Lock seat,seat	1
4	4147G-J0A2-00006N	ZS150-48A座垫锁座安装板(粉亮黑)	Seat lock mounting plate	1
5	B061770106000060L	法兰面螺母M6（磨盘齿）	Nut M6	2
6	91302-0060-18090L	翻边垫Φ6×φ18×9-1.5	Flanged washer Φ6×φ18×9-1.5	2
7	B166741106001270L	法兰面螺栓M6×12（凹穴）	Flange boltm M6×12	2
8	B008180005001020L	十字槽盘头螺钉M5×10	Screw M5×10	2
9	B166741106001670L	法兰面螺栓M6×16（凹穴）	Bolt M6×16	2
10	6222A-0000-1200	工字形胶垫(φ8.5×φ12×φ17-(2.5+3+2.5))	Rubber washer (φ8.5×φ12×φ17-(2.5+3+2.5))	2
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




		Revision Number Page:30		
NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	31100-J0A2-11006N	ZS150-48A车架(升级版，粉亮黑)	Frame	1
2	7117D-J0A2-00006N	ZS150-48A下连接板支架(粉亮黑)	Bracket,lower connecting board	1
3	B061870108000060L	法兰面锁紧螺母M8	Nut M8	4
4	32303-J844-00006N	ZS150-38A发动机前悬挂组合(粉亮黑)	Front suspension, engine	1
5	B166741108007070L	法兰面螺栓（凹穴）M8×70	Bolt M8×70	2
6	B1667411080090T0L	法兰面螺栓(40Cr)M8×90	Bolt M8×90	2
7	08216-0000-2200	扎带L=250mm(尼龙、黑, 宽3. 5mm)	Tie belt L=250mm	10
8	08216-0000-1500	复合扎带L=123(带线卡)	Tie belt L=123mm	1
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				

WHOLE CHAIN CASE/CHAIN

NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	9A113-1060-0100	十字大扁头螺钉M6×10	Screw m6×10	2
2	63342-H206-0100	ZS110-26(II)车体盖胶塞	Rubber plug,vehicle	2
3	35110-J0A2-0100	ZS150-48B半链盒(黑坯)	Half chain case	1
4	26400-428H-0128	链条（428H×128节）	Chain	1
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	52215-J0A2-00000L	ZS150-48B后制动臂扭簧(军绿)	Torsion spring	1
	2	B061700006000060L	六角螺母M6	Nut m6	1
	3	B057830006002570L	六角头螺栓M6×25	Bolt m6×25	1
	4	52100-J0A2-020071	ZS150-48A后制动臂(脚启动、银白)	Rear braking lever	1
	5	52101-J0A2-01000C	ZS150-48B后制动拐臂(彩锌)	Regulating lever, rear brake	1
	6	B057830006002070L	六角头螺栓M6×20	Bolt m6×20	1
	7	24400-J0A2-020071	ZS150-48A变速踏板组合(加长、银白)	Gear shift footpeg	1
	8	B008940112000000S	轴用挡圈12	Check ring	1
	9	91301-0120-20020L	平垫圈 φ12×φ20×2	Washer φ12×φ20×2	1
	10	B000700108003070G	内六角圆柱头螺钉M8×30	Screw M8×30	1
	11	21136-1256-0000	防水蹄套	Waterproof sleeve	1
	12	21200-1256-00009X	ZS125-70启动臂(泳闪银)	Starting arm	1
	13	21201-J0A2-00006N	ZS150-48A启动臂限位杆(粉亮黑)	Limit lever, starting arm	1
	14	B166741108002070L	法兰面螺栓(凹穴)M8×20	Bolt M8×20	4
	15	B000930008000000L	弹圈φ8	Spring washer 8	4
	16	B0009701080000K0L	GB/T97平垫φ8(军绿140HV)	washer 8	4
	17				
	18				
	19				
	20				


TANK




NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	62143-0000-0400	单层油管 (φ5×φ9+φ7×φ11(700+20)、耐油)	Oil pipe (φ5×φ9×720)	1
2	61100-J0A2-C1N468	ZS150-48A油箱 (国II、黑闪金黑、N4#)	Fuel tank	1
2	61100-J0A2-C1N398	ZS150-48A油箱 (国II、MANA850红、N3#)	Fuel tank	1
2	61100-J0A2-C1N3HF	ZS150-48A油箱 (国II、秘鲁蓝、N3#)	Fuel tank	1
3	B061770106000060L	法兰面螺母M6 (磨盘齿)	Nut m6	4
4	87200-J0A2-00000C	ZS150-48A燃油传感器 (彩锌)	Fuel snesor	1
5	61150-J0A2-0000	ZS150-48A油开关	Fuel cock	1
6	B166741106001270L	法兰面螺栓M6×12 (凹穴)	Bolt m6×12	2
7	61267-J0A2-00006N	ZS150-48A油箱左装饰罩支架 (粉亮黑)	Bracket,fuel tank left decoration cover	1
8	61277-J0A2-00006N	ZS150-48A油箱右装饰罩支架 (粉亮黑)	Bracket,fuel tank right decoration cover	1
9	61180-0000-0389	燃油过滤器 (一体式、耐油)	Fuel filter	1
10	B166741106004070L	六角头螺栓M6×40	Bolt m6×40	2
11	61127-I538-00000C	油箱衬套 (长度20mm)	Bush,fuel tank	2
12	61119-I219-0000	油箱后缓冲胶圈	Rear buffer rubber ring,fuel tank	2
13	91301-0060-25020L	平垫圈 φ6×φ25×2	Washer φ6×φ25×2	2
14	61111-I219-0000	油箱前缓冲套	Front buffer bush,fuel tank	2
15	61112-I538-0200	油箱后缓冲套	Rear buffer bush,fuel tank	1
16	91402-0075-07510C	卡簧φ7.5 (彩锌)	clip spring φ7.5	4
17	61302-0000-6000	复合油管 (φ4×φ8×100、耐油)	Oil pipe (φ4×φ8×100)	1
18	61302-0000-2600	复合油管 (φ4×φ8×150、耐油)	Oil pipe (φ4×φ8×150)	1
19				
20				

NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	9A118-1060-016700	锥头内六角螺钉M6×16(盘φ13.5)	Screw M6×16	2
2	9A139-1060-016700	内六角大扁头台阶螺栓M6×16(台阶φ8.5×5.5)	Bolt M6×16	2
3	61131-J0A2-C0N466	ZS150-48A油箱左装饰罩(亚黑、N4#)	Left decoration cover,fuel tank	1
3	61131-J0A2-C0N366	ZS150-48A油箱左装饰罩(亚黑、N3#)	Left decoration cover,fuel tank	1
4	61132-J0A2-C0N466	ZS150-48A油箱右装饰罩(亚黑、N4#)	Right decoration cover,fuel tank	1
4	61132-J0A2-C0N366	ZS150-48A油箱右装饰罩(亚黑、N3#)	Right decoration cover,fuel tank	1
5	6113A-J0A2-0000	ZS150-48A油箱左装饰罩背板	The left decorative cover rear panel of fuel tank	1
6	6113B-J0A2-0000	ZS150-48A油箱右装饰罩背板	The right decorative cover rear panel of fuel tank	1
7	9A133-1042-013X0L	自攻螺钉(盘φ9)ST4.2×13	Screw ST4.2×13	8
8				
8				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	32281-J0A2-00000L	ZS150-48A主支架轴(军绿)	Shaft,main bracket	1
	2	32204-I126-0100	主支架减震垫	Damping pad,main bracket	1
	3	91301-0170-23020L	平垫圈 $\phi 17 \times \phi 23 \times 1.5$	Washer $\phi 17 \times \phi 23 \times 1.5$	1
	4	B008940116000000S	轴用挡圈 16	Shaft clip ring 16	1
	5	32202-J0A2-00000L	ZS150-48A主支架弹簧(军绿)	Spring,main bracket	1
	6	32200-J0A2-01006N	ZS150-48A主支架(CG平衡轴、粉亮黑)	Main bracket	1
	7	91113-6100-03570L	非标六角台阶螺栓M10 $\times$ 1.25 $\times$ 35	Bolt M10 $\times$ 1.25 $\times$ 35	1
	8	32130-J0A2-00006N	ZS150-48A侧支架(粉亮黑)	side bracket	1
	9	B061770210000060L	法兰面螺母M10 $\times$ 1.25(磨盘齿)	Nut M10 $\times$ 1.25	1
	10	32102-J0A2-00000L	ZS150-48A侧支架弹簧(军绿)	Spring,side bracket	1
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				



www.seacubemoto.com

NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	86700-J0A2-0000	ZS150-48A后牌照灯	Rear licence plate lamp	1
2	86720-0000-0000	后牌照灯灯泡(12V/5W)	bulb(12V/5W), rear licence plate lamp	1
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				




NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	9A133-1042-016X0L	自攻螺钉 (盘 φ9) ST4. 2×16	Screw st4.2×16	5
2	91205-1042-01700L	自攻卡子ST4.2×17	Self-tapping clip st4.2×17	5
3	63201-J0A2-0100	ZS150-48B后挡泥板前段 (中心后减、黑坯)	Front part,rear fender	1
4	6222A-0000-1200	工字形胶垫 (φ 8. 5× φ 12× φ 17- (2. 5+3+2. 5)	H shape rubber washer(φ8.5×φ12×φ17-(2.5+3+2.5)	1
5	6320B-J0A2-0000	后牌照支撑 (铝合金)	Support,rear licence	1
6	63206-J0A2-00006N	ZS150-48A后牌照支架	Bracket,rear licence	1
7	86708-J0A2-00006N	ZS150-48A后牌照灯安装支架	Mounting,rear licence plate lamp	1
8	6321H-J0A2-0000	ZS150-48A后挡泥板嵌件 (PP)	Rear fender inserts	1
9	63215-J0A2-0000	后挡泥板胶塞φ18.5×φ15.5×φ21×7(5230020-103604)天然胶	Rubber plug φ18.5×φ15.5×φ21×7	2
10	B166741106001670L	法兰面螺栓M6×16 (凹穴)	Bolt m6×16	2
11	6222A-0000-2700	工字形胶垫 (φ 10× φ 13× φ 17. 5-2. 6+2. 8+2. 6)	H shape rubber washer(φ10×φ13×φ17.5-2.6+2.8+2.6)	1
12	63215-H259-0000	后挡泥板胶塞	Rubber plug,rear fender	1
13	85830-H259-0100	ZS110-60后反射器	Reflector, rear	1
14				
15				
16				
17				
18				
19				
20				

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	9A113-1060-01270L	十字大扁头螺钉M6×12(φ14)	Screw M6×12	3
	2	63249-J0A2-0000	ZS150-48B内挡泥板(黑坯)	Inner fender	1
	3	63249-J0A2-0100	ZS150-48A内挡泥板(黑坯14版)	Inner fender	1
	4	6325A-J0A2-00006N	ZS150-48A内挡泥左上支撑(14版)	left upper support,Inner fender	1
	5	6325B-J0A2-00006N	ZS150-48A内挡泥右上支撑(14版)	right upper support,Inner fender	1
	6	63251-J0A2-01006N	ZS150-48A内挡泥板左支承(14版)	left support,Inner fender	1
	7	63252-J0A2-01006N	ZS150-48A内挡泥板右支承(14版)	right support,Inner fender	1
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

CAP


Revision Number Page:41

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	63342-H206-0100	ZS110-26(II) 车体盖胶塞	Rubber plug,vehicle	2
	2	63301-J0A2-C0N466	ZS150-48A左侧盖(亚黑、N4#)	left side cap	1
		63301-J0A2-C0N366	ZS150-48A左侧盖(亚黑、N3#)	left side cap	1
	3	63332-J0A2-C0N466	ZS150-48A右侧盖(亚黑、N4#)	right side cap	1
		63332-J0A2-C0N366	ZS150-48A右侧盖(亚黑、N3#)	right side cap	1
	4	9A118-1060-016700	锥头内六角螺钉M6×16(盘φ13.5)	Screw M6×16	2
	5	91302-0060-18090L	翻边垫Φ6×φ18×9-1.5	Flanged washer Φ6×φ18×9-1.5	2
	6	6222A-0000-1200	工字形胶垫(φ8.5×φ12×φ17-(2.5+3+2.5)、三元乙丙胶)	H shape rubber washer(φ8.5×φ12×φ17-(2.5+3+2.5)	2
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


LOWER COMMUTATION COVER

Revision Number Page:42

NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
1	62502-J0A2-0300	ZS150-48A发动机左下导流罩(ZY发动机, 黑坯)	Left lower commutation cover	1
2	62503-J0A2-0300	ZS150-48A发动机右下导流罩(ZY发动机, 黑坯)	Right lower commutation cover	1
3	9A133-1042-013X0L	自攻螺钉 (盘 Φ9) ST4.2×13	Screw ST4.2×13	3
4	91302-0060-18090L	翻边垫Φ6×φ18×9-1.5	Flanged washer Φ6×φ18×9-1.5	4
5	9A118-1060-016700	锥头内六角螺钉M6×16 (盘 Φ13.5)	Conical head hexagonal	4
6	6222A-0000-1200	工字形胶垫 (Φ8.5×Φ12×Φ17-(2.5+3+2.5)	H shape rubber washe(φ8.5×φ12×φ17-(2.5+3+2.5)	2
7	62518-J0A2-03006N	ZS150-48A发动机下导流罩左支架(ZY发动机/粉亮黑)	Engine lower guide cover left bracket	1
8	62519-J0A2-03006N	ZS150-48A发动机下导流罩右支架(ZY发动机/粉亮黑)	Engine lower guide cover right bracket	1
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				



www.seacubemoto.com

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	42217-J0A2-0000	ZS150-48B左后扶手(黑坯)	Rear armrest	1
	2	9A118-1080-030700	锥头内六角螺钉M8×30 (盘φ17)	Screw M8×30	4
	3	6222A-0000-2200	工字形胶垫 (φ 13× φ 17× φ 26-3+4+3、天然胶)	H shape rubber washe(φ13×φ17×φ26-3+4+3)	4
	4	42218-J0A2-0000	ZS150-48B右后扶手(黑坯)	Right bracket, rear cargo	1
	5	91302-0080-23120L	翻边垫φ8×φ23×11.5-2	Flanged washer φ8×φ23×11.5-2	4
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

Vehicle tools		Revision Number Page:45			
	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	06000-I126-C100	ZS125-2(I)随车工具(白板口袋5/套)	Vehicle tools	1
	2				
	3				
	4				
	5				
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

	NO.	PART CODE	CHINESE DESCRIPTION	ENGLISH DESCRIPTION	QTY
	1	630EF-J0A2-0100	ZS150-48B左车体盖标牌(Z-one-S)	Label,vehicle left part cap	1
	2	630EG-J0A2-0100	ZS150-48B右车体盖标牌(Z-one-S)	Label,vehicle right part cap	1
	3	630FE-J0A2-0000	ZS150-48A仪表罩装饰罩标牌	Label,meter decoration cover	1
	4	630JG-J0A2-0000	ZS150-48方向柱上连接板水晶标贴	Crystal label,steering post upper connecting board	1
	5	63024-J0A2-C290	ZS150-48A侧盖标牌(Z-ONE S, 水晶标)	Label,side cap	2
	6	63021-J0A2-0000	ZS150-48A油箱标牌(银色)	Crystal label,fuel tank	2
	7	63005-J0A2-C000	ZS150-48A驾驶注意标贴(英文)	Label,notes for driving	1
	8	630ED-J0A2-C000	ZS150-48A轮胎参数标贴(英文)	Tire parameter label	1
	9	630EO-J0A2-1200	ZS150-48A前挡风玻璃贴花(2#)	Label,Front windshield	1
	10	63216-0000-C100	后挡泥标贴(ZSR、外贴)	Label,rear fender	1
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				