



ZS110-15(II)摩托车零部件图册
(前碟后鼓、铝轮)V01



发动机 ENGINE			Revision Number Page:2			
NO		PART CODE	DESCRIPTION		QTY	USD
	1	10001-H199-00A016	发动机 (C125)	ENGINE	1	
	2					
	3					
	4					
	5					
	6					
	7					
	8					
	9					
	10					
	11					
	12					
	13					
	14					
	15					
	16					
	17					
	18					
	19					
	20					

www.seacubemoto.com

前照灯/尾灯HEADLIGHT/TAIL LIGHT		Revision Number Page:3			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	9A133-1042-013X0H	扁头自攻钉ST4.2×13(黑锌)	Screw st4.2×13	2
	2	86151-H199-C000	ZS110-15(II) 前大灯左压块	Left pressing block,headlight	1
	3	86152-H199-C000	ZS110-15(II) 前大灯右压块	Right pressing block,headlight	1
	4	86112-0000-0000	前照灯位置灯泡 (12V5W)	Bulb(12v5w) position lamp	1
	5	86160-0000-0100	前照灯灯泡 (12V35/35W尖形)	Bulb 12V35/35W,headlight	1
	6	86200-H199-C100	ZS110-15(II) 尾灯总成(防水,防紫外线,飞利浦灯泡)	Rear lamp assembly	1
	7	86260-0000-0100	尾灯灯泡 (12V21/5W)	Bulb 12v21/5w, rear lamp	1
	8	86340-0000-0400	转向灯灯泡 (12V10W插、橙色)	Bulb 12v10w, turning lamp	2
	9	86100-H199-C600	ZS110-15(II) 前照灯(哥伦比亚)	Headlight	1
	10	B057830006001670X	GB/T5783螺栓M6×16	Bolt M6×16	2
	11	B0009601060000K0X	GB/T96.1平垫6(蓝白锌140HV)	Washer 6	4
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.sealubemoto.com

前照灯灯壳/仪表壳headlight Shell/instrument Shell		Revision Number Page:4			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	9A133-1048-019X0H扁头自攻钉ST4.8×19(黑锌)(Φ9)	Screw st4.8×19	2	
	2	91205-1042-01700X自攻钉卡子ST4.2×17(蓝白锌)	Clip st4.2×17	6	
	3	63501-H199-C0000PZS110-15(II)前照灯灯壳	Shell,headlight	1	
	4	9A133-1042-013X0H扁头自攻钉ST4.2×13(黑锌)(Φ9)	Screw st4.2×13	2	
	5	9A133-1048-016X0H扁头自攻钉ST4.8×16(黑锌)(Φ9)	Screw st4.8×16	2	
	6	72210-H199-C100ZS110-15(II)变光开关	Light shift switch	1	
	7	63505-H199-C000ZS110-15(II)仪表壳(黑坏)	Shell,instrument	1	
	8	72240-H199-C000ZS110-15(II)照明开关	Switch,illuminator	1	
	9	9A133-1042-016X0H扁头自攻钉ST4.2×16(黑锌)	Screw st4.2×16	2	
	10	9A113-1050-01670G十字大扁头螺钉M5×16(8.8级)	Screw m5×16	1	
	11	72220-H199-C000ZS110-15(II)转向灯开关	Switch,turning light	1	
	12	72230-H235-0000ZS110-30喇叭开关按钮	Switch,horn	1	
	13	B0009601050000K0GGB/T96.1平垫5	washer 5	1	
	14	72270-H235-0000ZS110-30电启动开关按钮	Electric starting switch	1	
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

仪表METER		Revision Number Page:5			
NO		PART CODE	DESCRIPTION	QTY	USD
	1	87100-H199-C200	ZS110-15(II) 仪表总成(哥伦比亚专用)	1	
	2	9A133-1048-016X0H	扁头自攻钉ST4.8×16(黑锌)(Φ9)	2	
	3				
	4				
	5				
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seacubemoto.com

手把/后视镜HANDLEBAR/REAR VIEW MIRROR		Revision Number Page:6			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	69110-H281-C00065	ZS110-42B左后视镜(珍珠黑、0609-145)	Left rear view mirror	1
	2	69120-H281-C00065	ZS110-42B右后视镜(珍珠黑、0609-145)	Right rear view mirror	1
	3	72100-H199-C1006N	ZS110-15(II)方向把管(配智能车架, 粉亮黑)	Tube,steering handlebar	1
	4	72010-G129-020065	ZS100-9左手把胶套(凹花纹、珍珠黑)	Rubber bush,left handlebar	1
	5	72030-H136-000065	ZS110-9装饰头组件(珍珠黑)	Decoration head	2
	6	72020-G129-020065	ZS100-9右手把胶套组合	Rubber bush assembly,right handlebar	1
	7	B0009601050000K0G	GB/T96. 1平垫5(镀铬140HV)	Washer 5	1
	8	B008180005001220X	GB/T818螺钉M5×12	Screw m5×12	1
	9	72208-H235-0000	ZS110-30风门手柄	Handlebar,choke	1
	10	72207-H235-0000	ZS110-30风门支架(座)	Bracket,choke	1
	11	B008180005001020X	GB/T818螺钉M5×10	Screw m5×10	1
	12	17010-H235-0200	ZS110-30加油器固定座(整圈定位)	Fixing seat,oiler	1
	13	B061870210000060X	锁紧螺母M10×1. 25	Locknut m10×1.25	1
	14	72118-0000-00000X	方向把管锁紧衬套(蓝白锌)	Locking bush,steering handlebar tube	1
	15	B166740210005070X	螺栓M10×1. 25×50	Bolt m10×1.25×50	1
	16				
	17				
	18				
	19				
	20				


www.sealubemoto.com

前碟刹FRONT DISC BRAKE		Revision Number Page:7				
NO	PART CODE	DESCRIPTION	QTY	USD		
	1	53001-G272-00000L	ZS100-9D前制动盘(军绿)	Front brake disc	1	
	2	B166740106002070X	GB/T16674. 1螺栓M6×20	Bolt m6×20	5	
	3	B166740108002570X	GB/T16674. 1螺栓M8×25	Bolt m8×25	2	
	4	53000-H199-C000	ZS110-15(II)前碟刹总成(新状态管夹,带保护弹簧)	Front disc brake assembly	1	
	5	53014-H199-C000	前碟刹下泵	Lower pump,front disc brake	1	
	6	5307Y-H199-C000	前碟刹摩擦片组合	Friction disc component,front disc brake	2	
	7	53002-H199-C000	前碟刹油管	Oil pipe,front disc brake	1	
	8	72310-H199-C000	右手柄	Brake handlebar	1	
	9	53012-H199-C000	前碟刹上泵	Upper pump,front disc brake	1	
	10					
	11					
	12					
	13					
	14					
	15					
	16					
	17					
	18					
	19					
	20					


www.seacubemoto.com

前转向灯FRONT TURNING LIGHT		Revision Number Page:8				
NO	PART CODE	DESCRIPTION		QTY	USD	
	1	86340-0000-0400	转向灯灯泡 (12V10W插、橙色) (S)	Bulb 12V10W,turning lmap	2	
	2	86300-H199-C100	ZS110-15 (II) 前左转向灯 (防水, 防紫外线, 白灯罩)	Left turning lamp, front	1	
	3	86400-H199-C100	ZS110-15 (II) 前右转向灯 (防水, 防紫外线, 白灯罩)	Right turning lamp, front	1	
	4	9A133-1042-016X0H	扁头自攻钉ST4. 2×16 (黑锌450HV)	Self tapping screw ST4.2×16	6	
	5	B0009601050000K0G	GB/T96. 1平垫5 (镀铬140HV)	washer 5	6	
	6					
	7					
	8					
	9					
	10					
	11					
	12					
	13					
	14					
	15					
	16					
	17					
	18					
	19					
	20					

www.seacubemoto.com

电气元件ELECTRIC PARTS		Revision Number Page:9			
NO	PART CODE	DESCRIPTION		QTY	USD
	1	85100-H199-C100	ZS110-15(II) 主电缆 (12V全波交流, 哥伦比亚, 带防水套)	Main cable	1
	2	85171-H199-C100	保险管10A	Fuse 10a	1
	3	B166740106001270X	GB/T16674. 1螺栓M6×12	Bolt m6×12	1
	4	85500-G124-C000	ZS100喇叭(单喇叭, 不锈钢, 出口)	Horn	1
	5	81200-H206-0000	ZS110-26(II) 点火器	Ignitor	1
	6	B166740106001670X	GB/T16674. 1螺栓M6×16	Bolt m6×16	1
	7	85600-I126-0800	ZS125-2闪光器(精品)	Flasher	1
	8	B057830005001620X	GB/T5783螺栓M5×16	Bolt m5×16	1
	9	B0009701050000K0X	GB/T97. 1平垫 φ5 (蓝白锌140HV)	Washer 5	3
	10	81100-I126-C000	ZS125-2点火线圈(出口带火花塞帽)	Ignition coil	1
	11	83100-H206-0000	ZS110-26(II) 调压整流器	Rectifier	2
	12	08216-0000-0200	扎带L=220mm	Tie belt L=220mm	3
	13	82290-I126-0500	ZS125-2启动继电器	Starting relay	1
	14	84600-H199-C100	后制动灯开关	Rear brake lamp switch	1
	15				
	16				
	17				
	18				
	19				
	20				


www.sealubemoto.com

操纵拉索CONTROL CABLE		Revision Number Page:10			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	87300-H136-01000B	ZS110-9里程表软轴(碟, 916mm, 接头白锌)	Cable,odometer	1
	2	72700-G272-00000B	ZS100-9D风门拉索(接头白锌)	Cable,choke	1
	3	72400-I225-C0000B	ZS125-40B油门拉索(102mm, 接头白锌)	Cable,throttle	1
	4				
	5				
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

方向柱/前减震器STREERING STEM/FRONT ABSORBER		Revision Number Page:11			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	71201-G124-0000	轴承上挡圈 (26)	Upper check ring,bearing	1
	2	71203-G124-0000	轴承上座圈 (45)	Upper seat ring,bearing	1
	3	71204-G124-0000	轴承下座圈 (54)	Lower seat ring,bearing	1
	4	71202-G124-0000	轴承下挡圈 (34)	Lower check ring,bearing	1
	5	71205-0000-0000	钢球 (Φ 4. 7625)	Iron ball(Φ 4.7625)	52
	6	71106-H199-C000	方向柱锁紧螺母	Locking nut,steering handlebar	1
	7	71135-H199-C000	方向柱卡圈	Circlip,steering post	1
	8	71105-H199-C000	方向柱调节螺母	Adjusting nut,steering post	1
	9	71121-H199-C0006N	方向柱立管	Standing tube, steering post	1
	10	71100-H199-C0006N	ZS110-15 (II) 方向柱总成 (粉亮黑)	Steering post assemblby	1
	11	B166740210004570X	螺栓M10×1. 25×45	Bolt m10×1.25×45	4
	12	34100-H199-C00065	ZS110-15 (II) 左前减震器 (碟)	Front absorber, left	1
	13	34200-H199-C00065	ZS110-15 (II) 右前减震器 (碟)	Front absorber, right	1
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

油箱FUEL TANK		Revision Number Page:12			
		PART CODE	DESCRIPTION	QTY	USD
	1	61100-G272-000065	ZS100-9D油箱(珍珠黑)	Fuel tank	1
	2	B166740106001270X	GB/T16674.1螺栓M6×12	Bolt m6×12	4
	3	61180-0000-0100	燃油过滤器(耐油)	Fuel filter	1
	4	07002-H199-C000	ZS110-15(II)全车锁(二锁及油箱盖)	Vehicle lock	1
	5	87200-I225-C100	ZS125-40B燃油传感器(泰国耐乙醇)	Fuel sensor	1
	6	61302-0000-0700	复合油管(Φ4×Φ8×140、耐油)	Fuel tube 140mm	1
	7	91402-0075-07510X	卡簧Φ7.5(蓝白锌)	Circlip Φ7.5	4
	8	61302-0000-4100	复合油管(Φ4×Φ8×540、耐油)	Fuel tube 540mm	1
	9	B008190006001220X	GB/T819沉头螺钉M6×12	Screw M6×12	2
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

座垫SEAT		Revision Number Page:13			
		PART CODE	DESCRIPTION		QTYUSD
	1	41100-H199-C300	ZS110-15(II) 双人座垫 (无座垫皮及座垫泡沫)	Seats for double men	1
	2	B061770106000060X	GB/T6177.1 螺母M6	Nut m6	2
	3	41490-H199-C0000X	ZS110-15(II) 座垫锁座 (蓝白锌)	Lock seat,seat	1
	4				
	5				
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

杂物箱TIDY		Revision Number Page:14			
NO	PART CODE	DESCRIPTION		QTY	USD
	1	42411-H199-C000	ZS110-15(II) 杂物箱(黑坯)	Goods box	1
	2	42423-I225-0100	ZS125-40B杂物箱上胶垫	Damping pad,goods box	4
	3	91302-0060-20150X	翻边垫 $\phi 6\times 20\times 2-15$ (蓝白锌)	Flanged washer $\phi 6\times 20\times 2-15$	2
	4	91302-0060-20180X	翻边垫 $\phi 6\times 20\times 2-18$ (蓝白锌)	Flanged washer $\phi 6\times 20\times 2-18$	2
	5	B166740106003070X	GB/T16674. 1螺栓M6 $\times$ 30	Bolt m6 $\times$ 30	4
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

蓄电池BATTERY		Revision Number Page:15			
NO	PART CODE	DESCRIPTION		QTY	USD
	1	63706-H199-C000	ZS110-15(II) 蓄电池盒盖(黑坯)	1	
	2	83200-C000-0700	蓄电池(12N5-3B干荷式出口)	1	
	3	83230-0000-0400	电解液(12N5-3B)	1	
	4	91207-1050-01800X	螺纹卡子M5×17.5(蓝白锌)	1	
	5	9A112-1050-01620X	十字带垫螺钉M5×16(Φ7×1.5)	1	
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seacubemoto.com

化油器/进气管CARBURETOR/INTAKE PIPE			Revision Number Page:16			
NO		PART CODE	DESCRIPTION		QTY	USD
	1	B166740106002571X	GB/T16674. 1螺栓M6×25 (Φ11)	Bolt m6×25	4	
	2	15801-H206-0000	ZS110-26 (II) 进气管石棉垫	Heat insulating gasket	1	
	3	15810-H206-0000	ZS110-26 (II) 进气管密封垫	Gasket,intake pipe	1	
	4	15834-H206-0000	ZS110-26进气管密封垫O型圈	O-ring	1	
	5	15800-I225-C000	ZS125-40B进气管	Intake pipe	1	
	6	17100-I355-C700	ZS125-47化油器	Carburetor	1	
	7					
	8					
	9					
	10					
	11					
	12					
	13					
	14					
	15					
	16					
	17					
	18					
	19					
	20					


www.seacubemoto.com

排气消声器MUFFLER		Revision Number Page:17			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	B166740108003570X	GB/T16674. 1螺栓M8×35	Bolt m8×35	1
	2	B0009601080000K0X	GB/T96. 1平垫8	Washer 8	2
	3	B061870108000060X	GB/T6187. 1锁紧螺母M8	Nut m8	1
	4	18000-H199-C3000G	ZS110-15(II)排气消声器(三悬挂, 智能车架, AKT字样, 镀铬)	Muffler	1
	5	B009230006001730X	GB/T923 盖形螺母M6×17	Cap nut m6×17	2
	6	18030-H206-0000	ZS110-26(II)排气消声器密封垫	Seal pad,muffler	1
	7	B166740108001670X	GB/T16674. 1螺栓M8×16	Bolt m8×16	1
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

空滤器AIR CLEANER		Revision Number Page:18			
NO		PART CODE	DESCRIPTION	QTY	USD
	1	B057830006001270X	GB/T5783螺栓M6×12	2	
	2	B0009601060000K0X	GB/T96.1平垫6(蓝白锌140HV)	2	
	3	16100-H199-C400	ZS110-15(II)空滤器(歪嘴,短接头)	1	
	4				
	5				
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

前面罩FRONT WIND COVER		Revision Number Page:19			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	62301-H199-C1000P	ZS110-15(II) 前面罩 (两孔白坯)	Front cover	1
	2	91205-1042-01700X	自攻钉卡子ST4.2×17	Clip ST4.2×17	2
	3	9A114-1060-01670X	十字大扁头螺钉M6×16(Φ16)	Screw (Φ16)M6×16	2
	4	91311-G124-0000W	ZS100(I) 橡胶平垫(Φ5×Φ15)	Rubber pad (Φ5×Φ15)	2
	5	B0009601060000K0G	GB/T96.1平垫6(镀铬140HV)	Washer 6	2
	6	9A133-1042-013X0H	扁头自攻钉ST4.2×13(Φ9)	Screw ST4.2×13(Φ9)	4
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seafiremoto.com

挡风板WIND BOARD		Revision Number Page:20			
NO		PART CODE	DESCRIPTION	QTY	USD
	1	63401-H199-C0000P	ZS110-15(II) 左挡风板(白坯)	Left wind board	1
	2	62402-H199-C400QV	ZS110-15(II) 左护板(哥伦比亚磨砂黑)	Lh.Shield	1
	3	62403-H199-C400QV	ZS110-15(II) 右护板(哥伦比亚磨砂黑)	Rh.Shield	1
	4	63406-H199-C0000P	ZS110-15(II) 右挡风板(白坯)	Right wind board	1
	5	9A133-1048-013X0H	扁头自攻钉ST4.8×13(黑锌450HV)	Screw ST4.8×13	8
	6	9A114-1060-01670G	十字大扁头螺钉M6×16(Φ16)	Screw m6×16(Φ16)	4
	7	B0009601060000K0G	GB/T96.1平垫6(镀铬140HV)	washer Φ6	4
	8	63404-H199-C00065	ZS110-15(II) 挡风板支架	Bracket,wind board	1
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seacubemoto.com

中护板CENTER SHIELD		Revision Number Page:21			
NO		PART CODE	DESCRIPTION	QTY	USD
		1 9A113-1050-01670G	十字大扁头螺钉M5×16	Screw m5×16	5
		2 B0009601050000K0G	GB/T96. 1平垫5	Washer 5	5
		3 91207-1050-01800X	螺纹卡子M5×17. 5	Clip m5×17.5	5
		4 62201-H199-C000	ZS110-15 (II) 中护板	Central protecting board	1
		5 9A133-1048-016X0H	扁头自攻钉ST4. 8×16	Screw ST4.8×16	3
		6 B0009601060000K0G	GB/T96. 1平垫6	Washer 6	2
		7 9A114-1060-01670G	十字大扁头螺钉M6×16	Screw m6×16	2
		8 63360-H199-C000	ZS110-15 (II) 右车体胶护板	Rubber protecting board,vehicle right part	1
		9 63350-H199-C000	ZS110-15 (II) 左车体胶护板	Rubber protecting board,vehicle left part	1
		10			
		11			
		12			
		13			
		14			
		15			
		16			
		17			
		18			
		19			
		20			


www.seacubemoto.com

车体盖VEHICLE CAP		Revision Number Page:22				
NO		PART CODE	DESCRIPTION		QTY	USD
	1	9A114-1060-01670G	十字大扁头螺钉M6×16	Screw m6×16	2	
	2	63341-H199-C0000P	ZS110-15(II)左车体盖(白坯)	Cap, vehicle left part	1	
	3	63352-H199-C0000P	ZS110-15(II)右车体盖(白坯)	Cap,vehicle right part	1	
	4	63602-H199-C0000P	ZS110-15(II)尾盖(白坯)	Tail cap	1	
	5	9A133-1042-013X0H	扁头自攻钉ST4. 2×13(黑锌)	Screw st4.2×13	4	
	6					
	7					
	8					
	9					
	10					
	11					
	12					
	13					
	14					
	15					
	16					
	17					
	18					
	19					
	20					


www.seacubemoto.com

前挡泥板FRONT FENDER		Revision Number Page:23			
NO		PART CODE	DESCRIPTION	QTY	USD
	1	63101-H199-C0000P	ZS110-15(II) 前挡泥板前体(白坯)	Front part,front fender	1
	2	63113-J110-0000	ZS150-15前挡泥板胶垫	Rubber pad,fr.Fender	4
	3	B166740106001270X	GB/T16674. 1螺栓M6×12(蓝白锌8. 8级)	Bolt m6×12	2
	4	B0009601060000K0X	GB/T96. 1平垫6(蓝白锌140HV)	Washer 6	3
	5	63111-G272-0000	ZS100-9D护线环	Wire protecting ring	1
	6	91112-1060-01700X	六角法兰台阶螺栓M6×17(蓝白锌)	Bolt m6×17	2
	7	B166740106002570X	GB/T16674. 1螺栓M6×25(蓝白锌8. 8级)	Bolt m6×25	1
	8	91207-1060-01900X	螺纹卡子M6×19(蓝白锌)	Clip m6×19	1
	9	63102-I225-C400	ZS125-40B前挡泥板后体(新款亚洲豹)	Rear part,front fender	1
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.sealubemoto.com

后挡泥板REAR FENDER		Revision Number Page:24					
		PART CODE	DESCRIPTION		QTY	USD	
		1	63203-H199-C000	ZS110-15(Ⅱ)后挡泥板(黑坯)	Rear fender	1	
		2	B057830006001670X	GB/T5783螺栓M6×16	Bolt m6×16	4	
		3	B0009601060000K0X	GB/T96. 1平垫6(蓝白锌140HV)	Washer 6	4	
		4	9A113-1050-01670G	十字大扁头螺钉M5×16	Screw M5×16	6	
		5	B0009601050000K0G	GB/T96. 1平垫5	Washer 5	6	
		6	91207-1050-01800X	螺纹卡子M5×17. 5(蓝白锌)	Clip M5×17.5	6	
		7	85830-H199-C000	ZS110-15(Ⅱ)后反射器	Reflector, rear	1	
		8	86213-G272-0000	ZS100-9D尾灯胶套	Sleeve,rear lamp	1	
		9					
		10					
		11					
		12					
		13					
		14					
		15					
		16					
		17					
		18					
		19					
		20					


www.seaclubmoto.com

前铝轮FRONT ALUMINUM WHEEL		Revision Number Page:25			
		PART CODE	DESCRIPTION	QTY	USD
	1	51120-H199-C00066	ZS110-15(II) 前铝轮(1.4×17, 碟, 六筋, 无亮边, 亚黑)	Front aluminum wheel(1.4×17)	1
	2	51181-I126-00000X	ZS125-2前轮轴(M12×1.25×203)	Axle(M12×1.25×203),front wheel	1
	3	51102-I126-01000X	ZS125-2前轮右衬套(φ12×φ23×20.5碟)	Right bush φ12×φ23×20.5,front wheel	1
	4	B061870212000060X	GB/T6187. 2锁紧螺母M12×1.25	Locknut m12×1.25	1
	5	87330-H136-000066	ZS110-9计速器(亚黑)	Speedcounter	1
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

后制动器/缓冲体REAR BRAKE/BUFFER		Revision Number Page:26			
NO	PART CODE	DESCRIPTION		QTY	USD
	1	55000-H206-C20066	ZS110-26(II) 缓冲体总成(34齿)	Buffer assembly	1
	2	54200-G124-C10066	ZS100后制动器(亚黑)	Rear brake	1
	3	B000910002001800X	GB/T91开口销2×18	Open pin 2×18	1
	4				
	5				
	6				
	7				
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

后制动器 (拆分件) REAR BRAKE		Revision Number Page:27			
NO		PART CODE	DESCRIPTION		QTYUSD
 拆分图仅供参考，请以实物为准！	1	54200-G124-C10066	ZS100后制动器 (亚黑)	Rear brake	1
	2	54205-G124-C10066	后制动器盖	Cap,rear brake	1
	3	54212-G124-C100	后制动器拉臂螺栓	Bolt,rear brake pull arm	1
	4	54209-G124-C100	后制动器凸轮	Cam,rear brake	1
	5	54141-G124-C100	制动器毛毡	Felt,front brake	1
	6	54208-G124-C100	后制动器指示牌	Indicating board,rear brake	1
	7	54207-G124-C100	后制动器拉臂	Pulling arm,rear brake	1
	8	54220-G124-C100	后制动蹄片组件	Pad,rear brake	2
	9	54201-G124-C100	后制动蹄片弹簧	Pad spring,rear brake	2
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				


www.seacubemoto.com

后铝轮REAR ALUMINUM WHEEL		Revision Number Page:28				
NO	PART CODE	DESCRIPTION		QTY	USD	
	1	51220-H199-C00066	ZS110-15(II)后铝轮(1.6×17, 六筋, 无缓冲块, 无亮边, 亚黑)	Rear aluminum wheel(1.6×17)	1	
	2	51281-H199-01000X	ZS110-15(II)后轮轴(M12×1.25×222, 蓝白锌)	Axle(m12×1.25×222),Rear wheel	1	
	3	35012-H206-00000X	ZS110-26(II)右链条调节器(蓝白锌)	Right adjuster,chain	1	
	4	55008-G129-00000X	ZS100-9链轮内衬套(蓝白锌)	Inner bush,sproket	1	
	5	35011-H206-00000X	ZS110-26(II)左链条调节器(蓝白锌)	Left adjuster,chain	1	
	6	55009-G124-00000X	ZS100链轮内衬套调节螺母(蓝白锌)	Adjusting nut,sprocket wheel inner bush	1	
	7	B061870212000060X	GB/T6187.2锁紧螺母M12×1.25	Locknut m12×1.25	1	
	8	51201-H281-00000X	ZS110-42B后轮左衬套(φ17×φ27×17.5)	Left bush(φ17×φ27×17.5),Rear wheel	1	
	9	51202-F122-00000X	ZS90-2后轮右衬套(φ12×φ26×29)	Right bush(φ12×φ26×29),rear wheel	1	
	10					
	11					
	12					
	13					
	14					
	15					
	16					
	17					
	18					
	19					
	20					

www.sealubemoto.com


平叉/后减震器REAR SWING ARM/REAR ABSORBER		Revision Number Page:29			
NO		PART CODE	DESCRIPTION	QTY	USD
	1	35281-H199-01000X	ZS110-15(II) 平叉轴 (10×279, 左端22)	1	
	2	B061730010000060X	GB/T6173螺母M10×1. 25	1	
	3	35200-H199-C0008G	ZS110-15(II) 平叉 (半链盒)	1	
	4	35001-H136-C100	ZS110-9链条护卡 (橡胶)	1	
	5	B166740210003570X	GB/T16674. 2螺栓M10×1. 25×35	2	
	6	33300-H199-C00065	ZS110-15(II) 后减震器	2	
	7	B0009601100000K0X	GB/T96. 1平垫 φ10	2	
	8	B009230010000060G	GB/T923 盖形螺母M10×1. 25	2	
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seacubemoto.com

链盒/链条chain case/CHAIN				Revision Number Page:30	
NO		PART CODE	DESCRIPTION	QTY	USD
	1	35110-H199-C000	ZS110-15(II)半链盒(外星人、黑坯)	Half chain case	1
	2	26400-428H-0104	链条(428H×104节)	Chain (428h×104)	1
	3	B057830006000870X	GB/T5783螺栓M6×8	Bolt m6×8	1
	4	B057830006001670X	GB/T5783螺栓M6×16	Bolt m6×16	1
	5	B061770106000060X	GB/T6177.1螺母M6	Nut M6	1
	6	B0009601060000K0X	GB/T96.1平垫6	Washer 6	2
	7	91302-0060-18040G	翻边垫Φ6×Φ18×4	flanged washer Φ6×Φ18×4	1
	8				
	9				
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seacubemoto.com

后扶手REAR HANDRAIL



	PART CODE	DESCRIPTION	QTY	USD
1	B166740108002570X	GB/T16674. 1螺栓M8×25	Bolt m8×25	4
2	B0009601100000K0X	GB/T96. 1平垫 φ 10 (蓝白锌)	Washer 10	4
3	42200-H199-C000	ZS110-15 (II) 后扶手 (包胶)	Rear handrail	1
4	91311-H199-0000	ZS110-15 (II) 橡胶平垫 (φ 18× φ 30×5)	Rubber washer (φ 18× φ 30×5)	4
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				


www.seacubemoto.com

后脚蹬REAR FOOTREST		Revision Number Page:32				
NO	PART CODE	DESCRIPTION		QTY	USD	
	1	B166740108002570X	GB/T16674. 1螺栓M8×25	Bolt M8×25	2	
	2	32433-H199-C000	ZS110-15(Ⅱ)左后脚蹬装饰件	Decoration parts,left rear footpeg	1	
	3	B061870210000060X	GB/T6187. 2锁紧螺母M10×1. 25	Nut M10×1.25	2	
	4	9A133-1042-013X0H	扁头自攻钉ST4. 2×13(Φ9)	Screw ST4.2×13(Φ9)	2	
	5	32122-H199-C000	ZS110-15(Ⅱ)右后脚蹬装饰件	Decoration parts,right rear footpeg	1	
	6	32410-H199-C40071	ZS110-15(Ⅱ)左后脚蹬总成(哥整改状态, 铝合金, 附件白锌, 银白)	Left rear pedal assembly	1	
	7	32420-H199-C40071	ZS110-15(Ⅱ)右后脚蹬总成(哥整改状态, 铝合金, 附件白锌, 银白)	Right rear footpeg assembly	1	
	8					
	9					
	10					
	11					
	12					
	13					
	14					
	15					
	16					
	17					
	18					
	19					
	20					


www.seacubemoto.com

前脚蹬/支架FRONT FOOTPEG/BACKET		Revision Number Page:33			
NO	PART CODE	DESCRIPTION	QTY	USD	
	1	32101-H206-0000	ZS110-26 (II) 前脚蹬胶套	Rubber bush,front footpeg	2
	2	32100-H199-C3006N	ZS110-15 (II) 前脚蹬总成	Front pedal assembly	1
	3	B000930008000000X	GB/T93弹圈Φ8(蓝白锌)	Elastic pad 8	4
	4	B0009701080000K0X	GB/T97.1平垫Φ8(蓝白锌140HV)	Washer 8	4
	5	B057830008002070X	GB/T5783螺栓M8×20(蓝白锌)	Bolt m8×20	4
	6	B000910003002500X	GB/T91开口销3×25(蓝白锌)	Open pin 3×25	1
	7	91301-0170-23020X	平垫Φ17×Φ23×1.5(蓝白锌)	Washer Φ17×Φ23×1.5	1
	8	32204-G124-0000	ZS100主支架减震垫	Damping pad,main bracket	1
	9	32281-I225-00000X	ZS125-40主支架轴(蓝白锌)	Shaft,main bracket	1
	10	32200-H199-C4006N	ZS110-15 (II) 主支架	Main bracket	1
	11	32203-G272-00000X	ZS100-9D主支架挂勾(蓝白锌)	Hook,main bracket	1
	12	32202-H199-01000X	ZS110-15 (II) 主支架弹簧(82mm)	Spring,main bracket	1
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.sealubemoto.com

脚踏操纵件FOOT CONTROL PARTS		Revision Number Page:34			
NO		PART CODE	DESCRIPTION	QTY	USD
	1	52100-I225-04000G	ZS125-40B后制动臂(小脚踏)	Rear braking lever	1
	2	21200-H206-01000G	ZS110-26(II)启动臂(镀铬)	Starting arm	1
	3	B05783000600227	螺栓M6×22	Bolt m6×22	2
	4	52201-I225-02000X	ZS125-40B后制动臂回位簧(长102mm)	Returning spring, rear brake r	1
	5	B000910002001800X	GB/T91开口销2×18(蓝白锌)	Opening pin 2×18	1
	6	B0009701060000K0X	GB/T97.1平垫6(蓝白锌140HV)	Washer 6	1
	7	52200-H199-C0000X	ZS110-15(II)后制动臂拉杆(480mm)	Pull rod, rear brake	1
	8	24400-G129-00000G	ZS100-9变速踏板(单离合)(镀铬)	Gear shift footpeg	1
	9	84602-I225-01000X	ZS125-40B后制动灯开关簧(长135mm)	Spring, rr. Brake switch	1
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.sealinemoto.com

车架FRAME		Revision Number Page:35			
NO	PART CODE	DESCRIPTION		QTY	USD
	1	31100-H199-C5006N	ZS110-15(II) 车架(三悬挂, 带面板支架)	Frame	1
	2	B057820008011570X	GB/T5782螺栓M8×115(蓝白锌8.8级)	Bolt m8×115	1
	3	B057820008010270X	GB/T5782螺栓M8×102(蓝白锌8.8级)	Bolt m8×102	1
	4	B166740108009070X	GB/T16674. 1螺栓M8×90(蓝白锌8.8级)	Bolt m8×90	1
	5	B061870108000060X	GB/T6187. 1锁紧螺母M8(蓝白锌8级)	Nut M8	3
	6	B166740108003570X	GB/T16674. 1螺栓M8×35(蓝白锌8.8级)	Bolt m8×35	2
	7	06000-I265-C000	LZX125-2随车工具(六件套, 白板)	Vehicle tools	1
	8	31221-G129-0000	ZS100-9前悬挂胶塞	Rubber plug,front suspension	2
	9	B166740106002871G	GB/T16674. 1螺栓M6×28	Bolt M6×28	2
	10				
	11				
	12				
	13				
	14				
	15				
	16				
	17				
	18				
	19				
	20				

www.seacubemoto.com