



气缸头部件/气缸体部件CYLINDER HEAD ASSY/CYLINDER ASSEMBLY					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	11226-I008-000086	CG125D气缸头上盖 (8806)	UPPER COVER, CYLINDER HEAD	1	
2	B057890006002870X	GB5789螺栓M6×28 (兰白锌)	BOLT M6×28	3	
3	B057890006001270X	GB5789螺栓M6×12 (兰白锌)	BOLT M6×12	1	
4	93301-70621513000	70张紧杆注油铝垫圈6.2×1.5×13	WASHER 6.5×1.5×12	1	
5	90103-I008-0000	CG125D气缸头上盖密封圈	SEAL RING OF UPPER COVER, CYLINDER HEAD	1	
6	B061700006000090X	GB6170螺母M6 (兰白锌)	NUT 6	4	
7	91127-I006-0000	CB125脚进气管双头螺栓 (普通 L:27mm)	BOLT	2	
8	B057830006002070X	GB5783螺栓M6×20 (兰白锌)	BOLT M6×20	2	
9	90101-20335000300	CB125进气管O形圈33.5×3 (氟硅胶)	O-RING 33.5×3	1	
10	15800-I006-0018	CB125脚进气管组合 (JQ-18)	INLET PIPE	1	
11	91104-I008-00000X	CG125D缸头缸体螺栓M8×78 (兰白锌)	BOLT M8×78	1	
12	93301-80852018000	CB125盖形螺母铜垫圈8.5×2×18	WASHER 8.5×2×18	1	
13	1122B-J034-000086	CG150D气缸头组合 (8806)	CYLINDER HEAD ASSY	1	
14	91138-I008-00000X	CG125D缸头排气口双头螺栓M6×35 (兰白锌)	BOLT M6×35	2	
15	1572B-I008-0000	CG125D挡油罩组合	SEAL, VALVE STEM	2	
16	81300-I006-0000	CB125脚火花塞部件	SPARK PLUG	1	
17	9022B-J034-0100	CG150D气缸头密封垫组合 (金属)	GASKET ASSY, CYLINDER HEAD	1	
18	91521-I0002000000	CG125脚定位销10×20	PIN 10×20	2	
19	91113-I008-00000X	CG125D缸体箱体连接螺栓M6×22 (兰白锌)	BOLT M6×22	2	
20	1110B-J034-000086	CG150D气缸体部件 (缸标149 8806)	CYLINDER ASSEMBLY	1	
21	90205-J034-0000	CG150D气缸体密封垫	GASKET, CYLINDER BLOCK	1	
22	17100-0000-0078	CG150D化油器 (PZ27 手动无泵)	CARBURETOR	1	
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					




气缸头部件/气缸体部件
CYLINDER HEAD ASSY/CYLINDER ASSEMBLY

配气机构 VALVE MECHANISM					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	15701-J034-0000	CG150D进气门	INLET VALVE	1	
2	15702-J034-0000	CG150D排气门	EXHAUST VALVE	1	
3	15706-I008-0000	CG125D气门外弹簧座圈(下)	RETAINER, VALVE SPRING	2	
4	15708-I008-0000	CG125D气门内弹簧座圈(下)	SPRING SEAT	2	
5	15703-I008-0000	CG125D气门外弹簧	VALVE OUTER SPRING	2	
6	15704-I008-0000	CG125D气门内弹簧	VALVE INNER SPRING	2	
7	15710-I008-0000	CG125D气门内外弹簧组合	INNER SPRING, ASSY	2	
8	15705-I008-0000	CG125D气门弹簧座(上)	SPRING SEAT	2	
9	15707-I008-0000	CG125D气门锁夹	VALVE COTTER	4	
10	15404-I008-0000	CG125D气门间隙调节螺钉	SCREW, VALVE CLEARANCE	2	
11	15403-I008-0000	CG125D气门间隙调节螺母	NUT, VALVE CLEARANCE	2	
12	91180-I008-0000	CG125D上摇臂螺栓M8×28	BOLT M8×28	3	
13	93301-80852018000	CG125上摇臂螺母铜垫圈8.5×2×18	WASHER 8.5×2×18	3	
14	1540A-I008-0000	CG125D气门上摇臂组合	ROCKER ARM ASSEMBLY, VALVE	1	
15	1532A-I008-0001	CG125D-2#铝合金推杆组合	PUSH LEVER COMP	2	
16	93303-51230220900	CG125D下摇臂波形垫圈12.3×0.2×20.9	WAVE WASHER 12.3×0.2×20.9	1	
17	15407-I008-0000	CG125D下摇臂	LOWER ROCKER ARM	2	
18	15408-I008-0000	CG125D下摇臂轴	SHAFT, LOWER ROCKER ARM	1	
19	90101-20180000250	CG125D下摇臂轴O形圈18×2.5(氟硅胶)	O-RING 18×2.5	1	
20	15109-I008-0000	CG125D配气凸轮轴弹簧	SPRING	1	
21	90101-20200000250	CG125D凸轮轴O形圈20×2.5(氟硅胶)	O-RING 20×2.5	1	
22	15105-J034-0000	CG150D配气凸轮芯轴	AIR MLET CAM SHAFT	1	
23	93301-51421024000	CG125D凸轮轴垫圈14.2×1×24	WASHER 14.2×1×24	1	
24	1510A-I008-0000	CG125D正时从动齿部件	NG DRIVEN SPROCKET COMP	1	
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					




配气机构
VALVE MECHANISM

曲轴箱盖 CRANKCASE COVER					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	B166740A06004070X	GB16674小盘螺栓M6×40(兰白锌)	BOLT M6×40	10	
2	B166740A06005070X	GB16674小盘螺栓M6×50(兰白锌)	BOLT M6×50	1	
3	12426-I008-0000	CG125D机油观察窗	OIL LELVE SIGHT WINDOW	1	
4	90304-I006-0000	CB125脚启动轴油封16×28×7(丁腈胶)	OIL SEAL 16×28×7	1	
5	2242A-I008-00000X	CG125D离合器操纵臂组合(兰白锌)	CONTROLLING ARM ASSEMBLY, CLUTCH	1	
6	90101-20065000190	CG125D离合器操纵臂O形圈6.5×1.9(氟硅胶)	O-RING 6.5×1.9	2	
7	22427-I008-0000	CG125D离合器操纵臂弹簧	CLUTCH CONTROLLING ARM SPRING	1	
8	22429-I008-0000	CG125D离合器分离凸轮	CLUTCH SEPARATION CAM	1	
9	91523-I008-0000	CG125D操纵臂卡销	CLUTCH LEVER PIN	1	
10	12421-I008-100185	CG125D右曲轴箱盖(ZONGSHEN 鲸鱼款 8805)电感式	COVER COMP. RIGHT CRANKCASE	1	
11	14301-I006-0000	CB125脚机油尺组合(白板 本色)整体式	OIL RULER ASSY	1	
12	90101-10180000300	CG125机油尺O形圈18×3(丁腈胶)	O-RING 18×3	1	
13	91521-08001400000	70定位销8×14×6.3	PIN 8×14×6.3	2	
14	90206-I008-0000	CG125D右曲轴箱盖密封垫	GASKET, R. CRANKCASE COVER	1	
15	91521-I0001400000	CG125脚定位销10×14	PIN 10×14	2	
16	90101-10132000265	C100小视孔盖O形圈13.2×2.65(丁腈胶)	O-RING 13.2×2.65	1	
17	12303-G011-000085	C100小视孔盖(8805)	CAP. SMALL VIEW HOLE	1	
18	92102-I008-0001	CG125D含油轴承(铁基)	BEARING	1	
19	12301-I008-100085	CG125D左曲轴箱前盖(白板 鲸鱼款 8805)	FRONT PART, L. CRANKCASE COVER	1	
20	90204-I008-0000	CG125D左曲轴箱前盖密封垫	GASKET, L. CRANKCASE COVER	1	
21	90101-10274000265	C100大视孔盖O形圈27.4×2.65(丁腈胶)	O-RING 27.4×2.65	1	
22	12307-I008-10010G	CG125D左前盖装饰盖(ZONGSHEN 鲸鱼款 白铬)	DECORATE COVER, L. CRANKCASE COVER	1	
23	B166740A06002570B	GB16674小盘螺栓M6×25(白锌)	BOLT M6×25	1	
24	12308-I008-400085	CG125D双联齿轮盖(白板 威风款 8805)	COVER, REDUCTION GEAR	1	
25	90101-10620000300	CG125D减速齿轮盖O形圈62×3(丁腈胶)	O-RING 62×3	1	
26	12302-I008-050085	CG125D左曲轴箱后盖(CG125D-JY-26B# 8805)	BACK PART, L. CRANKCASE COVER	1	
27	B166740A06002870X	GB16674小盘螺栓M6×28(兰白锌)	BOLT M6×28	2	
28	B166740A06005070X	GB16674小盘螺栓M6×50(兰白锌)	BOLT M6×50	2	
29	B166740A06004070X	GB16674小盘螺栓M6×40(兰白锌)	BOLT M6×40	5	
30	B166740A06002070X	GB16674小盘螺栓M6×20(兰白锌)	BOLT M6×20	3	
31	B008180006001220X	GB818螺钉M6×12(兰白锌)	SCREW M6×12	4	
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					




离合器总成 CLUTCH ASSY					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	22314-I008-0000	CG125D离合器顶杆	ROD, CLUTCH PUSH	1	附件
2	22401-I008-0000	CG125D离合器分离轴套	SEPARATING AXLE SLEEVE	1	附件
3	B166740A06002270B	GB16674小盘螺栓M6×22(白锌)	BOLT M6×22	4	
4	92102-00000006001	轴承(6001)	BEARING (6001)	1	
5	22121-I008-0000	CG125D离合器端盖	END COVER, CLUTCH	1	
6	22142-I006-0000	CB125脚离合器弹簧	SPRING, CLUTCH	4	
7	91403-I008-0000	CG125D离合器挡圈20	ELASTIC CHECK RING	1	
8	22105-I006-0000	CB125脚离合器中心套	CENTER SLEEVE, CLUTCH	1	
9	22214-I006-0000	CB125脚离合器主动摩擦片	DRIVE FRICTION DISK	5	
10	22215-I006-0000	CB125脚离合器从动摩擦片	OUTER FRICTION DISK A	4	
11	22122-I006-0000	CB125脚离合器压盘	PRESSURE PLATE, CLUTCH	1	
12	22002-I006-0000	CB125脚离合器花键垫圈	KEYWAY WASHER	1	
13	22150-I008-0000	CG125D离合器外罩组合	OUT CASE ASSEMBLY, CLUTCH	1	
14	22000-I008-0100	CG125D-1#离合器总成(普通型 不带轴承)	CLUTCH ASSY	1	
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					



离合器总成


CLUTCH ASSY

机油泵部件/机油滤清器部件 OIL PUMP/OIL FILTER					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	14200-I006-0000	CB125脚机油滤清器部件	OIL FILTER, COMP	1	
2	14201-I006-0000	CB125脚机油滤清器出油管	OIL PIPE	1	
3	B008190105001220B	GB819. 1螺钉M5×12(白锌)	SCREW M5×12	3	
4	14202-I006-0000	CB125脚机油滤清器出油管弹簧	SPRING, OIL PIPE	1	
5	14207-I006-0000	CB125脚机油滤清器盖	OIL FILTER COVER	1	
6	14208-I006-0000	CB125脚机油滤清器开口销	OPEN PIN	1	
7	90209-I006-0000	CB125脚机油滤清器端盖密封垫	GASKET, OIL FILTER	1	
8	91203-I008-0000	CG125D机油滤清器薄螺母	NUT	1	
9	22004-I006-0000	CB125离合器碟形垫圈16. 5×2×27	DISH WASHER, CLUTCH	1	
10	14205-I006-0000	CB125脚机油滤清器体	OIL FILTER BODY	1	
11	23101-I008-0000	CG125D主动齿	PRIMARY DRIVE GEAR	1	
12	90101-I0094000240	CG125机油泵O形圈9. 4×2. 4(丁腈胶)	O-RING 9. 4	2	
13	B008180004001020B	GB818螺钉M4×10(白锌)	SCREW M4×10	2	
14	14108-I008-0000	CG125D机油泵盖板	OIL PUMP COVER	1	
15	14111-I008-0000	CG125D机油泵内转子	INNER ROTOR, OIL PUMP	1	
16	14112-I008-0000	CG125D机油泵外转子	OUTER ROTOR, OIL PUMP	1	
17	14110-I008-0000	CG125D机油泵体(电感式)	OIL PUMP BODY	1	
18	B0011902025100000	GB119. 2销2.5×10	PIN 2. 5×10	1	
19	14107-I008-0000	CG125D机油泵油泵轴(电感式)	SHAFT, OIL PUMP	1	
20	1410B-I008-0001	CG125D机油泵齿轮组合(电感式)PA66	OIL PUMP GEAR ASS.	1	
21	B0089600060000000	GB896挡圈6	CIRCLIP 6	1	
22	B008190106003020B	GB819. 1螺钉M6×30(白锌)	SCREW M6×30	2	
23	14100-I008-0001	CG125D机油泵部件(电感式 材质为PA66)	OIL PUMP ASSY	1	
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					




机油泵部件/机油滤清器部件
OIL PUMP/OIL FILTER


曲轴箱 CRANKCASE					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	B166740A06005570X	GB16674小盘螺栓M6×55(兰白锌)	BOLT M6×55	1	
2	22422-I008-00030X	CG125D-3#离合器钢索支架(兰白锌)	HOLDER, CLUTCH CABLE	1	
3	91101-I008-0100	CG125D-2#气缸双头螺栓A(126mm 油道 螺纹22mm 杆径φ6.3)	CYLINDER STUD BOLT A	1	
4	91101-I008-0200	CG125D-3#气缸双头螺栓A(126mm 螺纹22mm 杆径φ7.5)	CYLINDER STUD BOLT A	1	
5	93301-C125202200B	CG125D B栓平垫圈12.5×2×22(白锌)	WASHER 12.5×2×22	4	
6	91212-I008-00000C	CG125D气缸头AB栓长螺母M8×32(彩锌)	NUT	4	
7	B057890006002870X	GB5789螺栓M6×28(兰白锌)	BOLT M6×28	2	
8	18097-I008-0000	CG125D废气循环管 I 卡箍	CLAMP	1	
9	12130-I008-0001	CG125D-1#通气管组件(复合层材料 卡箍1个)	PIPE ASSY	1	
10	91102-I008-0200	CG125D-3#气缸双头螺栓B(132mm 螺纹22mm 杆径φ7.5)	CYLINDER STUD BOLT B	2	
11	90208-I008-0000	CG125D曲轴箱密封垫	GASKET, CRANKCASE	1	
12	1212B-J034-010085	CG150D-2#左曲轴箱组合(8805)	LEFT CRANKCASE BLOCK	1	
13	12103-I008-0000	CG125D挡线片	POSITION PLATE	1	
14	B166740A06001270B	GB16674小盘螺栓M6×12(白锌)	BOLT M6×12	1	
15	92102-I008-0001	CG125D含油轴承(铁基)	BEARING	1	
16	B166740A06005070X	GB16674小盘螺栓M6×50(兰白锌)	BOLT M6×50	9	
17	B166740A06009570X	GB16674小盘螺栓M6×95(兰白锌)	BOLT M6×95	1	
18	11230-I006-00000W	CB125脚气门室盖(抛丸钝化)	COVER, VALVE CHAMBER	1	
19	90101-20350000300	CB125气门盖O形圈35×3(氟硅胶)	O-RING 35×3	1	
20	14221-I006-0000	CB125脚机油过滤网弹簧	SPRING, OIL FILTER STRAINER	1	
21	1431B-I006-0000	CB125脚机油过滤网组合	STRAINER, OIL FILTER	1	
22	90301-I006-0000	CB125脚换挡臂油封14×28×7(丁腈胶)	OIL-SEAL 14×28×7	1	
23	1213B-I008-0000	CG125D压销体组合	PRESSING PIN BODY ASSY	1	
24	B166740A06002570B	GB16674小盘螺栓M6×25(白锌)	BOLT M6×25	1	
25	91103-I008-00000X	CG125D放油螺塞(兰白锌)	OIL DRAIN PLUG	1	
26	93301-71242020000	CG125D放油螺塞铝垫圈12.4×2×20	WASHER 12.4×2×20	1	
27	90302-I008-0000	CG125D曲轴油封34×50×7(丁腈胶)	OIL-SEAL 34×50×7	1	
28	B057830006001270B	GB5783螺栓M6×12(白锌)	BOLT M6×12	1	
29	15108-I008-0000	CG125D凸轮轴挡板	STOP PLATE, CAMSHAFT	1	
30	92102-0000006202Z	轴承(6202Z)	BEARING (6202Z)	1	
31	92102-000HK212810	滚针轴承(HK212810)	BEARING (HK212810)	1	
32	1222B-J034-000185	CG150D右曲轴箱组合(8805)	RIGHT CRANKCASE BLOCK	1	
33	92102-00000006006	轴承(6006)	BEARING (6006)	1	
34	92102-000NK152312	滚针轴承(NK152312)	BEARING (NK152312)	1	
35	92102-00000006204	轴承(6204)	BEARING (6204)	1	
36	90303-I006-0000	CB125脚副轴油封20×34×7(丁腈胶)	OIL SEAL 20×34×7	1	
37	91521-10001400000	CG125脚定位销10×14	PIN 10×14	4	
38					
39					
40					
41					
42					
43					
44					
45					



曲轴连杆部件/活塞 CRANKSHAFT CONNECTING-ROD ASSY/PISTON					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	1320B-J034-2000	CG150D曲轴连杆部件(立多禄KU)	CRANKSHAFT CONNECTING-ROD ASSY	1	
2	91601-I008-0000	CG125D半圆键25×14×4	SEMICIRCULAR KEY	1	
3	92102-00063-28-P5	轴承 (63/28/P5)	BEARING (63/28/P5)	1	
4	92102-63-28-RS-P5	轴承 (63/28-RS/P5)	BEARING (63/28-RS/P5)	1	
5	13222-I008-0000	CG125D曲轴正时主动齿轮	HUB DUMP CHAIN SPROCKET	1	
6	13220-J034-0300	CG150D曲轴连杆组合(无轴承、半圆键、主动齿) 立多禄KU	CONNECTING ROD COMP 3	1	
7	13103-J034-0000	CG150D活塞环一	PISTON RING 1	1	
8	13104-J034-0000	CG150D活塞环二	PISTON RING 2	1	
9	13120-J034-0000	CG150D油环组合	OIL RING ASSY	1	
10	1310A-J034-0000	CG150D活塞环总成	PISTON RING COMP	1	
11	91401-I006-0000	CB125脚活塞销挡圈	CLIP PISTON PIN	2	
12	13102-J034-0000	CG150D活塞销	PISTON PIN	1	
13	13101-J034-0300	CG150D活塞(改进型)	PISTON	1	
14	91106-I008-0000	CG125D磁电机安装螺栓M10×36	BOLT M10×36	1	
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					




传动机构 TRANSMISSION MECHANISM					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	93301-61521025000	CB125主轴止推垫圈 15. 2×1×25	WASHER 15. 2×1×25	1	
2	23222-I008-0002	CG125D五档主轴2档齿轮	GEAR M-2	1	
3	23222-I008-0005	CG125D五档主轴5档齿轮	GEAR M-5	1	
4	23223-I006-0000	CB125脚齿轮隔圈17. 3 (20) ×1. 6×26	WASHER	3	
5	23226-I008-0000	CG125D主轴齿轮卡圈	CIRCLIP	3	
6	23222-I008-0004	CG125D五档主轴4档齿轮	GEAR M-4	1	
7	23222-I008-0003	CG125D五档主轴3档齿轮	GEAR M-3	1	
8	23221-I008-0000	CG125D五档主轴芯轴	TRANSMISSION MAIN SHAFT	1	
9	93301-62020527000	CB125主轴止推垫圈 20. 2×0. 5×27	WASHER 20. 2×0. 5×27	1	
10	23231-I008-0000	CG125D主轴起动齿轮组合	FINAL SHAFT	1	
11	93301-61521030000	CB125副轴止推垫圈 15. 2×1×30	WASHER 15. 2×1×30	1	
12	23248-I008-0000	CG125D副轴启动过桥齿轮	GEAR	1	
13	23203-I008-0003	CG125D副轴启动齿轮衬套	GEAR BUSH	1	
14	93301-51650524000	CG125D副轴止推垫圈 16. 5×0. 5×24	WASHER 16. 5×0. 5×24	2	
15	23242-I008-0001	CG125D五档副轴1档齿轮	GEAR C-1	1	
16	23203-I008-0001	CG125D副轴1档齿轮衬套	GEAR BUSH	1	
17	23242-I008-0003	CG125D五档副轴3档齿轮	GEAR C-3	1	
18	23242-I008-0004	CG125D五档副轴4档齿轮	GEAR C-4	1	
19	23241-I008-0000	CG125D-1#五档副轴芯轴	TRANSMISSION COUNTER SHAFT	1	
20	23242-I008-0005	CG125D五档副轴5档齿轮	GEAR C-5	1	
21	23242-I008-0002	CG125D五档副轴2档齿轮	GEAR C-2	1	
22	93301-52001027000	CG125D副轴止推垫圈 20×1×27	WASHER 20×1×27	1	
23	23401-I008-0008	CG125D主动链轮 (428. 15)	DRIVE SPROCKET	1	
24	23402-I006-0000	CB125脚主动链轮固定板	FIXING PLATE, DRIVE SPROCKET	1	
25	B057830006001070B	GB5783螺栓M6×10 (白锌)	BOLT M6×10	2	
26	93301-51211018000	CG125D启动轴垫圈12. 1×1×18	WASHER 12. 1×1×18	1	附件
27	B0089401160000000	GB894. 1挡圈16	CIRCLIP 16	1	
28	2112B-I008-0000	CG125D棘轮导板组合	GUIDE PLATE ASS.	1	
29	21119-I008-0000	CG125D启动棘轮弹簧	SPRING, KICK STARTING RATCHET WHEEL	1	
30	93301-51611024000	CG125D启动轴垫圈16. 1×1×24	WASHER 16. 1×1×24	1	
31	21118-I008-0000	CG125D启动棘轮	STARTING RATCHET	1	
32	91402-I008-0000	CG125D启动轴弹性挡圈Φ 18. 5×1. 2×Φ 22. 4	CIRCLI Φ 18. 5×1. 2×Φ 22. 4	1	
33	93301-62000527000	CG125启动轴垫圈20×0. 5×27	WASHER 20×0. 5×27	1	
34	21117-I008-0000	CG125D启动齿轮	GEAR, KICK STARTER	1	
35	21107-I008-0001	CG125D启动轴芯轴 (油封光杆L:60) 兰白锌	PIVOT, KICK STARTING SHAFT	1	
36	21104-I008-0000	CG125D启动轴弹簧座	SEAT, SPRING, KICK STARTING SHAFT	1	
37	21106-I008-0000	CG125D启动轴复位弹簧	RETURN SPRING, KICK STARTING SHAFT	1	
38	21111-I008-0000	CG125D启动轴轴环	COLLAPSIBLE	1	
39	93301-51611030000	CG125D启动轴垫圈16. 1×1×30	WASHER 16. 1×1×30	1	附件
40	23220-I008-0000	CG125D五档主轴组合	MAIN SHAFT, TRANSMISSION	1	
41	23240-I008-0001	CG125D-1#五档副轴组合 (副轴147 副轴启动齿为钢套)	COUTERSHAFT TRANSMISSION	1	
42	23200-I008-0001	CG125D-1#主副轴组合 (副轴147 副轴启动齿为钢套)	TRANSMISSION MAIN.COUNTER SHAFT	1	
43	21100-I008-0202	CG125D启动轴总成 (油封光杆L:60 兰白锌)	KICK STARTING SHAFT ASSEMBLY	1	
44	21200-I008-0009	CG125D启动杆部件 (QD-9)	START-UP BAR COMP	1	
45					




传动机构
TRANSMISSION MECHANISM

变速机构 GEARSHIFT MECHANISM					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	B0089401120000000	GB894. 1挡圈12	CIRCLIP 12	1	
2	24303-I008-0000	CG125D换挡板弹簧	SPRING, GEARSHIFT PLATE	1	
3	24319-I008-0000	CG125D换挡板 (五档循环环档)	GEARSHIFT PLATE	1	
4	24301-I008-00000C	CG125D换挡轴组合 (五档循环环档 彩锌)	GEARSHIFT SHAFT COMP	1	
5	24302-I008-0000	CG125D换挡回位弹簧	RETURN SPRING	1	
6	93301-51400520000	CB125脚踏换挡臂垫圈14×0.5×20	WASHER 14×0.5×20	2	
7	B0089401140000000	GB894. 1挡圈14	CIRCLIP 14	1	
8	24300-I008-00010C	CG125D换挡臂部件 (五档循环环档 彩锌)	GEARSHIFT LEVER COMP	1	
9	B057830006002070G	GB5783螺栓M6×20 (白铬)	BOLT M6×20	1	
10	24400-I008-0016	CG125D变速踏板部件 (BT-16)	GEARSHIFT SHAFT	1	
11	24107-I006-0000	CB125脚踏拨叉轴	SHAFT, GEARSHIFT FORK	1	
12	24104-I006-0000	CB125脚副轴右拨叉	RIGHT FORK, COUNTERSHAFT	1	
13	24106-I006-0000	CB125脚主轴拨叉	CENTER FORK, MAINSHAFT	1	
14	24105-I006-0000	CB125脚副轴左拨叉	LEFT FORK, COUNTERSHAFT	1	
15	91126-I008-00000B	CG125D五星板紧固螺栓 (白锌)	BOLT	1	
16	B0009300060000000	GB93弹垫6	WASHER Φ6	1	
17	24202-I008-0600	CG125D五星板 (五档循环环档)	STOPPING PLATE	1	
18	B0011901040100000	GB119. 1销4×10	PIN 4×10	1	
19	24213-I008-0600	CG125D变速鼓 (五档循环环档)	GEARSHIFT DRUM	1	
20	24304-I006-0100	CB125脚-2#定位板弹簧	SPRING ,LOCATING PLATE	1	
21	2434A-I008-0400	CG125D-2#定位板组合 (五档循环环档及五档非循环环档)	LOCATING PLATE ASSY	1	
22	91115-I008-00000B	CG125D档位定位板螺栓 (五档循环环档 白锌)	BOLT FIXING PLATE	1	
23	88004-I008-0100	CG125D-2#档显动触头	CONTACT, CEARINDICATION	1	
24	88031-I008-150045	CG125D-2A#档显线束 (五档循环环 L:450)接口D03	GEARSHIFT SWITCH COMP	1	
25	B008190106002020B	GB819. 1螺钉M6×20 (白锌)	SCREW M6×20	1	
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					




磁电机总成 MAGNETO COMP					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	82130-I008-0100	CG125D磁电机转子组合 (12V8极)	ROTOR ASSY, MAGNETO	1	
2	82120-I008-020043	CG125D磁电机定子组合 (12V8极全波交流大盒 L1:430) 接口21	STATOR ASSY, MAGNETO	1	
3	B057830005001670B	GB5783螺栓M5×16 (白锌)	BOLT M5×16	2	
4	B057830005002570B	GB5783螺栓M5×25 (白锌)	BOLT M5×25	3	
5	91197-I008-00000C	CG125D超越离合器紧固螺钉M8×18 (彩锌)	BOLT M8×18	3	
6	82130-I008-0101	CG125D磁电机转子组合 (12V8极 不带超越离合器)	ROTOR ASSY, MAGNETO	1	
7	21303-I008-0000	CG125D启动离合器滚柱弹簧	SPRING	3	
8	21305-I008-0000	CG125D启动离合器弹簧套/顶销	CONE BILOCKAGE	3	
9	21304-I008-0000	CG125D启动离合器滚柱	CLUTCH ROLLER	3	
10	21301-I008-0000	CG125D超越离合器本体组合	ASSEMBLY, SPIDER	1	
11	21300-I008-0000	CG125D超越离合器部件	ASSEMBLY, OVERRUNNING CLUTCH	1	
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					



磁电机总成 MAGNETO COMP

电启动机构 ELECTRIC STARTING MECHANISM					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	82200-I008-440151	CG125D-3#启动电机部件 (机座8805 机壳8805 无字 圆形 单线L:510)	STARTING MOTOR ASSY	1	
2	21402-I008-0100	CG125D-2#双联齿轮轴	SHAFT, REDUCTION	1	
3	93301-51050518000	CG125D双联齿轮垫圈10. 5×0. 5×18	WASHER 10. 5×0. 5×18	4	
4	2140A-I008-0103	CG125D-2#双联齿轮组合 (一) 带含油轴承	GEAR, REDUCTION, 1	1	
5	21401-I008-1100	CG125D-4#双联齿轮 (二) 含油轴承专用	GEAR, REDUCTION, 2	1	
6	2142A-I008-0100	CG125D启动大齿轮组合 (改进)	PLATE GEAR ASSY	1	
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					





www.seacubemoto.com



电启动机构


ELECTRIC STARTING MECHANISM

电器件 ELECTRIC					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	81100-I008-000050	高压包MG03B L:500	IGNITION COIL	1	
2	81200-I008-0000	点火器MD125-3B	C. D. I	1	
3	83100-I008-010020	整流调压器MT12V8-ZS05B	RECTIFIER	1	
4	82290-I049-000016	继电器MQJ10-ZS01A	RELAY	1	
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					
16					
17					
18					
19					
20					
21					
22					
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					



电器件 ELECTRIC

废气再循环系统 EXHAUST GAS RECIRCULATION SYSTEM					
序号 NO.	编码 (PART CODE)	中文名称 (CHINESE DESCRIPTION)	英文名称 (ENGLISH DESCRIPTION)	数量 QTY	备注REMARK
1	16156-I008-0100	CG125D二次空滤器连接胶管II (14×9×400)	CONNECTING PIPE	1	
2	16157-I008-0000	CG125D二次空滤器连接胶管卡圈14	HOOP	2	
3	16160-I008-0000	CG125D二次空滤器部件	SEC. AIR BOX VALVE	1	
4	16156-I008-0000	CG125D二次空滤器连接胶管I (14×9×230(35))	CONNECTING PIPE	1	
5	16157-I008-0100	CG125D二次空滤器连接胶管卡圈15.3	HOOP	1	
6	B166740A06002070X	GB16674小盘螺栓M6×20(兰白锌)	BOLT M6×20	1	
7	B166740A06002870X	GB16674小盘螺栓M6×28(兰白锌)	BOLT M6×28	1	
8	B166740A06001670X	GB16674小盘螺栓M6×16(兰白锌)	BOLT M6×16	3	
9	18090-J034-0001	CG150D空气泵(带防尘胶套)	GAS PUMP	1	
10	18110-I008-0000	CG125D废气循环橡胶管组件I (Φ15×Φ9×50×50)	RUBBER PIPE	1	
11	18097-I008-0000	CG125D废气循环管I卡箍	CLAMP	2	
12	18092-I008-0000	CG125D废气循环橡胶管I (Φ15×Φ9×50×50)	RUBBER PIPE	1	
13	1809B-I008-00000Y	CG125D废气循环铁管组合(电泳黑漆)	IRON PIPE	1	
14	90268-DA80-0000	PW70废气循环铁管纸垫	PAPER GASKET	1	
15	90274-I008-0000	CG125D二次空气泵支架隔热垫	INSULATING GASKET	1	
16	18089-I008-00000C	CG125D空气泵支架板(彩锌)	GAS PUMP PLATE	1	
17	93301-3062201300B	70缸头盖铁垫圈6.2×2×13(白锌)	WASHER 6.2×2×13	2	
18	B061700006000090X	GB6170螺母M6(兰白锌)	NUT 6	1	
19	18092-I008-0106	CG125D废气循环橡胶管II-7#(Φ9×Φ4×270×40)	RUBBER PIPE	1	
20	18097-I008-0100	CG125D废气循环管II卡箍	CLAMP	1	
21	18110-I008-0106	CG125D废气循环橡胶管组件II-7#(Φ9×Φ4×270×40)	RUBBER PIPE	1	
22	18082-I008-00000X	CG125D废气循环橡胶管II管夹(兰白锌)	RUBBER PIPE	1	
23					
24					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					



环保装置
ENVIRONMENT PROTECT MECHANISM