

HP & HP-PV Series Pure Sine Wave Inverter/Solar Charger

Technical parameter



- Ultra Low THD, Typically 7% Under Full Linear Load
- Battery Temperature Sensing For Increased Charging Precision
- Powerful Charge Rate up to 120Amp, Selectable From 0% -100%
- Auto Gen Start Function For Off Grid System With Generator As Backup Power
- MPPT Solar Charger Controller Available







Features

- Smart Remote Control
- Support Solar Panel with MPPT Function
- Designed to Operate under Harsh Environment
- DC Start & Automatic Self-Diagnostic Function
- Compatible with Both Linear & Non-Linear Load
- Easy to Install & Easy to Operate & Easy to Solve
- Low DC Voltage Supports Home & Office Appliances
- Powerful Charge Rate Up to 120Amp, Selectable From 0%-100%
- High Efficiency Design & "Power Saving Mode" to Conserve Energy
- Battery Priority Mode, Designates the Inverter-Preferred UPS Config u ration
- 13 Vdc Battery Recover Point, Dedicated for Renewable Energy Systems
- 8 Pre Set Battery Type Selector Plus De-sulphation for Totally Flat Batteries
- 4-step Intelligent Battery Charging, PFC (Power Factor Correction) for Charger
- 8 ms Typical Transfer Time Between Utility & Battery, Guarantees Power Continuity
- 15s Delay Before Transfer when AC Resumes, Protection for Load when Used with Generator

Product dominance



On the rear panel of inverter, there are 5 DIP switches which enable users to customize the performance of the device.

Switch	Switch Fu	unction	Position: 0	Position: 0			
SW1	Low Battery	Trip Volt	10.0VDC For Deep-Cycle Battery	10.5VDC For Starting Battery			
			2 for 24Vdc, for 48Vdc				
	AC Input Range/(AVR)	AC Source	For Utility Mode	For Generator Mode 154-253Vac/(150-276Vac)			
SW2		230Vac HV	184-253Vac/(176-276Vac)				
	riange/(AVII)	120Vac LV	100-135Vac/(92 -144Vac)	90-135Vac/(78-144Vac)			
SW3	Power Saver Auto Setting		Night Charger Function	Detect Load Per 3 Secs			
SW4	O/P Frequer	ncy Setting	50Hz	60Hz			
SW5	Solar/AC Prio	rity Setting	Utility Priority	Battery Priority			

Pure Sine Wave Inverter/Solar Charger

Low Battery Trip Volt:

The Low Battery Trip Volt is set at 10.0VDC by default. It can be customized to 10.5VDC

AC Input Range:

There are different acceptable AC input ranges for different kinds of loads. It can be customized from 184-253VAC to 154-253VAC.

Load Sensing Cycle:

The inverter is factory defaulted to detect load for 250ms in every 30 seconds. This cycle can be customized to 3 seconds thru the SW3 0n DIP switch.

Frequency adjust:

The frequency of the inverter is arranged by the Sw4.

The factory default configuration for 220/230/240VAC inverter is 50Hz,and 60Hz for 100/110/120VAC inverter. While the output freq can be easily changed once a qualified freq is applied to the inverter.

Solar/ AC Priority Setting:

Our inverter is designed AC priority by default. This means, when AC input is present, the battery will be charged first, and the inverter will transfer the input AC to power the load.

The AC Priority and Battery Priority switch is available upon request. When you choose battery priority, the inverter will inverting from battery despite the AC input.


Specification

			HP Pure	Sine Wav	e Inverter/	Charger						
	Model	1.0KW	1.5KW	2.0KW	3.0KW	4.0KW	5.0KW	6.0KW	8.0KW	10.0KW	12.0KW	
Inverter	Continuous Output Power	1.0KW	1.5KW	2.0KW	3.0KW	4.0KW	5.0KW	6.0KW	8.0KW	10.0KW	12.0KW	
	Surge Rating (20Secs)	3.0KW	4.5KW	6.0KW	9.0KW	12.0KW	15.0KW	18.0KW	24.0KW	30.0KW	36.0KW	
	Output Waveform	Pure Sine wave/Same as input (Bypass Mode)										
	Nominal Efficiency	>88%(Peak)										
	Line Mode Efficiency					>9	5%					
	Power Factor	0.9-1.0										
Output	Nominal Output Voltage rms	100-110-120Vac / 220-230-240Vac										
	Output Voltage Regulation	±10%RMS										
	Output Frequency	50Hz±0.3Hz / 60Hz±0.3Hz										
	Short Circuit Protection	Yes (1sec after fault)										
	Typical transfer Time	10ms (Max)										
	THD	< 10%										
DC Input	NominalInput Voltage		12.0V	dc/24.0Vd	c/48.0Vdc		24.0Vdc	/48.0Vdc		48.0Vdc		
	Minimum Start Voltage	10	0.0Vdc/ 10	.5Vdc for	12Vdc Mc	de						
	Low Battery Alarm	10.5Vdc/ 11.0Vdc for 12Vdc Mode										
	Low Battery Trip	10	0.0Vdc/10	.5Vdc for	12Vdc Mc	ode	*2 for 24Vdc, *4 for 48Vdc;					
	High Voltage Alarm	16.0Vdc for 12Vdc Mode										
	Low Battery Voltage Recover	15.5Vdc for 12Vdc Mode										
	Idle Consumption- Search Mode	< 25W When Power Saver On. (Refer to Table)										
	Output Voltage	Depends on battery type (Refer to Table 2.5.2)										
	Charger Breaker Rating	20A	20A	20A	25A	32A	40A	40A	50A	80A	80A	
Charger	Max Charge Power Rate		1/3 Rating Power (Refer to Table 2.5.3)									
	Battery Initial Voltage for start		10-15.7\	dc for 12	Vdc Mode		*2 for 24Vdc, *4 for 48Vdc;					
	Over Charge Protection S.D.		15.7V	dc for 12V	dc Mode							
BTS	Battery Temperature Sensor (Optional)	Yes (Refer to the table) Variances in Charging Voltage & S.D Voltage Base on the Battery Temperature.										
	Input Voltage Waveform	Sine wave (Grid or Generator)										
	Nominal Voltage	100-110-120Vac / 220-230-240Vac										
Bypass & Protection	Max Input AC Voltage	150Vac For 120Vac LV Mode; 300Vac For 230Vac HV Mode;										
	NominalInput Frequency	50Hz or 60Hz										
	Low Freq Trip	47±0.3Hz for 50Hz, 57±0.3Hz for 60Hz										
	High Freq Trip	55±0.3Hz for 50Hz, 65±0.3Hz for 60Hz										
	Overload protection (SMPS load)	Circuit Breaker										

Pure Sine Wave Inverter/Solar Charger

		F F	IP Pure S	ine Wave	Inverter/C	Charger						
	Output Short Circuit Protection	Circuit Breaker										
Bypass & Protection	Bypass Breaker Rating	20A	20A	20A	25A	32A	40A	40A	50A	80A	80A	
	Transfer Switch Rating	30Amp for UL&TUV					40Amp for UL 80Amp				np for UL	
	Bypass Without Battery Connected					ptional)						
	Max Bypass Current	30Amp					40Amp		80Amp			
Solar Charger	Rated Voltage	12Vdc/24Vdc/48Vdc										
	Solar Input Voltage Range	15-45Vdc/30-70Vdc/60-100Vdc										
	Rated Charge Current	40 or 60A										
	Rated Output Current	15A										
	Self Consumption	< 10mA										
	Bulk Charge (Default)		14.5V	dc for 12V	dc Mode							
	Floating Charge(Default)	13.5Vdc for 12Vdc Mode										
Optional)	Equalization Charge(Default)		14.OV	dc for 12V	dc Mode	*2 for 24Vdc, *4 for 48Vdc ;						
optional	Over Charge Disconnection		14.8V	dc for 12V	dc Mode							
	Over Charge Recovery		13.6V	dc for 12V	dc Mode							
	Over Discharge Disconnection		10.8V	dc for 12V	dc Mode							
8	Over Discharge Reconnection		12.3V	dc for 12V	dc Mode							
	Temperature Compensation	-13.2mV/°C for 12Vdc Mode										
	Ambient Temperature	0-40°C (Fullload) 40-60°C (Derating)										
	Mounting					I Mount						
Mechanical Specifications	Inverter Dimensions(L*W*H)	388*415*200mm				488*415*200mm			588*415*200mm			
	Inverter Weight (Solar Chg) KG	21+2.5	22+2.5	23+2.5	27+2.5	38+2.5	48+2.5	49+2.5	60+2.5	66+2.5	70+2.5	
	Shipping Dimensions(L*W*H)	550*520*310mm 650					0*520*310mm 750*520*310mm					
	Shipping Weight (Solar Chg) KG	23+2.5	24+2.5	25+2.5	29+2.5	40+2.5	50+2.5	51+2.5	62+2.5	68+2.5	72+2.5	
	Display	Status LEDs / Status LEDs + LCD										
	Standard Warranty	1 Years										

Wiring





MPPT SOLAR CHARGE & DISCHARGE CONTROLLER

- High converting efficiency higher than 97%
- Reversed current protection for preventing equipment damage
- Automatic battery temperature compensation for long-term reliability
- Three stage chage control system (bulk, absorption,and float mode) with temperture compensation